



CHCNAV i89 GNSS USER GUIDE



Survey & Engineering | Apr 2025

Table of Content

| | |
|---|----|
| Preface | 1 |
| Copyright | 1 |
| Copyright 2023 | 1 |
| Trademarks | 1 |
| Safety Warnings | 1 |
| FCC Interference Statement | 2 |
| CE Interference Statement | 2 |
| Conformity to Japanese regulations | 2 |
| 1 Introduction | 3 |
| 1.1 Safety Information | 3 |
| 1.1.1 Warnings and Cautions | 3 |
| 1.2 Regulations and Safety | 3 |
| 1.2.1 Use and Care | 4 |
| 1.3 Technical Support | 4 |
| 1.4 Disclaimer | 4 |
| 1.5 Your Comments | 4 |
| 2 Getting Started with I89 | 5 |
| 2.1 About the Receiver | 5 |
| 2.2 Parts of the Receiver | 5 |
| 2.2.1 Front Panel | 5 |
| 2.2.2 Lower Housing | 6 |
| 2.2.3 Receiver Ports | 7 |
| 2.3 Batteries and Power | 8 |
| 2.3.1 Batteries | 8 |
| 2.3.2 The Internal Battery | 8 |
| 2.3.3 Battery Safe | 8 |
| 2.4 Product Basic Supply Accessories | 10 |
| 2.4.1 Base Kit Basic Supply | 10 |
| 2.4.2 Rover Kit Basic Supply | 11 |
| 2.5 Connecting to an Office Computer | 12 |
| 2.6 Connecting to a Controller | 12 |
| 2.6.1 Connecting via Wi-Fi with LandStar 8 Software | 12 |
| 2.6.2 Connecting via Bluetooth with LandStar 8 Software | 14 |
| 2.7 Downloading Logged Data | 16 |
| 2.7.1 FTP Download | 16 |
| 2.7.2 USB Download | 18 |
| 3 Equipment Setup and Operation | 20 |
| 3.1 Post-processing Base Station Setup | 20 |
| 3.2 Real-Time Base Station Setup | 22 |
| 3.2.1 Internal UHF | 22 |
| 3.2.2 External UHF | 24 |
| 3.3 Real-Time Rover Station Setup | 25 |
| 3.4 Working with the Tilt Compensation | 26 |
| 3.4.1 Operation Steps for first IMU initialization | 26 |
| 3.4.2 Notes of using tilt measurement | 28 |
| 3.5 Visual Survey | 29 |
| 3.5.1 Survey point mode | 29 |
| 3.5.2 Modeling mode | 32 |
| 4 Configuring Through a Web Browser | 34 |
| 4.1 Status Menu | 36 |
| 4.1.1 Position Submenu | 36 |
| 4.1.2 Activity Submenu | 36 |
| 4.1.3 Google Map Submenu | 37 |

| | |
|--|----|
| 4.2 Satellites Menu | 38 |
| 4.2.1 Tracking Table Submenu | 38 |
| 4.2.2 Tracking Info. Table Submenu | 39 |
| 4.2.3 Tracking Skyplot Submenu | 39 |
| 4.2.4 Satellite Activation Submenu | 40 |
| 4.3 Receiver Configuration Menu | 40 |
| 4.3.1 Description | 40 |
| 4.3.2 Antenna Configuration Submenu | 41 |
| 4.3.3 Reference Station Settings Submenu | 42 |
| 4.3.4 Receiver Reset Submenu | 44 |
| 4.3.5 Languages Submenu | 44 |
| 4.3.6 User Management Submenu | 45 |
| 4.4 Data Recording Menu | 45 |
| 4.4.1 Log Settings Submenu | 45 |
| 4.4.2 FTP Push Settings Submenu | 48 |
| 4.4.3 FTP Push Log Submenu | 48 |
| 4.5 IO Settings Menu | 49 |
| 4.5.1 IO Settings Submenu | 49 |
| 4.6 Network Setting Menu | 56 |
| 4.6.1 Email Alarm Submenu | 56 |
| 4.6.2 HTTP Submenu | 57 |
| 4.6.3 HTTPS Submenu | 57 |
| 4.7 Module Setting Menu | 58 |
| 4.7.1 Description Submenu | 58 |
| 4.7.2 WiFi Submenu | 58 |
| 4.7.3 Bluetooth Settings Submenu | 59 |
| 4.7.4 Radio Settings Submenu | 59 |
| 4.7.5 IMU Settings Submenu | 59 |
| 4.8 Firmware Menu | 61 |
| 4.8.1 Firmware Info Submenu | 61 |
| 4.8.2 Hardware Version Submenu | 62 |
| 4.8.3 Config File Submenu | 62 |
| 4.8.4 System Log Download Submenu | 62 |
| 4.8.5 User Log Submenu | 63 |
| 4.8.6 Firmware Update Submenu | 63 |
| 4.8.7 GNSS Board Upgrade Submenu | 64 |
| 4.8.8 Radio Upgrade Submenu | 64 |
| 4.8.9 Upgrade Online Submenu | 64 |
| 4.8.10 GNSS Registration Submenu | 65 |
| CHC Navigation | 66 |

Preface

Copyright

Copyright 2023

CHCNAV | CHC Navigation Technology Ltd. All rights reserved. The CHCNAV are trademark of CHC Navigation Technology Limited. All other trademarks are the property of their respective owners.

Trademarks

All product and brand names mentioned in this publication are trademarks of their respective holders.

Safety Warnings

GNSS (Global Navigation Satellite System) receivers are electronic devices that use signals from satellites to determine location, speed, and time. While GNSS receivers are generally safe to use, there are some safety considerations that users should keep in mind:

- (1) Do not rely solely on GNSS for navigation: GNSS signals can be disrupted by various factors such as tall buildings, trees, and bad weather. It is important to use other navigation aids such as maps, compasses, and visual landmarks.
- (2) Keep GNSS receivers away from other electronic devices: Electronic devices such as mobile phones, radios, and computers can emit electromagnetic interference (EMI) that can disrupt GNSS signals. Keep GNSS receivers away from such devices to avoid EMI.
- (3) Do not tamper with GNSS receivers: Tampering with GNSS receivers or modifying their software can cause them to malfunction or produce inaccurate readings. Only use GNSS receivers that are certified and authorized for use.
- (4) Follow manufacturer instructions: Follow the manufacturer's instructions regarding the safe use and handling of GNSS receivers. This includes instructions for charging, cleaning, and storing the device.
- (5) Dispose of GNSS receivers properly: When disposing of GNSS receivers, follow local regulations for electronic waste disposal to avoid harming the environment.



- (6) It is important to use GNSS receivers safely to avoid accidents or injury. If you experience any issues or concerns with your GNSS receiver, contact the manufacturer or a qualified technician for assistance.

FCC Interference Statement

This equipment has been designed to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules in the Portable Mode. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

CE Interference Statement

Declaration of Conformity: Hereby, CHC Navigation Technology Ltd. declares that this i89 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

Conformity to Japanese regulations

Japanese Radio Law and Japanese Telecommunications Business Law Compliance.

- This device is granted pursuant to the Japanese Radio Law and the Japanese Telecommunications Business Law.
- This device should not be modified (otherwise the granted designation number will become invalid).

1 Introduction

The i89 GNSS Receiver User Guide describe show to setup and use the CHCNAV i89 GNSS receiver. In this manual, “the receiver” refers to the i89 GNSS receiver unless otherwise stated. Even if you have used other Global Navigation Satellite Systems (GNSS) products before, CHCNAV recommends that you spend sometime reading this manual to learn about the special features of this product. If you are not familiar with GNSS, go to www.chcnav.com for an interactive look at CHCNAV and GNSS.

1.1 Safety Information

1.1.1 Warnings and Cautions

An absence of specific alerts does not mean that there are no safety risks involved.

A Warning or Caution information is intended to minimize the risk of personal injury and/or damage to the equipment.



WARNING - A Warning alerts you to a potential misused or wrong setting of the equipment.



CAUTION - A Caution alerts you to a possible risk of serious injury to your person and/or damage to the equipment.

1.2 Regulations and Safety

The receivers contain a built-in wireless modem for signal communication through Bluetooth wireless technology or through external communication data link. Regulations regarding the use of the wireless modem vary greatly from country to country. In some countries, the unit can be used without obtaining an end-user license. However, in some countries, the administrative permissions are required. For license information, consult your local dealer. Bluetooth operates in license-free bands.

Before operating a i89 GNSS receiver, determine if authorization or a license to operate the unit is required in your country. It is the responsibility of the end-user to obtain an operator's permit or license for the receiver for the location or country of use.

1.2.1 Use and Care

This receiver is designed to withstand the rough environment that typically occurs in the field. However, the receiver is high-precision electronic equipment and should be treated with reasonable care.



CAUTION - Operating or storing the receiver outside the specified temperature range will cause irreversible damage.

1.3 Technical Support

If you have a problem and cannot find the information you need in this manual or CHCNAV website (www.chcnav.com) , contact your local CHCNAV dealer from which you purchased the receiver(s). If you need to contact CHCNAV technical support, please contact us by email(support@chcnav.com) or Skype (chc_support).

1.4 Disclaimer

Before using the receiver, please make sure that you have read and understood this User Guide, as well as the safety information. CHCNAV holds no responsibility for the wrong operation by users and for the losses incurred by the wrong understanding about this User Guide. However, CHCNAV reserves the rights to update and optimize the contents in this guide regularly. Please contact your local CHCNAV dealer for new information.

1.5 Your Comments

Your feedback about this user guide will help us to improve it in future revision. Please email your comments to support@chcnav.com.

2 Getting Started with I89

2.1 About the Receiver

The new CHCNAV i89 GNSS receiver offers integrated IMU-RTK technology to provide a robust and accurate GNSS positioning in any circumstances. Unlike the standard MEMS based GNSS receivers, the i89 GNSS IMU-RTK combines state-of-the-art GNSS RTK engine, calibration-free professional IMU sensor and advanced GNSS tracking capabilities. Survey projects are achieved with high productivity and reliability pushing the boundaries of conventional GNSS RTK survey.

The LCD panel enables user to check satellite-tracking status, Bluetooth and Wi-Fi technology provides cable-free communication between the receiver and controller.

The receiver can be used as the part of an RTK GNSS system with CHCNAV LandStar 8 software. And you can download the GNSS data that recorded in the internal memory of receiver to a computer.

To configure the receiver for performing a wide variety of functions, you can use the web interface by connecting the receiver with PC or smartphone through Wi-Fi.

2.2 Parts of the Receiver

The operating controls are all located on the front panel. Type-C port , radio antenna port and connectors are located on the bottom of the unit.

2.2.1 Front Panel

The following figure shows a front view of the receiver.

The front panel contains four indicator LEDs and two buttons.





| Name | Description |
|----------------------------------|--|
| Correction LED (Yellow/Green) | <ul style="list-style-type: none"> Indicates whether the receiver is transmitting/receiving differential data. As a Base station: successfully transmitting differential data, flash yellow light. As a Rover station: successfully receiving differential data from Base station will flash yellow light when it is single or float, flash green light when it is fixed. |
| Satellite LED (Blue) | <ul style="list-style-type: none"> Shows the number of satellites that the receiver has tracked. When the receiver is searching satellites, the blue LED flashes once every 5 seconds. When the receiver has tracked N satellites, the blue LED will flash N times every 5 seconds. |
| Power LED(Red) | <ul style="list-style-type: none"> Under normal conditions red power light The power light shows orange when charging The power light shows green when fully charged |
| Static LED (Yellow) | <ul style="list-style-type: none"> Flash means static is on. |
| Power button (White) | <ul style="list-style-type: none"> Press and hold this button for 3 seconds to turn on or turn off the receiver. |
| Fn button (White) | <ul style="list-style-type: none"> Press and hold this button for 3 seconds to turn on or turn off the static mode. |

2.2.2 Lower Housing

The lower housing contains one TNC radio antenna connector and one USB type C port.



2.2.3 Receiver Ports

| Port | Name | Description |
|---|-------------------------|---|
|  | USB port | <ul style="list-style-type: none"> • This port is a type-C USB connector that supports USB communications. • Users can use USB Cable supplied with the system to download the logged data to a computer but can't upload the data. • USB port can used to charge the i89 GNSS receiver |
|  | Radio antenna connector | <ul style="list-style-type: none"> • Connect a radio antenna to internal radio of the receiver. And this connector is not used if you are using an external radio. |

2.3 Batteries and Power

2.3.1 Batteries

The receiver has an built-in non-removable Lithium-ion battery.

2.3.2 The Internal Battery

The rechargeable Lithium-ion battery is supplied partially charged.



WARNING – Charge and use the rechargeable Lithium-ion battery only in strict accordance with the instructions. Charging or using the battery in unauthorized device can cause an explosion or fire and can result in personal injury and/or equipment damage.

To prevent injury or damage:

- Do not charge or use the battery if it appears to be damaged or leaking.
- Charge the Lithium-ion battery only in a CHCNAV product that is specified to charge it. Be sure to follow all instructions that are provided with the battery charger.
- Discontinue charging a battery that gives off extreme heat or a burning odor.
- Use the battery only in CHCNAV equipment that is specified to use it.
- Use the battery only for its intended use and according to the instructions in the product documentation.

2.3.3 Battery Safe



WARNING – Do not damage the rechargeable Lithium-ion battery. A damaged battery can cause an explosion or fire and can result in personal injury and/or property damage.

To prevent injury or damage:

- Do not use or charge the battery if it appears to be damaged. Signs of damage include, but are not limited to discoloration, warping, and leaking battery fluid.
- Do not expose the battery to fire, high temperature, or direct sunlight.
- Do not immerse the battery in water.
- Do not use or store the battery inside a vehicle under hot weather condition.

- Do not drop or puncture the battery.
- Do not open the battery or short-circuit its contacts.








WARNING – Avoid contact with the rechargeable Lithium-ion battery if it appears to be leaking. Battery fluid is corrosive and contact with it can result in personal injury and/or property damage.


To prevent injury or damage:

- If the battery leaks, avoid with the battery fluid.
- If battery fluid gets into your eyes, immediately rinses your eyes with clean water and seek medical attention. Please do not rub your eyes!
- If battery fluid gets onto your skin or clothing, immediately use clean water to wash off the battery fluid.








2.4 Product Basic Supply Accessories

2.4.1 Base Kit Basic Supply

| Item | Picture |
|-------------------------------|---|
| i89 GNSS Receiver |  |
| UHF Whip Antenna |  |
| Power Adapter |  |
| USB Type-C |  |
| H.I. Tape |  |
| Extension pole |  |
| Tribrach with optical plummet |  |
| Auxiliary H.I. Tool |  |

| | |
|----------------------------|--|
| <p>Transport Hard Case</p> |  |
|----------------------------|--|


2.4.2 Rover Kit Basic Supply

| Item | Picture |
|----------------------------|---|
| <p>I89 GNSS Receiver</p> |  |
| <p>UHF</p> |  |
| <p>Power Adapter</p> |  |
| <p>USB Type-C</p> |  |
| <p>2M Range Pole w/bag</p> |  |
| <p>Auxiliary H.I. Tool</p> |  |
| <p>Transport Hard Case</p> |  |

2.5 Connecting to an Office Computer

The receiver can be connected to an office computer for serial data transfer or settings via a HCE600 USB Type-C. Before you connect to the office computer, ensure that the receiver is powered on by internal battery or external power.

The following figure shows how to connect to the computer for serial data transfer or settings:




2.6 Connecting to a Controller


2.6.1 Connecting via Wi-Fi with LandStar 8 Software

Turn on the controller → run LandStar 8 → goto **Config** main menu → tap **Connect**.


In the Connect screen, select **CHC** for the Manufacture field, **i89** for Device Type field, **WIFI** for Connection Type field.




Tap the Wireless Lan icon on the right side to select the hotspot → Switch on the WiFi module by the top switch → select the target device in the list.



Tap **Connect** to link to the hotspot. If the first-time connection to this hotspot, user may type in the password.




Tap the **Connect** button to build the connection.




2.6.2 Connecting via Bluetooth with LandStar 8 Software

Turn on the controller → run LandStar 8 → goto **Config** main menu → tap **Connect**.


In the Connect screen, select **CHC** for the Manufacture field, **i89** for Device Type field, **Bluetooth** for Connection Type field.



Tap the **Bluetooth Manager** and turn on the **Bluetooth** function to search Bluetooth device around → select the target device in the list → Tap back button → select the target device in the Bluetooth manager list.



Tap the **Connect** button to build the connection.



2.7 Downloading Logged Data

Data logging involves the collection of GNSS measurement data over a period at a static point or points, and subsequent post-processing of the information to accurately compute baseline information. Data logging using receivers requires access to suitable GNSS post-processing software such as the CHC Geomatics Office (CGO) Software.

2.7.1 FTP Download

The procedures of downloading logged data through FTP areas follows:


- (1) Switch on the receiver, search its Wi-Fi in the computer and connect.
- (2) After the successful connection, open the file manager in the computer and input “ftp://192.168.1.1” in the address box.



- (3) Input user name and password, the default user name and password are “ftp”.




- (4) Double click the folder “repo_receiver SN” (take 3411955 as example), you will see 9 folders. The “push_log” folder is used to save the log files, and the other 8 folders represent different logging sessions and are used for store static data.




(5) Double click the folder that you have configured to store the static data, you will see the folder(s) created by the i89 system automatically and named by the date which is decided by GPS time when you start to log data.




(6) Select the destination folder and double click it, two folders named as different data format (hcn and rinex) will be displayed.



(7) Select the data format that you configured to save the static data, you will find the static raw data.



Notes: For hcn files, the name of the file is represented as XXXXXDDDNN, where XXXXXX is the SN of the receiver, DDD is day of year, and NN is the recording session.

 **WARNING** – The static data will be saved in the first logging session, the “record_1” folder, by default. Old files will be deleted if the storage space is full. If you configure not to auto delete old files when the memory is low, the receiver will stop data logging.


2.7.2 USB Download

The procedures of downloading logged data in the receiver areas follows:


(1) Switch on the receiver and connect it with a computer by HCE600 Type-C. After the successful connection, a removable disk named as the Serial Number (SN) of the receiver will appear on the computer.




(2) Double click the removable disk and you will see the folder named as “repo”.




(3) Double click this folder, you will see the folders. The “push_log” folder is used to save the log files, and another folders represent different logging session and are used for store static data.




(4) Double click the folder that you have configured to store the static data, you will see the folder(s) created by the i89 system automatically and named by the date which is decide by GPS time when you start to log data.



(5) Select the destination folder and double click it, and then two folders named as different data format (hcn and rinex) will be displayed.



(6) Select the data format that you have configured to save the static data, you will find the static raw data.



Tip – For hcn files, the name of the file is represented as XXXXXXDDDNN, where XXXXXX is the SN of the receiver, DDD is day of year, and NN is the recording session.




WARNING – The static data will be saved in the first logging session, the “record_1” folder, by default. Old files will be deleted if the storage space is full. If you configure not to auto delete old files when the memory is low, the receiver will stop data logging.

3 Equipment Setup and Operation

3.1 Post-processing Base Station Setup

For good performance, the following base station setup guidelines are recommended:

Components:



| NO | NAME |
|----|------------------------|
| a | I89 GNSS receiver |
| b | Extension pole (30 cm) |
| c | Tribrach adaptor |
| d | Tribrach w/ Opti |
| e | Aluminum tripod |

Steps:

- (1) Put tripod in the target position, center and level it roughly.

- (2) Place and lock the tribrach in the tripod.
- (3) Connect the Tribrach adaptor to the Tribrach w/ Opti.
- (4) Screw the receiver onto the extension pole, and connect it to Tribrach w/ Opti.
- (5) Center and level the receiver more precisely.
- (6) Connect the receiver to external battery by using USB Type-C cable if necessary.
- (7) Turn on the receiver by pressing the power button for 3 s.
- (8) Measure the antenna height by using H.I. tape and auxiliary H.I. tool.
- (9) Press the function button to select Data to start recording static raw.

If work with a data controller:

- (10) Switch on the data controller and connect it to the receiver.
- (11) Use software to configure the receiver as static mode.

3.2 Real-Time Base Station Setup

3.2.1 Internal UHF

For good rover operation, the following base station setup guidelines are recommended:

Components:



| NO | NAME |
|----|------------------------|
| a | i89 GNSS receiver |
| b | UHF whip antenna |
| c | Extension pole (30 cm) |
| d | Tribrach adaptor |
| e | Tribrach w/ Opti |
| f | Aluminum tripod |

Steps:

(1) Put tripod in the target position, center and level it roughly.

(2) Place and lock the tribrach in the tripod.

If work as a UHF base station, the UHF whip antenna need to be connected to the receiver.

(3) Connect the receiver to external battery by using external power cable if necessary.

(4) Connect the receiver to external storage disk by using USB cable if necessary.

(5) Turn on the receiver by pressing the power button for 3 s.

(6) Measure the antenna height by using H.I. tape and auxiliary H.I. tool.

(7) Switch on the data controller and connect it to the receiver.

(8) Use software to configure the receiver as cellular base or UHF base mode.

3.2.2 External UHF

For good performance, the following base station setup guidelines are recommended:

Steps:

- (1) Put tripod in the target position, center and level it roughly.
- (2) Place and lock the tribrach in the tripod.
- (3) Screw the receiver onto the tribrach.
- (4) Center and level the receiver more precisely.
- (5) Connect the receiver to external datalink by using GPS to datalink cable.
- (6) Hang the external datalink on the tripod leg.
- (7) Connect the receiver to external battery by using external power cable if necessary
- (8) Connect the receiver to external storage disk by using USB cable if necessary.
- (9) Turn on the receiver by pressing the power button for 3 s.
- (10) Measure the antenna height by using H.I. tape and auxiliary H.I. tool.
- (11) Turn on the external datalink and configure it as need. If work with a data controller:
- (12) Switch on the data controller and connect it to the receiver.
- (13) Use software to configure the receiver as external datalink base mode.

3.3 Real-Time Rover Station Setup

For good performance, the following rover station setup guidelines are recommended:

Components:



| No. | Name |
|-----|---------------------|
| a | i89 GNSS receiver |
| b | 2M range pole w/bag |

Steps:

(1) Keep the receiver fully charged.

If work as a UHF rover station, the UHF whip antenna need to be connected to the receiver.

(2) Turn on the receiver by pressing the power button for 3 s.

(3) Switch on the data controller and connect it to the receiver.

(4) Use software to configure the receiver as cellular rover or UHF rover mode.

(5) Center and level the receiver more precisely.


(6) Use software to start survey.


3.4 Working with the Tilt Compensation

The auto-IMU need to be calibrated at the first time when users get a new i89 GNSS receiver. After initializing the sensor successfully, the i89 GNSS receiver will record the calibration parameters, and the user do not need to calibrate it manually anymore.


After enable the tilt survey, the i89 IMU can be ready after a few steps walk or a bit movement automatically.


3.4.1 Operation Steps for first IMU initialization


(1) Open Landstar8-> Tap Point Survey-> Tap  to activate tilt measurement.





(2) Hold the pole vertical for a while and shake according to the procedures in the interface to do initialization.





(3) This icon  will appear when the initialization is successful.



(4) Enter the Name and Antenna, then tap , point will be collected and store to Points automatically.

(5) When this icon  appears, the text will show "IMU is invalid. Need to reinitialize" at the middle of interface.



(6) Tap  to close tilt compensation.

3.4.2 Notes of using tilt measurement

1. At the beginning of initialization, the pole height of the instrument should be the same as that antenna height in the software.
2. In the process of tilt measurement, if the controller shows that “Tilt is not available, please measure in alignment” (red), please shake RTK slightly from left to right or back to front until the reminder disappears.
3. The controller will prompt “Tilt is not available, please measure in alignment” when the receiver is stationary over 30 seconds or the pole hit the ground toughly.
4. The pole cannot be shaken when point is collected.
5. Initialization is required:
 - when the RTK is turned on everytime;
 - when IMU module is turned on everytime;
 - when receiver drops at working;
 - when the poleis tilted more than 65 degree;
 - when the receiver is stationary more than 10 minutes;
 - when the RTK rotates toofaston the matching pole (2 rounds per second); . when the pole hit the ground toughly.

3.5 Visual Survey

3.5.1 Survey point mode

The survey point mode means that by taking video survey of the target to be surveyed and solving the survey result in real time, and selecting the point to be surveyed on the photo than you can get the coordinate value of the point.

(1) Finish the IMU initialization, enter the visual survey, do as it prompts;




(2) Choose the **For measurement** mode;




(3) Create a new task, and aim at which point you want to survey, click the button to record the video;



Note: Keeping constant speed when shooting, the length of the video must not be less than 5 seconds, the route of walking can refer to the following picture, walking in a straight line or around the shooting.



(4) Click the icon of End Recording to finish recording and confirm the solved data, and the software will automatically perform data solving;



(5) Select the photo which the point to be surveyed is located, capture the corresponding point location, click [Select], and the latitude, longitude and plane coordinates of the point will be displayed below.



Note: The 2D quality represents the resolution accuracy of the surveyed point. Capturing the same point position on multiple photos will improve the accuracy of the surveyed point, and the 2D value of the point decreases gradually.

(6) Click **[Save]** and enter the point name to save the surveyed points in the point management. After saving successfully, you can click on the point library and goto the point management to view the coordinates you just saved. If additional points are needed, you can continue to select points for solving and saving data.


3.5.2 Modeling mode

Modeling mode means that video surveys can be taken from multiple angles, distances and heights of the target to be surveyed, and then the observed image data can be exported and later imported into the modeling software for modeling.

- (1) The same operation with the point mode, finish the IMU initialization;
- (2) Choose the Modeling mode;



(3) Create a new task, and aim at which building you want to model, click the button to record the video;



Note: When filming, keep a constant speed, the length of the video should not be less than 5 seconds, the route of travel can refer to the example, it is recommended that from different heights, different angles, different distances to survey the target for multi-sided shooting. If the target to be surveyed is single-sided, it is recommended to use straight shooting; if the target to be surveyed is a panorama of building, it is recommended to shoot around, and the camera is recommended to have a certain angle (30°- 45°) with the target to be surveyed when shooting. The schematic diagram is as follows.

(4) Click the end icon to finish recording and make sure that the data has been saved to exit LandStar.

4 Configuring Through a Web Browser

Supported browsers:

- Google Chrome
- Microsoft Internet Explorer version 10, or higher

To connect to the receiver through a web browser:

1. Turn on the Wi-Fi of the receiver.
2. Search the wireless network named as GNSS-XXXXXXX (the SN of your receiver) on your computer, and then establish the connection.
3. After the successful connection between your computer and the receiver, enter the IP address (192.168.1.1) of the receiver into the address bar of the web browser on your computer:

192.168.1.1/pc/login.html

4. The web browser prompts you to enter a login account and password:




The default login account for the receiver is:

- Login Account: admin
- Password: password

Note – Tick **remember me** option, and then the browser will remember the Login Account and Password you entered.

5. Once you login, the webpage appears as follows:



This web page shows the configuration menus on the left of the browser window, and the setting on the right. Each configuration menu contains the related submenus to configure the receiver and monitor receiver performance.

This chapter describes each configuration menu.

To view the webpage in another language, select the corresponding language name from the dropdown list on the upper right corner of the webpage.

Currently, these languages are available:



4.1 Status Menu

This menu provides a quick link to review the receiver's position information, satellites tracked, runtime, current data log status, current outputs, available memory, and more.

4.1.1 Position Submenu

This page shows the relevant position information about the receiver's position solution which including the position, DOP values, satellites used and tracked, and the receiver clock information.

Position

Latitude: 31°9'34.69907381"(North)
 Longitude: 121°10'42.45353990"(East)
 Height: 43.190
 Type: Single

DOP

PDOP: 1.842753
 HDOP: 1.119418
 VDOP: 1.463777
 TDOP: 1.536212

Satellite Used: 17Total

GPS(0):
 GLONASS(4): 7,8,14,24
 BDS(13): 1,2,3,4,5,7,8,10,13,19,26,59,60
 GALILEO(0):
 SBAS(0):
 QZSS(0):

Satellites Tracked: 19Total

GPS(1): 19
 GLONASS(4): 7,8,14,24
 BDS(13): 1,2,3,4,5,7,8,10,13,19,26,59,60
 GALILEO(1): 13
 SBAS(0):
 QZSS(0):

Receiver Clock

GPS Week: 2362
 GPS Seconds: 282647

4.1.2 Activity Submenu

Lists several important items to help you understand how the receiver is being used and its current operating condition. Items include the identities of currently tracked satellites, internal and external storage usage rate, how long the receiver has been operational, state of the internal battery, power source state, files being logged, and data streams being output. With this information, it is easy to tell exactly what functions the receiver is performing.

Satellites Track: 20Total

GPS(1): 19
 GLONASS(4): 7,8,14,24
 BDS(14): 1,2,3,4,5,7,8,10,13,19,22,26,59,60
 GALILEO(1): 13
 SBAS(0):
 QZSS(0):

Activity Status


Current Time: 2025-04-16 06:30:52 (UTC)
 Operation Duration: 00-00-00 00:03:56
 Internal Storage: 12.19% 783MB/6425MB
 External Storage: 0% Disconnected
 External Power: Disconnected
 Battery: 49%

| Record Info | | | | | | |
|---------------|-----------|-----------|---------------|---|--|-----------------------|
| | | | | | | Clear All |
| Recording Num | File Name | Activated | Log Status | Setting Parameter | Switch | Clear Data |
| 1 | record1 | No | Not Recording | Modify Detail | ON OFF | Clear |

| | Type | Description | Output | Connection Status | Modify |
|----|------------------------------|--------------------|-----------|-------------------|--|
| 1 | RTK Client | 211.144.118.5:2102 | --- | Unconnected | Connect Disconnecting Detail |
| 2 | TCP/UDP_Client1/NTRIP Server | 192.168.3.18:9900 | --- | Unconnected | Connect Disconnecting Detail |
| 3 | TCP/UDP_Client2/NTRIP Server | 192.168.3.18:9901 | --- | Unconnected | Connect Disconnecting Detail |
| 4 | TCP/UDP_Client3/NTRIP Server | 192.168.3.18:9902 | --- | Unconnected | Connect Disconnecting Detail |
| 5 | TCP/UDP_Client4/NTRIP Server | 192.168.3.18:9903 | --- | Unconnected | Connect Disconnecting Detail |
| 6 | TCP/UDP_Client5/NTRIP Server | 192.168.3.18:9904 | --- | Unconnected | Connect Disconnecting Detail |
| 7 | TCP/UDP_Client6/NTRIP Server | 192.168.3.18:9905 | --- | Unconnected | Connect Disconnecting Detail |
| 8 | TCP Server/NTRIP Caster1 | 9901 | --- | Closed | Connect Disconnecting Detail |
| 9 | TCP Server/NTRIP Caster2 | 9902 | --- | Closed | Connect Disconnecting Detail |
| 10 | TCP Server/NTRIP Caster3 | 9903 | --- | Closed | Connect Disconnecting Detail |
| 11 | TCP Server/NTRIP Caster4 | 9904 | --- | Closed | Connect Disconnecting Detail |
| 12 | Serial Port | 115200 | --- | --- | Settings |
| 13 | Bluetooth | GNSS-3782275 | GPGGA:5s, | --- | Settings |
| 14 | Radio | 458.050000MHz | --- | --- | Settings |


4.1.3 Google Map Submenu

Tap this submenu to show the location of the receiver on Google map.



4.2 Satellites Menu

Use the Satellites menu to view satellite tracking details and enable/disable GPS, GLONASS, BDS and Galileo constellations. These menus include tabular and graphical displays to provide all required information on satellite tracking status.



4.2.1 Tracking Table Submenu


Provides the status of satellites tracked in general, such as the satellite ID, satellite type, attitude angle, azimuth angle, L1 SNR, L2 SNR, L5 SNR and enable/disable status of each one.

All GPS GLONASS BDS GALILEO SBAS QZSS

| SV | Type | Elevation Angle | Azimuth Angle | L1 SNR | L2 SNR | L5 SNR | B1C SNR | B2A SNR | B2B SNR | Enabled |
|----|---------|-----------------|---------------|--------|--------|--------|---------|---------|---------|---------|
| 4 | GPS | 21 | 75 | 34.360 | 37.280 | 17.950 | 0.000 | 0.000 | 0.000 | No |
| 6 | GPS | 55 | 326 | 29.460 | 45.910 | 29.160 | 0.000 | 0.000 | 0.000 | Yes |
| 9 | GPS | 30 | 111 | 29.260 | 40.490 | 20.910 | 0.000 | 0.000 | 0.000 | Yes |
| 11 | GPS | 34 | 284 | 26.580 | 42.530 | 25.530 | 0.000 | 0.000 | 0.000 | Yes |
| 12 | GPS | 15 | 316 | 33.620 | 34.750 | 0.000 | 0.000 | 0.000 | 0.000 | No |
| 14 | GPS | 22 | 179 | 27.570 | 40.050 | 21.720 | 0.000 | 0.000 | 0.000 | No |
| 17 | GPS | 58 | 100 | 30.070 | 44.920 | 0.000 | 0.000 | 0.000 | 0.000 | Yes |
| 19 | GPS | 73 | 26 | 31.830 | 38.550 | 0.000 | 0.000 | 0.000 | 0.000 | Yes |
| 22 | GPS | 40 | 195 | 26.070 | 31.200 | 0.000 | 0.000 | 0.000 | 0.000 | No |
| 7 | GLONASS | 18 | 34 | 28.430 | 41.250 | 0.000 | 0.000 | 0.000 | 0.000 | Yes |
| 8 | GLONASS | 49 | 84 | 30.330 | 48.240 | 0.000 | 0.000 | 0.000 | 0.000 | Yes |
| 14 | GLONASS | 27 | 292 | 30.560 | 37.430 | 0.000 | 0.000 | 0.000 | 0.000 | Yes |


4.2.2 Tracking Info. Table Submenu

The following figure is an example of satellite track diagram page. Users can determine the satellite types and the corresponding SNR of L-band carriers to be displayed in any combination.




4.2.3 Tracking Skyplot Submenu

The following figure is an example of Skyplot page.




4.2.4 Satellite Activation Submenu

Use this menu to enable or disable satellites.



4.3 Receiver Configuration Menu

Use this menu to configure settings such as the antenna type and height, elevation mask and PDOP setting, the reference station coordinates, receiver resetting and web interface language:




4.3.1 Description



This submenu shows the receiver information and reference station information, including antenna related information, elevation mask angle, reference station work mode and position, etc.

4.3.2 Antenna Configuration Submenu

Use this screen to configure all the items related to the GNSS antenna. You must enter the correct values for all antenna-related fields, because the choices you make affect the accuracy for logged data and broadcast correction data significantly:



4.3.3 Reference Station Settings Submenu

Reference Station Settings x

Reference Station Mode: Auto Rover

Save

Sample for Average

Positioning Constraint: Single Solution Coordinates Fixed Solution Coordinates

Sampling Amount: 300 0%

Start

Stop

Use this screen to configure settings such as the station coordinates and the broadcast station identifiers. You must enter accurate information in these fields, as this data affects the accuracy of logged data files and broadcast correction data significantly:

For Reference Station Mode, there are three modes available:

- a) **Auto Rover:** The receiver will serve as a rover after this mode is enabled, and then receive correction data through the working mode set last time.
- b) **Auto Base:** The receiver will serve as a base after this mode is enabled, and then broadcast correction data based on coordinate inputted by user or obtained through autonomous positioning automatically.

Reference Station Settings x

Reference Station Mode: Auto Base

Base Station Name: []

Base Station ID: []

Reference Latitude: [0] [0] [0.00000000] N S

Reference Longitude: [0] [0] [0.00000000] E W

Reference Height: 0.0000

Save

Sample for Average

Positioning Constraint: Single Solution Coordinates Fixed Solution Coordinates

Sampling Amount: 300 0%

Start Stop

Coordinates transfer threshold value(Meter): 0

Save

Base list

Add Save Delete Modify

| ID | Height | Latitude | | | Longitude | | |
|----|---------|----------|-----|--|-----------|------|--|
| 1 | 48.8410 | [31] | [9] | [34.51635113] <input type="radio"/> S <input checked="" type="radio"/> N | [121] | [10] | [42.51282375] <input checked="" type="radio"/> E <input type="radio"/> W |
| 2 | 44.3753 | [31] | [9] | [34.54676214] <input type="radio"/> S <input checked="" type="radio"/> N | [121] | [10] | [42.59886917] <input checked="" type="radio"/> E <input type="radio"/> W |

c) **Manual Base:** The receiver will serve neither as a base or a rover after this mode is enabled. Users need to configure the receiver manually.

Reference Station Settings ×

Reference Station Mode:

Base Station Name:

Base Station ID:

Reference Latitude: ° ' '' N S

Reference Longitude: ° ' '' E W

Reference Height:

📍 Use Current Position
💾 Save

Sample for Average

Positioning Constraint: Single Solution Coordinates Fixed Solution Coordinates

Sampling Amount:

▶ Start
⏹ Stop

For Reference Latitude and Reference Longitude:

There are mainly three methods to enter the reference coordinates and shown as follows:

- a) **Acquire Current Position:** Click this button to acquire current position obtained through autonomous positioning automatically.
- b) **Manual Input:** Manually input the coordinate of a control point.
- c) **From CORS:** After the receiver logging in CORS, the software can record the coordinate of current position based on fix solution.

For Sample for Average:

Users can determine the positioning limit and sampling amount. The positioning limit falls into two types:

- a) **Single Solution Coordinates:** Collect the coordinates of receiver obtained through autonomous positioning.
- b) **Fixed Solution Coordinates:** Only collect coordinates of receiver with a fixed solution.

After the configuration of positioning limit and sampling amount, click ▶ Start to carryout sampling and averaging → the progress bar will show the progress → the result will be served as the coordinate of current position.

If users need to save the changes, please tap 💾 Save button.

4.3.4 Receiver Reset Submenu

Use this screen to completely or partially reset the receiver:

Receiver Reset x

| | |
|-----------------------------|---|
| Reboot Receiver: | <input checked="" type="checkbox"/> Confirm |
| Return to Factory Defaults: | <input checked="" type="checkbox"/> Confirm |
| Clear Satellite Data: | <input checked="" type="checkbox"/> Confirm |
| Turn Off Receiver: | <input checked="" type="checkbox"/> Confirm |


4.3.5 Languages Submenu

Use this screen to select the web interface language:

Language x


| | | |
|---|-----------|---|
|  | English | <input checked="" type="checkbox"/> Confirm |
| | 中文 | |
| | English | |
| | Русский | |
| | Español | |
| | Português | |
| | Français | |
| | 日本語 | |

4.3.6 User Management Submenu



4.4 Data Recording Menu

Use the Data Logging menu to set up the receiver to log static GNSS data and to view the logging settings. You can configure settings such as observable rate, recording rate, continuous logging limit, and whether to auto delete old files when memory is low. This menu also provides the controls for the FTP push feature:



4.4.1 Log Settings Submenu

Here shows the data logging status, including internal and external storage usage and data logging status of each session. Also, users can configure the data logging settings for each session, including recording name, store location, storage limit, store formats, start time, etc.

Log Settings x

| Store Info | | | |
|------------|------------------|---------------|-------------------|
| | Position | Total Storage | Storage Available |
| 1 | Internal Storage | 6425MB | 2701MB |
| 2 | External Storage | 0MB | 0MB |

Attention: Total assigned storage size should be less than 6GB. It will stop recording when the storage is full.

| Record Info | | | | | | |
|------------------|-----------|-----------|---------------|---|---|-----------------------|
| Recording Number | File Name | Activated | Log Status | Setting Parameter | Switch | Clear Data |
| 1 | record1 | No | Not Recording | Modify Detail | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF | Clear |

To edit the settings of each session, click the **Modify** button to the right of the required session, and then the Recording Edit screen appears:

Recording Edit

Auto Record: Yes No

Sample Interval: 1Hz

Elevation Mask: 10 (°)

Duration Time: 60 (Minute)

Site Name: CHCNAV

Antenna Height: 0.0000

Measure Way: Antenna Phase Ce

Storage Format: HCN

RINEX Version: 3.0x

Compress Rinex Data: Yes No

[Advanced](#)

[Save](#)
[Back](#)

Click advanced to see more settings.

Recording Edit

Auto Record: Yes No

Sample Interval: 1Hz

Elevation Mask: 10 (°)

Duration Time: 60 (Minute)

Site Name: CHCNAV

Start Date: Yes No

Apply Time: Yes No

Integral Point Store: Yes No

Circulating Memory: Yes No

the data overwritten first file after storage space is full

Single Observations: Yes No

Turn on to record a single observation. Turn off to record repeated observations.

Antenna Height: 0.0000

Measure Way: Antenna Phase Ce

Storage Format: HCN

RINEX Version: 3.0x

Compress Rinex Data: Yes No

[Advanced](#)

Store Location: Internal Storage

Assigned Storage: 6000 (MB)

Observer: CHC



Observe Agency: CHC

FTP Push: Close 1.ftp server 1 2.ftp server 2 3.ftp server 3

[Save](#)
[Back](#)

In this screen, you can configure all the data logging parameters, and determine whether the recording files will be affected by the FTP Push. The parameters are mainly as follows:

- **Auto Record:** on or off.
- **Sample Interval:** Select the observable rate from the dropdown list.
- **Elevation Mask:** Enter the elevation mask.
- **Duration Time:** Set the duration of data logging.
- **Site Name:** Enter the name of the site.
- **Antenna Height:** the measured height value.
- **Measure way:** Antenna Phase Center, Vertical Height, Slant Height
- **Storage Format:** Select the format of the data store.
- **RINEX Version:** OFF, 3.02, 2.11
- **Start Date:** Select Yes or No option to determine whether to auto record start date.
- **Apply Time:** Select Yes or No option to determine whether to auto record apply time.
- **Integral Point Store:** Select Yes or No option to determine whether to allow receiver to save data every hour.
- **Circulating Memory:** Select Yes or No option to determine whether to auto delete old files if the storage space is full.
- **Repeat Observations:** Select Yes or No option to determine whether to turn on to record a single observation.
- **Store Location:** Internal Storage, External Storage.
- **Assigned Storage:** The assigned memory size of current thread(for example, Record 1) is 10000MB
- **Observer:** Enter the name of observer.
- **Observer Agency:** Enter the name of observer agency.
- **FTP Push:** Decide whether to push the stored files to the FTP server of your choice.

Tap  button to save the settings and back to the Log,Also, users can click  to abandon the changed settings and back to Log Settings screen.

Note – To modify data logging parameters, make sure the data logging session is switched off.

To switch on or off ANY data logging session, tap the ON or OFF button on the right of the required session.

To delete the recorded files of ANY data logging session, tap the Clear button on the right of the required session.

To delete the recorded files of ALL data logging sessions, tap the Clear ALL Accounts button.

4.4.2 FTP Push Settings Submenu

Use this screen to configure the receiver to push stored files to the FTP server of your choice. Only files that are configured to use FTP push are transmitted.

| Record Info | | | | |
|-------------|--------------|------------------|--------------------|------------------------|
| Server ID | Server IP | Remote Directory | Server Description | Modify |
| 1 | 192.168.3.72 | /repo/first | ftp server 1 | Modify |
| 2 | 192.168.3.72 | /repo/second | ftp server 2 | Modify |
| 3 | 192.168.3.72 | /repo/third | ftp server 3 | Modify |

Tap **Modify** button on the right of the required FTP server and the FTP Push Settings screen appears:

FTP Push Settings ✕

Server IP:

Port:

Remote Directory:

Local directory: ▼

Server Description:

User Name:

Password:


✔ Save
✕ Back

4.4.3 FTP Push Log Submenu

Shows the related information about the recorded files that be pushed. And users can tap **Clear Ftp Send Log** button in the upper right corner to clear the log of FTP Push operations.

| Record Info | | | | |
|------------------------------------|-----------|-----------|-----------|------------------------|
| Server ID | Push File | File Size | Push Time | Push Successful Or Not |
| Clear FTP Push Log | | | | |

4.5 IO Settings Menu



Use the IO Settings menu to set up all receiver outputs and inputs. The receiver can output CMR, RTCM, Raw data, Ephemeris data, GPGGA, GPGSV, on TCP/IP, UDP, serial port, or Bluetooth ports.

4.5.1 IO Settings Submenu

The following figure shows an example of the screen that appears when you select this submenu.

| I/O Settings < | | | | | | | |
|----------------|-------------------------------|-------------------|-----------|-------------------|----------|---------------|--------|
| | Type | Description | Output | Connection Status | Modify | | |
| 1 | RTK Client | | --- | Unconnected | Connect | Disconnecting | Detail |
| 2 | TCP/UDP_Client1/NTRIP Server1 | 192.168.3.18:9900 | --- | Unconnected | Connect | Disconnecting | Detail |
| 3 | TCP/UDP_Client2/NTRIP Server2 | 192.168.3.18:9901 | --- | Unconnected | Connect | Disconnecting | Detail |
| 4 | TCP/UDP_Client3/NTRIP Server3 | 192.168.3.18:9902 | --- | Unconnected | Connect | Disconnecting | Detail |
| 5 | TCP/UDP_Client4/NTRIP Server4 | 192.168.3.18:9903 | --- | Unconnected | Connect | Disconnecting | Detail |
| 6 | TCP/UDP_Client5/NTRIP Server5 | 192.168.3.18:9904 | --- | Unconnected | Connect | Disconnecting | Detail |
| 7 | TCP/UDP_Client6/NTRIP Server6 | 192.168.3.18:9905 | --- | Unconnected | Connect | Disconnecting | Detail |
| 8 | TCP Server/NTRIP Caster1 | 9901 | --- | Closed | Connect | Disconnecting | Detail |
| 9 | TCP Server/NTRIP Caster2 | 9902 | --- | Closed | Connect | Disconnecting | Detail |
| 10 | TCP Server/NTRIP Caster3 | 9903 | --- | Closed | Connect | Disconnecting | Detail |
| 11 | TCP Server/NTRIP Caster4 | 9904 | --- | Closed | Connect | Disconnecting | Detail |
| 12 | Serial Port | 115200 | --- | --- | Settings | | |
| 13 | Bluetooth | GNSS-3 | GPGGA.5s, | --- | Settings | | |
| 14 | Radio | 456.050000MHz | --- | --- | Settings | | |


In this submenu, users can configure 6 types of input and output settings.

1. RTK Client

After configuring the settings of RTK client, users can log on CORS or APIS. Tap the **Connect** button to the right → the *IO Settings* screen will appear → choose one of the connection protocols among the NTRIP, APIS_BASE and APIS_ROVER → configure the related parameters


➤ click to logon CORS or APIS.

➤ Connection Protocol: NTRIP




The screenshot shows the 'RTK Client' dialog box with the following fields: 'Connection Protocol' set to 'NTRIP', 'Server IP' set to '211.144.118.5', 'Port' set to '2102', 'Mount Point' with a dropdown arrow and a green checkmark and the text 'Get', 'User Name' and 'Password' as empty text boxes. At the bottom are 'Confirm' and 'Back' buttons.

➤ Connection Protocol: APIS_BASE




The screenshot shows the 'RTK Client' dialog box with the following fields: 'Connection Protocol' set to 'APIS_BASE', 'Server IP' set to 'apis-af.' followed by a blurred area, 'Port' set to '9901', and 'Differential Data' set to 'OFF'. At the bottom are 'Confirm' and 'Back' buttons.

➤ Connection Protocol: APIS_ROVER




The screenshot shows the 'RTK Client' dialog box with the following fields: 'Connection Protocol' set to 'APIS_ROVER', 'Server IP' set to '210.14.66.58', 'Port' set to '9902', and 'Base ID' with a dropdown arrow. At the bottom are 'Confirm' and 'Back' buttons.


➤ Connection Protocol: TCP



1. TCP/UDP_Client/NTRIP Server

Tap the **Connect** button on the right of required TCP/UDP Client → the *IO Settings* screen will appear → select the connection protocol from TCP, UDP, NTRIP1.0 and NTRIP2.0 → enter the IP and Port of the target server → configure messages that you want to output to the target server → click  to save and complete the connection.

➤ Connection Protocol: TCP



➤ Connection Protocol: UDP

TCP/UDP Client

Auto connect: Connection Protocol: TCP

Server IP: 192.168.3.18

Port: 9901

Differential Data: OFF

Raw Data: OFF

HCPPP Data: OFF

GPGGA: OFF

GPGSV: OFF

GPRMC: OFF

GPZDA: OFF

GPGST: OFF

GPVTG: OFF

GPGSA: OFF

GPPOS: OFF

Retransmit: RTK OFF

➤ Connection Protocol: NTRIP1.0

TCP/UDP Client

Auto connect: Connection Protocol: TCP

Server IP: 192.168.3.18

Port: 9901

Differential Data: OFF

Raw Data: OFF

HCPPP Data: OFF

GPGGA: OFF

GPGSV: OFF

GPRMC: OFF

GPZDA: OFF

GPGST: OFF


GPVTG: OFF

GPGSA: OFF

GPPOS: OFF

Retransmit: RTK OFF


➤ Connection Protocol: NTRIP2.0



2. TCP Server/NTRIP Caster

Tap the **Connect** button to the right of required TCP Server/NTRIP Caster → the **IO Settings** screen will appear → select one of the connection protocols between NTRIP and TCP → configure the other related parameters → click **Confirm** to save the settings and open the server.

➤ Connection Protocol: TCP



➤ Connection Protocol: NTRIP

TCP/UDP Client

Auto connect: Connection Protocol: TCP

Server IP: 192.168.3.18

Port: 9901

Differential Data: OFF

Raw Data: OFF

HCPPP Data: OFF

GPGGA: OFF

GPGSV: OFF

GPRMC: OFF

GPZDA: OFF

GPGST: OFF

GPVTG: OFF

GPGSA: OFF

GPPOS: OFF

Retransmit: RTK OFF

3. Serial Port

Tap the **Settings** button on the right of Serial Port → the *Serial Port Setup* screen will appear → select Baud Rate used to transmit data → configure the messages that you want to output through the serial port → click to save the settings and start to transmit.

Serial Port Setup

Baud Rate: 115200

Differential Data: OFF

HCPPP Data: OFF

GPGGA: OFF

GPGSV: OFF

GPRMC: OFF

GPZDA: OFF

GPGST: OFF

GPVTG: OFF


GPGSA: OFF


GPPOS: OFF

Retransmit: RTK OFF

Raw Data: OFF


4. Bluetooth


Tap the **Settings** button to the right of Bluetooth → the *Bluetooth Set* screen will appear → configure the messages that you want to transmit through Bluetooth → click  to save the settings and start to transmit.



5. Radio


Tap the **Settings** button to the right of Radio → the *Radio Settings* screen will appear → select the format of differential data that you want to transmit through radio from the dropdown list

➤ click  to save the settings and start to transmit.




4.6 Network Setting Menu

Use this menu to view network information, configure the receiver’s mobile network, set email alert for specific situation, configure HTTP or HTTPS port, and the username and password of internal FTP site:



4.6.1 Email Alarm Submenu

Use this submenu to choose which situation of receiver will be alerted and input the email address.



4.6.2 HTTP Submenu

Use this submenu to configure HTTP port.

HTTP ×

HTTP Port: Save

4.6.3 HTTPS Submenu

Use this submenu to configure HTTPS port.

HTTPS ×

HTTPS


Enable HTTPS: Yes No

HTTPS Port:

Save

4.7 Module Setting Menu

Use this menu to check module information, configure WiFi, bluetooth, radio related settings, and turn on/off static voice of buzzer:




4.7.1 Description Submenu

Use this submenu to check the information of WiFi module, bluetooth module and radio module.



4.7.2 WiFi Submenu

Use this submenu to turn on/off WiFi function and modify password.



4.7.3 Bluetooth Settings Submenu

Use this submenu to turn on/off bluetooth function and modify PIN number.

Bluetooth Settings
×

Bluetooth Settings

Local Name: GNSS-9999516

MAC Address: EC:A7:AD:AD:A8:10

PIN:

Save

4.7.4 Radio Settings Submenu

Use this submenu to turn on/off radio function and configure radio parameters.

Radio Settings
×

Radio Settings

Radio Status: OFF ON OFF

Auto Start: Yes No

Radio Protocol: ▼

Channel Bandwidth : ▼ (kHz)

OTA Baud Rate: ▼

Radio Power: ▼

Radio Frequency: (410MHz--470MHz)

FEC:

Save

4.7.5 IMU Settings Submenu


Use this submenu to turn on/off IMU function.

IMU Setting ×

IMU Setting

IMU Status: ON OFF


Antenna Height:

 Save

IMU Init Status:
Lat:
Lon:
Alt:
Vertical dip:
direction of dip:

4.8 Firmware Menu

Use this menu to check the current firmware information, download the system log, update the receiver firmware, download or update the configuration file and register the receiver, and more:



4.8.1 Firmware Info Submenu

Use this submenu to check the current firmware information. The following figure shows an example of the firmware information.




4.8.2 Hardware Version Submenu

Use this submenu to check the hardware information, including mainboard version and core board version:




4.8.3 Config File Submenu

Use this submenu to update Configuration File.




4.8.4 System Log Download Submenu

Use this submenu to download the system log of the receiver.




4.8.5 User Log Submenu

Use this submenu to download the user log. Tap Download to download current user log; Tick items that you want to see on the user log and tap confirm button to confirm selected user log.



4.8.6 Firmware Update Submenu

Use this submenu to load new firmware to the receiver across the network. Tap the **Browse** button to locate the upgrade file → tap **Confirm** button to confirm the selected upgrading file and start upgrading.




NOTES:

(1)It may take about 3 or 4 minutes to complete the firmware upgrading. Do not touch the power button or unplug the power until the upgrading process finishes, or damage will be caused to the receiver.

(2)The receiver will restart after the firmware upgrading is done, so users need to, reconnect the receiver with your computer via Wi -Fi, and then log-in the receiver through a web browser to continue the configuration.


4.8.7 GNSS Board Upgrade Submenu

Use this submenu to upgrade GNSS Board. Use this submenu to load new board to the receiver across the network. Tap the **Browse** button to locate the upgrade file → tap **Confirm** button to confirm the selected upgrading file and start upgrading.



4.8.8 Radio Upgrade Submenu

Use this submenu to browse upgrade file and upgrade radio. Use this submenu to load new radio to the receiver across the network. Tap the **Browse** button to locate the upgrade file → tap **Confirm** button to confirm the selected upgrading file and start upgrading.



4.8.9 Upgrade Online Submenu

Use this submenu to input Server Address and upgrade online.



4.8.10 GNSS Registration Submenu

Use this submenu to register the receiver. Paste or enter the registration code to the Registration Code field → tap **Registration** button to complete the registration.



The screenshot shows a mobile application interface for GNSS registration. At the top, there is a blue header bar with the text "GNSS Registration" and a close icon (an 'x'). Below the header, there are three input fields, each with a label on the left and a text box on the right. The first field is labeled "Serial Number:" and contains the value "3411955". The second field is labeled "Registration Limit:" and contains the date "2022-4-24". The third field is labeled "Registration Code:" and contains the alphanumeric string "XpHTmdQ4mSo". Below these fields, there is a green button with a white key icon and the text "Registration".

| | |
|---------------------|-------------|
| Serial Number: | 3411955 |
| Registration Limit: | 2022-4-24 |
| Registration Code: | XpHTmdQ4mSo |





CHC Navigation

Building C, 577 Songying Road, Qingpu, District,
201703 Shanghai, China

Tel: +86 21 542 60 273 | Fax: +86 21 649 50 963

Email: sales@chcnav.com | support@chcnav.com

Skype: chc_support

Website: www.chcnav.com

This document is intended for general information purposes only. It

does not consider the reader's specific circumstances and

environmental constraints of use of GNSS.

Make your work more efficient