

PREVIDIA



FIRE DETECTION AND EXTINGUISHANT SYSTEMS



GameOver

GUIDE FOR INTEGRATION
WITH SUPERVISION SYSTEMS

inim
ELECTRONICS

Obligations of the User

The User agrees to:

- keep the contents of this document in strictest confidence and not to disclose or make available any part of it, or copies thereof to third parties, without the prior written permission of INIM Electronics s.r.l.
- use the information contained in this document solely for the purpose of integrating management of the Praesidia control panel into the User's own supervisory software and not for any other purpose whatsoever. The information should be used in accordance with the regulations in force in the country of installation. Any use of the same that can, directly and/or indirectly, lead to system behaviour that differs from the applicable norms or the required security standards is to be attributed solely to the User's responsibility.

Limitations of Liability

INIM Electronics s.r.l. shall not be held responsible for any errors or omissions found in the information or for any deviations from the standard protocols. INIM Electronics s.r.l. reserves the right to make changes and/or updates to the information contained in the protocols at any time without prior notice.

The User is fully responsible for any damage that may arise, directly and/or indirectly, as a result of the incorrect use of the information contained in this document, thus INIM Electronics s.r.l. is exonerated from any liability attached to it.

In no case shall INIM Electronics s.r.l., its suppliers and licensors be liable for any consequential, incidental, direct, indirect or special damage of any nature, whether foreseeable or not, arising from the use of the information contained in this document.

Where these limitations of liability cannot be applied according to the law in force in the jurisdiction of the User, they must, however, be deemed valid and enforceable to the fullest extent permitted by the same law.

Copyright

The information contained in this document is the sole property of INIM Electronics s.r.l.

No part may be copied without written authorization from INIM Electronics s.r.l.

All rights reserved.

Table of contents

Obligations of the User.....	2
Limitations of Liability.....	2
Copyright.....	2
Table of contents.....	3
Chapter 1 General information	5
1.1 Manufacturer's details	5
1.2 About this manual	5
Chapter 2 Connectible external systems.....	6
Chapter 3 Building Management System.....	7
3.1 Modbus RTU and Modbus over TCP/IP	7
3.2 BACnet	17
3.3 SmartLook Software	20
Chapter 4 Pager systems	21
Chapter 5 Video verification.....	22
Chapter 6 Voice Evac-systems.....	24
6.1 Voice Evac configuration.....	24

General information

1.1 Manufacturer's details

Manufacturer: INIM ELECTRONICS s.r.l

Production plant: Centobuchi, via Dei Lavoratori 10

Comune: 63076, Monteprandone (AP) - Italy

Tel.: +39 0735 705007

Fax: +39 0735 704912

E-mail: info@inim.biz

Web: www.inim.biz

The persons authorized by the manufacturer to repair or replace the parts of this system, hold authorization to work on INIM Electronics brand devices only.

1.2 About this manual

Manual code: DCMBINEOPREVIDIA

Version: 1.10

This manual provides the installer with the guidelines relating to the integration of Previdia control panels with external supervision systems.

1.2.1 Graphic conventions

Following are the graphic conventions used in this manual.

Conventions	Example	Description
Text in italics	Refer to <i>paragraph 1.2.1 Graphic conventions</i>	Indicates the title of a chapter, section, paragraph, table or figure in this manual or other published reference
[Uppercase letter] or [number]	[A] or [1]	Reference relating to a part of the system or video object.


Note:

The notes contain important information relating to the text.

Connectible external systems

Previdia series control panels have been especially developed and designed for connection to various systems which are external to the fire detection system itself, such as:

- **BMS (Building Management System):** supervision systems, usually comprising software installed on a PC platform, capable of supervising and managing the system through graphic maps, function keys, etc. These systems constitute an easy-to-use interface for end users.
- **Pager:** systems comprising a PABX capable of receiving text messages from other systems (in our case from fire-detection control panels) and forwarding them to remote devices such as pagers or displays of cordless telephones.
- **Video surveillance with IP cameras with Onvif protocol:** cameras installed in the same Ethernet network can be interconnected with the fire-detection control panel in order to provide images captured in ambients where dangerous situations have been detected (in the case of PTZ by positioning the camera at the correct angle). The images, visible on the control-panel console or from remote locations (via e-mail or web browser), provide a valid verification tool that allows the user to establish the seriousness or irrelevance of fire signalling.
- **Voice Evac:** voice evacuation systems comprise one or more control units (controller, amplifiers, power supplies) and a series of sound diffusion lines. These systems have the task of warning occupants of the necessity to evacuate the building and are more effective than sounders, as they are capable of providing detailed information regarding the fire. The interconnection of these systems and the fire detection system allows the activation of accurate voice messages relating specifically to the various zones in the building.



Building Management System

The connection of Previdia control panels with supervision systems (BMS, Building Management Systems) allows users to supervise and interact with their systems.

For this purpose Previdia control panels manage some of the most widely used communication protocols available on the market:

- **Modbus RTU**: protocol based on RS485 standard (for Previdia Max control panels only, available on the RS485-BMS port of the FPMCPU module)
- **Modbus over TCP/IP**: Modbus protocol based on TCP/IP standard, implemented on the Ethernet connection of the control panel
- **BACnet**: protocol based on TCP/IP standard (for Previdia Max control panels only, implemented on the Ethernet port of the IFMLAN module). This protocol is subject to licencing.
- **SmartLook interface**: protocol property of Inim Electronics used by SmartLook software (implemented on the Ethernet port, RS232 and USB located on the FPMCPU module for Previdia Max control panels and on the Ethernet and USB ports located on the Previdia Compact control panels main board)

Following are the specifications of each of the previously-mentioned protocols.

3.1 Modbus RTU and Modbus over TCP/IP

A BMS software framework connected to a Previdia control panel via Modbus protocol, capable of supervising and managing the control panel itself and all the control panels interconnected with it through the Hornet+ network (for further details regarding Hornet+ networking refer to the Praesidia networking guide).

For this reason it is necessary to configure a Modbus address for each control panel to be reached.

This setting must be done through the configuration software Previdia/Studio.

1. Open the Previdia/Studio solution that represents the system.
2. Select, from the control panels configured in the network, the control panel the BMS is connected to (via TCP/IP or RS485).
3. Access to the control panel CPU programming section:

for Previdia Max: Click first on the FPMCPU module icon and then on the display.

for Previdia Compact: Click first on the display.

for PREVIDIA-C-REP: You access directly to the section of interests.

4. The section shows the **Modbus address** button. Click on the button.

For each of the control panels connected in the Hornet+ network, the software will allow you to set on the Modbus the address to which to respond. If you select the "No Address" setting the control panel in question will not respond to Modbus commands (protocol disabled).



Note:

Modbus RTU and Modbus TCP/IP protocols are available and are not subject to an activation licence.

The Previdia control panel carries out the following commands via the Modbus:

- READ REGISTER
- SET COIL

3.1.1 Register Mapping

The “READ REGISTER” command serves to interrogate the control panel in relation to its status and the status of its connected components in accordance with the register mapping as shown below:

Registers for Previdia Max control panels (use Modbus 0x03 command to read)

Address	Name	High byte										Low byte										
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Bit 7	Bit 6	Bit 5	Bit 4	
20	Status of telephone communicator 1	Supervision failed		Call queue full					SMS fault			SMS OK			Fault call failed		Fault call OK					
21	Status of telephone communicator 2																					
25	Fire extinguishment module 1																					
48																				
49	Extinction module 1 terminals faults																					
72	Extinction module 24 terminals faults	...																				
100	Zone 1 Zone 2																					
599	Zone 999 Zone 1000																					
600	Group 1 Group 2																					
719	Group 239 Group 240																					

Registers for Previdia Max control panels (use Modbus 0x03 command to read)

Address	Name	High byte									Low byte												
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0						
868	IFM16IO 1 Module channels 1, 2	Do not use	Do not use	IFM16IO 1 Module, channel 2									IFM16IO 1 Module, channel 1										
		Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use						
899	IFM16IO 4 Module channels 15, 16	Do not use	Do not use	IFM16IO 4 Module, channel 16									IFM16IO 4 Module, channel 15										
		Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use						
900	IFM4IO 1 Module channels 1, 2	Do not use	Do not use	Output status	Disabled	IFM4IO 1 Module, channel 2									IFM4IO 1 Module, channel 1								
		Do not use	Do not use	Output status	Disabled	Fault	Early warning	Pre-alarm	Alarm	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use					
931	IFM4IO 16 Module channels 3, 4	Do not use	Do not use	IFM4IO 16 Module, channel 4									IFM4IO 16 Module, channel 3										
		Do not use	Do not use	Output status	Disabled	Fault	Early warning	Pre-alarm	Alarm	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use					
932	Module IFM4R 1 channels 1, 2	Do not use	Do not use	IFM4R 1 Module , channel 2									IFM4R 1 Module , channel 1										
		Do not use	Do not use	Output status	Disabled	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use					
963	Module IFM4R 16 channels 3, 4	Do not use	Do not use	IFM4R 16 Module , channel 4									IFM4R 16 Module , channel 3										
		Do not use	Do not use	Output status	Disabled	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use					
964	IFM24160 1 output 1 output 2	Do not use	Do not use	IFM24160 1 Module, output 2									IFM24160 1 Module, output 1										
		Do not use	Do not use	Output status	Disabled	Fault	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use					
965	IFM24160 1 Output 3 IFM24160 2 Output 1	Do not use	Do not use	IFM24160 2 Module, output 1									IFM24160 1 Module, output 3										
		Do not use	Do not use	Output status	Disabled	Fault	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use					
966	IFM24160 2 Module output 2 output 3	Do not use	Do not use	IFM24160 2 Module, output 3									IFM24160 2 Module, output 2										
		Do not use	Do not use	Output status	Disabled	Fault	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use					
967	IFM24160 3 Module output 1 output 2	Do not use	Do not use	IFM24160 3 Module, output 2									IFM24160 3 Module, output 1										
		Do not use	Do not use	Output status	Disabled	Fault	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use					
968	IFM24160 3 Output 3 IFM24160 4 Output 1	Do not use	Do not use	IFM24160 4 Module, output 1									IFM24160 3 Module, output 3										
		Do not use	Do not use	Output status	Disabled	Fault	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use					
969	IFM24160 4 output 2 output 3	Do not use	Do not use	IFM24160 4 Module, output 3									IFM24160 4 Module, output 2										
		Do not use	Do not use	Output status	Disabled	Fault	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use					

Registers for Previdia Max control panels (use Modbus 0x03 command to read)

Address	Name	High byte										Low byte									
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0				
1001	Loop 1 Address 1 Address 2	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Loop1 address 2										Loop1 address 1	
	Output status	Output status	Output status	Output status	Output status	Output status	Output status	Output status	Output status	Output status
1120	Loop 1 Address 239 Address 240	Loop1 address 240										Loop1 address 239									
	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
1121	Loop 2 Address 1 Address 2	Loop 2 address 2										Loop 2 address 1									
	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
1240	Loop 2 Address 239 Address 240	Loop 2 address 240										Loop 2 address 239									
	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
1241	Loop 3 Address 1 Address 2	Loop 3 address 2										Loop 3 address 1									
	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
1360	Loop 3 Address 239 Address 240	Loop 3 address 240										Loop 3 address 239									
	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
1361	Loop 4 Address 1 Address 2	Loop 4 address 2										Loop 4 address 1									
	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
1480	Loop 4 Address 239 Address 240	Loop 4 address 240										Loop 4 address 239									
	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
1481	Loop 5 Address 1 Address 2	Loop 5 address 2										Loop 5 address 1									
	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
1600	Loop 5 Address 239 Address 240	Loop 5 address 240										Loop 5 address 239									
	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
1601	Loop 6 Address 1 Address 2	Loop 6 address 2										Loop 6 address 1									
	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled

Registers for Previdia Max control panels (use Modbus 0x03 command to read)

Address	Name	High byte									Low byte								
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0		
1720	Loop 6 Address 239 Address 240	Loop 6 address 240									Loop 6 address 239								
		Do not use	Do not use	Output status	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Fault	Early warning	Pre-alarm	Alarm					
1721	Loop 7 Address 1 Address 2	Loop 7 address 2									Loop 7 address 1								
		Do not use	Do not use	Output status	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Fault	Early warning	Pre-alarm	Alarm					
...	...	Loop 7 address 240									Loop 7 address 239								
		Do not use	Do not use	Output status	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Fault	Early warning	Pre-alarm	Alarm					
1840	Loop 7 Address 239 Address 240	Loop 8 address 2									Loop 8 address 1								
		Do not use	Do not use	Output status	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Fault	Early warning	Pre-alarm	Alarm					
1841	Loop 8 Address 1 Address 2	Loop 8 address 240									Loop 8 address 239								
		Do not use	Do not use	Output status	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Fault	Early warning	Pre-alarm	Alarm					
1960	Loop 8 Address 239 Address 240	Loop 9 address 2									Loop 9 address 1								
		Do not use	Do not use	Output status	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Fault	Early warning	Pre-alarm	Alarm					
1961	Loop 9 Address 1 Address 2	Loop 9 address 240									Loop 9 address 239								
		Do not use	Do not use	Output status	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Fault	Early warning	Pre-alarm	Alarm					
2080	Loop 9 Address 239 Address 240	Loop 10 address 2									Loop 10 address 1								
		Do not use	Do not use	Output status	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Fault	Early warning	Pre-alarm	Alarm					
2081	Loop 10 Address 1 Address 2	Loop 10 address 240									Loop 10 address 239								
		Do not use	Do not use	Output status	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Fault	Early warning	Pre-alarm	Alarm					
...	...	Loop 10 address 240									Loop 10 address 239								
		Do not use	Do not use	Output status	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Fault	Early warning	Pre-alarm	Alarm					
2200	Loop 10 Address 239 Address 240	Loop 11 address 2									Loop 11 address 1								
		Do not use	Do not use	Output status	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Fault	Early warning	Pre-alarm	Alarm					
2201	Loop 11 Address 1 Address 2	Loop 11 address 2									Loop 11 address 1								
		Do not use	Do not use	Output status	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Fault	Early warning	Pre-alarm	Alarm					

Registers for Previdia Max control panels (use Modbus 0x03 command to read)

Address	Name	High byte										Low byte									
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0				
2320	Loop 11 Address 239 Address 240	Loop 11 address 240										Loop 11 address 239									
2321	Loop 12 Address 1 Address 2	Loop 12 address 2										Loop 12 address 1									
2440	...	Loop 12 address 240										Loop 12 address 239									
2441	...	Loop 13 address 240										Loop 13 address 239									
2560	Loop 13 Address 239 Address 240	Loop 13 address 240										Loop 13 address 239									
2561	Loop 14 Address 1 Address 2	Loop 14 address 240										Loop 14 address 1									
2680	...	Loop 14 address 240										Loop 14 address 239									
2681	Loop 15 Address 1 Address 2	Loop 15 address 240										Loop 15 address 1									
2800	...	Loop 15 address 240										Loop 15 address 239									
2801	Loop 16 Address 1 Address 2	Loop 16 address 240										Loop 16 address 1									
2920	...	Loop 16 address 240										Loop 16 address 239									

Registers for Previdia Compact control panels (use Modbus 0x03 command to read)

Address	Name	High byte									Low byte								
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0		
0	Control panel details Status 1													Investigate	Mute	Night mode			
1	Control panel details Status 2																		
2	Fault on boards 1																Fault board PREVIDIA-C-D/A/I		
6	Fault on boards 2																		
8	Active Timers 1	Timer 16	Timer 32	Timer 16	Timer 15	Timer 31	Timer 15												
9	Active Timers 2	Timer 32	Timer 16	Timer 32	Timer 14	Timer 30	Timer 30	Timer 14											
10	Disabled Timers 1				Timer 31	Timer 15	Timer 15												
11	Disabled Timers 2				Timer 30	Timer 14	Timer 12	Timer 28	Timer 12										
12	Loop fault																		
13	Loop disabled																		
20	Status of telephone communicator 1	Supervision failed		Call queue full	SMS fault	SMS OK	Fault call failed	Fault call OK	Alarm call failed	Alarm call OK	Fault call ongoing	Alarm call ongoing							
21	Status of telephone communicator 2																		
25	Fire extinguishment module																		
49	Faults on electrovalve terminal (I/O 4)																		

Registers for Previdia Compact control panels (use Modbus 0x03 command to read)

Address	Name	High byte										Low byte											
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2
100	Zone 1 Zone 2	Zone 2										Zone 1											
		Do not use	Do not use	Do not use	Do not use	Do not use	Test	Test	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	
599	Zone 999 Zone 1000	Zone 1000										Group 2											
		Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Disabled	Disabled	Disabled	Disabled	Fault	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Alarm
600	Group 1 Group 2	Group 240										Group 1											
		Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	
719	Group 239 Group 240	Channel I/O 2										Group 1											
		Do not use	Do not use	Do not use	Do not use	Do not use	Output status	Disabled	Disabled	Disabled	Disabled	Fault	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Alarm				
900	Channels I/O 1, I/O 2	Channel I/O 4										Group 1											
		Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	
901	Channels I/O 3, I/O 4	Relay output										Group 1											
		Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	
932	Relay output	Loop1 address 2										Group 1											
		Do not use	Do not use	Do not use	Do not use	Do not use	Output status	Disabled	Disabled	Disabled	Disabled	Fault	Fault	Early warning	Pre-alarm	Pre-alarm	Pre-alarm	Pre-alarm	Alarm				
1001	Loop 1 Address 1 Address 2	Loop1 address 240										Group 1											
		Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	
1120	Loop 1 Address 239 Address 240	Loop 2 address 2										Group 1											
		Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	
1121	Loop 2 Address 1 Address 2	Loop 2 address 240										Group 1											
		Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	
1240	Loop 2 Address 239 Address 240	Loop 2 address 240										Group 1											
		Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	Do not use	

3.1.2 COIL Mapping

The "SET COIL" allows you to carry out operations on the addressed control panel. To activate a COIL command relative to the implementation of an operation it is necessary to set it to "ON".

Following is the map of COIL registers:

COIL (use the Modbus 0x05 command)

Address	Name for Previdia Max
0	Activate "Action 1"
...	...
99	Activate "Action 100"
100	Enable/Disable Zone 1
...	...
1099	Enable/Disable Zone 1000
1100	Activate/Deactivate I/O 1 of IFM4IO 1 module
...	...
1163	Activate/Deactivate I/O 4 of IFM4IO 16 module
1200	Activate/Deactivate relay 1 of the IFM4R 1 module
...	...
1263	Activate/Deactivate relay 4 of the IFM4R 16 module
1300	Activate/Deactivate output 1 of the IFM24160 1 module
...	...
1311	Enable/Disable* output 3 of the IFM24160 4 module

Address	Name for Previdia Max
1400	Activate/Deactivate loop1 address 1 device's output
...	...
5239	Activate/Deactivate loop16 address 240 device's output
5400	Enable/Disable I/O 1 of IFM4IIO 1 module
...	...
5463	Enable/Disable I/O 4 of IFM4IO 16 module
5500	Enable/Disable relay 1 of the IFM4R 1 module
...	...
5563	Enable/Disable relay 4 of the IFM4R 16 module
5600	Enable/Disable output 1 of the IFM24160 1 module
...	...
5611	Enable/Disable output 3 of the IFM24160 4 module
5700	Enable/Disable address 1 of loop 1
...	...
9540	Enable/Disable address 240 of loop 16

COIL (use the Modbus 0x05 command)

Address	Name for Previdia Compact
0	Activate "Action 1"
...	...
99	Activate "Action 100"
100	Enable/Disable Zone 1
...	...
1099	Enable/Disable Zone 1000
1100	Activate/Deactivate I/O 1
...	...
1104	Activate/Deactivate I/O 4
1200	Activate/Deactivate relay

Address	Name for Previdia Compact
1400	Activate/Deactivate loop1 address 1 device's output
...	...
1879	Activate/Deactivate loop 2 address 240 device's output
5400	Enable/Disable I/O 1
...	...
5404	Enable/Disable I/O 4
5500	Enable/Disable relay
5700	Enable/Disable address 1 of loop 1
...	...
6179	Enable/Disable address 240 of loop 2

3.2 BACnet

BACnet is a building-automation-network communication protocol developed by ASHRAE (American Society of Heating, Refrigeration and Air-Conditioning Engineers). BACnet, as a result of its versatility and flexibility, is now extensively used as a standard communication protocol between devices and building-automation systems made by various manufacturers.

The BACnet protocol used for Previdia Max, with the IFMLAN module, is subject to licencing regulations.

3.2.1 BACnet licence

The licences for use of the BACnet protocol on Previdia Max control panels must be purchased from Inim Electronics.


The order codes are as follows:

- **INFLINIOPRALICBAC500**, BACnet protocol licence Previdia 500 points, Italian
- **INFLINEOPRALICBAC500**, BACnet protocol licence Previdia 500 points, English

Each licence allows the management of 500 points. For the management of a greater number of points it is necessary to purchase more than one licence. Inim Electronics supplies a single licence containing the sum of the licences purchased as per the format indicated here.

3.2.2 Licence activation procedure

1. In order to activate the licence you must communicate the following data to Inim:
 - the licence number shown in the letter /A/
 - the serial number of the IFMLAN /B/ (not to be confused with that of the FPMCPU). This data can be found in the software solution of the Previdia being configured, by going to the programming section of the IFMLAN module in the control panel.



2. The activation of the licence can be carried via e-mail or web.browser.

Via e-mail: send an e-mail to **service-previdia@inim.biz** containing the numbers previously indicated. You will receive an e-mail containing a file block which corresponds to the actual licence, required to block BACnet functionality.

Via web: by connecting to the **service-previdia.inimcloud.com** website it is possible to request the activation of a BACnet licence. After providing the previously mentioned data, the website will send you a file which corresponds to the actual licence.

3. After receiving the block file you must go back to the software solution associated with the control panel you are configuring. You must then go to programming section of the IFMLAN module and access the "BACnet - Activate licence" [C-D].
4. This section provides the **Load licence file** button [E] which allows you to inform the software of the location of the received file inside the computer.
5. Click on the **Activate licence** button [F] to send the licence to the IFMLAN module.

After the licence activation you can integrate the Previdia system using the BACnet protocol by means of the "Enable BACnet" option [G] and setting the parameters for the provider connection:

- BACnet device name
- BACnet device ID
- Password BACnet

3.2.3 BACnet objects

Following are the BACnet objects made available by Previdia and their essential features. For licencing purposes, each of the objects belonging to the typology listed below constitutes a "point".

- Life Safety Point
- Binary Input
- Binary Output
- Life Safety Zone

Life Safety Point

The "life safety point" comprises objects that represent the status of a specific point included in the following:

- Loop point
- IFM4IO module channel
- IFM16IO module channel
- IFMEXT module (one point only per module)

The status of each point is characterized by a defined list of values (stand-by, alarm, fault, etc.).

It is not possible to interact with a life safety point, change its status or bypass it.

Life Safety Zone

The "life safety zone" comprises objects that indicate the status of a zone. Therefore, they can be associated with the zones of the control panel that are linked to points.

It is not possible to interact with a life safety zone change its status or bypass it.

Binary Output

This object represents the status of any of the control panel outputs.

It is possible to change the status through the BACnet protocol. The "Binary output" objects of the Previdia control panel are the:

- Loop point
- IFM4IO module channel
- IFM4R module channel
- IFM16IO module channel
- IFM24160 module channel
- Actions on control panel

The actions on the control panel allow you to interact with the system. These are actions such as "silence sounders", "rearm control panel" or "investigate".


Binary Input

These objects represent the status of any of the control panel inputs, therefore, not is possible to view the status but not set it. On the Previdia control panel they are used for the viewing of some control panel conditions.

- Alarm
- Pre-alarm
- Fault
- Disable
- Night mode
- Sounder silenced
- Investigate

3.2.4 Creation of BACnet points via software

In order to create BACnet points you must first open the software, load the software solution of the relevant control panel/Hornet+ network, access the page relative to the IFMLAN then access the "BACnet" section.



This section provides the tools for the creation of life safety points. The other three sections ("Life safety zone", "Binary input" and "Binary output") function in the same way.

1. Select the control-panel point typology by means of the appropriate check boxes with dropdown menus [A]. In the section below [B] a list of points that correspond to the selection made will appear.
2. From the list select or deselect the BACnet points you wish to create.
3. Click on **Add** [C]. From this moment on the selected points will be shown in the "Life safety point" list [D]. The points in this section can be removed from the list by simply unticking the corresponding boxes.
4. Click on the **Write** button [E] to forward the programming to the control panel.

This procedure is valid for all BACnet point typologies.

3.3 SmartLook Software

The Previdia control panels can be supervised through the SmartLook software program created by Inim Electronics.

The SmartLook program is capable of enrolling the elements installed on the system either by reading the control panel directly or through the importation of data from the configuration software. At this point all that is necessary is to provide the graphic maps with image files and drag the icons of the objects installed on the system onto them.



SmartLook uses Modbus over TCP/IP to communicate with the control panel (refer to paragraph 3.1 Modbus RTU and Modbus over TCP/IP). During the configuration phase, SmartLook asks for the addresses of Previdia control panels on the Modbus and Hornet+ networks.

Note: *The address of a control panel in Modbus must coincide with that in Hornet+.*


For further information refer to the SmartLook software manual.

Pager systems

ESPA 4.4.4 is a standard protocol for the interconnection of paging systems, PABXs and automatic fire-detection systems. This protocol allows the exchange/sending of text messages between mobile devices such as pagers, cordless telephones, etc.

ESPA444 protocol is implemented for Previdia Max control panels within the IFMLAN module, through the RS232 communication port [A].

Serial	Terminal
RS232	1 Programmable ancillary power output
	2 RS232 TX
	3 RS232 RX
	4 RS232 RTS
	5 RS232 CTS
	6 Negative (GND, )
	7, 8 Earth



The protocol communication parameters can be configured through the Previdia control-panel configuration software. Access the page relative to the programming of the IFMLAN module, then access the "ESPA444" sub-section.



The screenshot shows the Previdia Studio software interface for configuring the IFMLAN module. The left sidebar shows the system path: System > Control panel xyz > IFMLAN. The main window has tabs for SETTINGS, CONTACTS, ACTIONS, ESPA444, ONVIF, BACNET, EVAC, and Maps. The ESPA444 tab is selected. On the left, there is a preview image of the IFMLAN module and several configuration fields:

- Serial number: NSNSNSNS
- IP: 192.xxx.xxx.xxx
- Netmask: 255.yyy.yyy.y
- Gateway: 192.zzz.zzz.zzz
- DNS server: 192.www.www.www
- Communication port: 6001
- Web server port: 80
- Checkboxes for: Enable SSL, Enable UPNP, Enable DHCP, and Enable BACNET.
- BACnet device name: Previdia
- BACnet device ID: 1234567890
- Password BACnet: *****
- Timezone: Europe (London, Jersey, Isle of Man, Guernsey)
- Checkboxes for: Web Reset Enabled and Web Silence Enabled.

The right side of the window contains a list of configuration options with dropdown menus and checkboxes:

Setting	Value
Serial port	RS232
Parity	None
Stop Bit	1
Data bit	7
Bits per second	300
Address	1
Pager address	1
Handshake	No
Add zone label	<input checked="" type="checkbox"/>
Add control panel label	<input type="checkbox"/>
Master	<input type="checkbox"/>
Delete event label	<input checked="" type="checkbox"/>

A 'Clear' button is located at the bottom of this list.

Refer to the user manual regarding the Previdia Max software configuration for further details.


Video verification

Control panels from the Previdia series are capable of capturing images from IP cameras equipped with ONVIF. These images can be displayed on screens or forwarded from a remote location via e-mail to provide the end-user with a clear understanding of what is happening in the ambient signalling the alarm.

The video verification function is implemented within the IFMLAN module. By means of the configuration software you can define the list of IP cameras (up to 200) that are intended to interact with the Previdia system.

Previdia Compact control panels can use the video verification function by means of a IFMLAN module of a Previdia Max control panel.

Access the page relative to the programming of the IFMLAN module, then access the "Onvif" sub-section. Each camera will acquire the various "preset" parameters:



To add the cameras to the configuration simply click-on the **Add** button [A]. The "Onvif cameras" section [B] provides a list of all the IP cameras in the configuration, whilst the "Camera" section on the right [C] provides the parameters of the selected camera.

Once the IP camera list has been defined, the configuration software will allow you to establish a series of presettings that permit the identification of the specific IP camera and the correct preset in accordance with each event.

To program the presettings go to the programming section of the graphic maps. To reach the IP Camera section you must first access the programming section of the FPMCPU frontplate module, click-on the “Graphic maps” button then access the “Cameras” sub-section.




Refer to the user manual regarding the Previdia Max software configuration for further details.

Voice Evac-systems

Previdia Max series control panels can be interconnected with the following voice evacuation systems.

- **Paso**

The voice evacuation systems made by Paso can be connected to the IFMLAN module through the RS485 port.



- **Tutondo**

The voice evacuation systems made by Tutondo can be connected to the IFMLAN module housed inside the Previdia Max control panel by means of TCP/IP connection..

6.1 Voice Evac configuration

Once the control panel has been connected to the voice evacuation system, the configuration software will allow you to configure each speaker line (evacuation zone) as an output capable of activating warning and evacuation messages.

Access the page relative to the programming of the IFMLAN module, then access the "Evac" sub-section.

1. Select the typology of voice-evacuation system [A].
2. Indicate the address of the Previdia Max control panel on the selected evacuation system [B]:
 - for "Paso" it is necessary to indicate the address on the RS485 connection BUS
 - for "Tutondo" it is necessary to indicate the IP address and the port
3. Indicate the number of evacuation zones (speaker lines) in the "Number of zones" box [C].

An icon will be added to the list at the bottom of the section for each added zone. In the case of "Tutondo", the "End of evacuation" zone is added automatically to all zones, this is an evacuation ended message that is common to all the evacuation zones.

4. Select each individual evacuation zone from the list [D] and program its parameters on the right [E].





ISO 9001 Quality Management
certified by BSI with certificate number FM530352

Centobuchi, via Dei Lavoratori 10
63076 Monteprandone (AP) Italy
Tel. +39 0735 705007 _ Fax +39 0735 704912

info@inim.biz www.inim.biz

