







| 2) DETAILS OF PRODUCT COMPONENTS |     |          |  |               |        |  |  |
|----------------------------------|-----|----------|--|---------------|--------|--|--|
| ITEM                             | QTY | PRODUCT  | PRODUCTION TYPE  | DIMENSION     | COLOUR |  |  |
| 1                                | 1   | Underpad | Total 34 gr (±2)<br>Backsheet – PE Film 14 gsm<br>Topsheet 8 gsm | 60x90 cm (±3) | White  |  |  |
|                                  |     |          | Pulp- Absorbent Area-21.12 gr                                    | 50x80 cm (±3) |        |  |  |

## 3) TEST RESULT (ISO 11948-1)

| ABSORPTION CAPACITY (ML)* | 773 |
|---------------------------|-----|
|---------------------------|-----|



## PRODUCT DATA SHEET UNDERPAD-NON STERILE 800.002C-1.02

## **4)GENERAL INFORMATION**

| Product Description    | UNDERPAD Non-Sterile   |  |  |
|------------------------|--|--|--|
| Certificates           | EN ISO 13485:2016  |  |  |
| Standards              | EN ISO 14971:2019  |  |  |
|                        | EN ISO 15223-1:2021  |  |  |
| Intented Use           | Underpad product is used as a mattress protector in health institutions such as hospitals, polyclinics, intensive care units, and home care patients.  |  |  |
| Instructions For Usage | Cut the products bag open with a scissor from the bottom side of the<br>packaging. Doing so will present you a better place to hold onto the pad<br>as you take it out of the packaging.<br>Take the underpad out and place it in a folded-up state, onto the surface<br>you'll be using it on.<br>Unfold the pad. Take the edge of the product and unfurl it outward, away<br>from you. Allow it to unfold completely.<br>Place the pad down on the surface, with the non plastic side up. The soft<br>side absorbs the urine, while the plastic-looking side will prevent any<br>liquid from going through and onto the surface. The person will lie down<br>on the softer side. |  |  |

## 5) PACKAGING

Packaging

Bag in 30 pcs

