



14 USEFUL HEAD SYSTEM

Useful head system (P/A)



| | | | | | |
|---|---------------------------------|---|---------|----|---------|
| A | Useful head system (kPa) | 4 | ANL 041 | 9 | ANL 103 |
| B | Water flow rate (l/h) | 5 | ANL 051 | 10 | ANL 153 |
| 1 | ANL 021 | 6 | ANL 071 | 11 | ANL 203 |
| 2 | ANL 026 | 7 | ANL 081 | | |
| 3 | ANL 031 | 8 | ANL 091 | | |

Useful head system (Q/N)



| | | | | | |
|---|---------------------------------|---|-------------|---|---------------|
| A | Useful head system (kPa) | 2 | ANL 071 (Q) | 5 | ANL 103 (Q/N) |
| B | Water flow rate (l/h) | 3 | ANL 081 (Q) | 6 | ANL 153 (Q/N) |
| 1 | ANL 051 (Q) | 4 | ANL 091 (Q) | 7 | ANL 203 (Q/N) |