

Model Name (제품명) : C30 plus (CX130)		
ERP Code	Part Code	Parts name
10013001	0A4M-COV01AA	Front Cover+materials+cost of printing
	0A4Q-WIN01AA	LCD Window
10013003	0A4R-RUB01AA	KEY RUBBER
10013004	LCD5-TS30206-LCM	3" TFT LCD
10013005	BOAD-0A4MAIN	CX130 MAIN B/D ASSY
10013006	BOAD-0A4SPO2	CX130 SPO2 B/D ASSY
10013007	BOAD-0A4KEY	CX130 KEY B/D ASSY
10012009	0A3M-COV03AA	Rear Cover+materials+cost of printing
10012010	BTNI-0485205	NI-MH battery (4.8v_2100mAh)
10013009	BTLI-0375235	LI-ION Battery (3.7V_2360mAh)