



- 2 Click on  button on the toolbar.
- 3 Insert CD/DVD or a USB drive.
- 4 Click **Device** menu to select a desired option. The **Path** menu becomes activated when you select the **User Directory** option, and you can specify a folder to export images.



- 5 Click **Export Type** to select options and click on the **Export** button.



- 6 Check the completion message or the error message.



- The message asking whether to remove the USB device appears when the study is exported to USB.