

GARANTİ BELGESİ & KULLANIM KLAVUZU

Elektrikli Termostatlı Çay&Kahve Makinaları



KAYALAR ÇELİK SAN.VE TİC.AŞ.

Garanti Belgesi

Çay makinalarının kullanma kılavuzunda belirtildiği şekilde kullanılması ve KAYALAR Çelik San. ve Tic. A.Ş.'nin yetkili kıldığı servis elemanları dışındaki şahıslar tarafından bakım, onarım veya başka bir nedenle müdahale edilmemiş olma şartıyla, bütün parçaları dahil olmak üzere tamamen malzeme, işçilik ve üretim hatalarına karşı 2 (İKİ) YIL SÜRE İLE GARANTİ EDİLMİŞTİR. Garanti kapsamı içinde yapılan işlemler için işçilik masrafı (servise geldiği zaman), değiştirilen parça bedeli yada başka bir ad altında hiçbir ücret talep edilmeyecektir. Garanti süresi içinde yapılacak onarımlarda geçen süre garanti süresine ilave edilir. Tamir süresi en fazla bir aydır. Bu süre mamülün servis istasyonunuza veya firmamıza teslim edildiği tarihten itibaren başlar.

Anzanın gidenilmesi konusunda uygulanacak teknik yöntemlerin tespiti ile değiştirilecek parçaların saptanması tamamen firmamıza aittir. Anzanın gidenilmesi yalnızca yetkili servis atölyelerinde yapılabilir. Müşterimizin buna onayı şarttır. Ancak ürünün satış tarihinden itibaren garanti süresinin içinde kalmak kaydıyla bir yıl içinde aynı anzayı üçten fazla tekrarlama veya farklı anzarların beşten fazla ortaya çıkması sonucu, üründen yararlanmamanın süreli kazanması veya tamiri için gerekli azami sürenin aşılması durumunda yetkili servis atölyelerinin mevcut olmaması halinde sırasıyla satıcı veya firmamız yetkilisi tarafından değiştirme işlemi yapılacaktır. Garanti belgesi ile ilgili olarak çıkabilecek sorunlar için Sanayi ve Ticaret Bakanlığı Tüketici ve Rekabetin Korunması Genel Müdürlüğü'ne başvurulabilir. Bu Garanti Belgesinin kullanılmasına 4077 Sayılı Kanun ile bu kanuna dayanılarak düzenlenen TRKGM - 95/116-117 sayılı tebliğ uyarınca T.C. Sanayi ve Ticaret Bakanlığı, Tüketicinin ve Rekabetin Korunması Genel Müdürlüğü tarafından izin verilmiştir.

ÜRETİCİ FİRMANIN

ÜNVANI : KAYALAR Çelik
San. ve Tic. A.Ş

ADRESİ :

TELEFON :

FAX :

TİCARET SİCİL NO.:

ÜRÜN CİNSİ:.....

ÜRÜN MODELİ:.....

ÜRÜN SERİ NO:.....

Dear Customers

we thank you for prefer to use our products and wish you get optimum productivity

Best Regards

KAYALAR ÇELİK SAN. TİC. A.Ş

*You can find base information of installation and repair stages in this booklet
*Pls conduct with kayalar if you can not find information for defective parts or when you define a mismatch.

Kayalar can change informations in this booklet if it needed.
A part of or all of this booklet can not be used by another firm without KAYALAR ÇELİK SAN. And TİC. A.Ş. ' permission.

Important points and issues!

- Plug the machine in a grounded outlet, definitely
- Don't use ground connection in a neutral cycle
- Don't use your machine without water
- Don't put water when your machine's resistance is hot
- Don't leave plug in if you don't use your machine
- (Allocation in between nets and resistance is provided by thermostats)
- Don't maintenance except authorized service
- Otherwise your appliance is to be out of service

Usage of Tea Machine

- Put fresh water to the water tank up to 3-4 cm below of tank.
- Put enough dry tea to the tea tank.
- Make the thermostat 110 °C.
- After 20 min. boiling, make thermostat 95 °C.
- After 10 min. rest, you can serve it.

USAGE of COFFEE MACHINE

- Put fresh water from the bottom of a coffee machine up to 3-4 cm below of coffee machine.
- Put enough filter coffee in the filter coffee reservoir.
- Push the start button to switch on
- Push the stop button to switch off
- After 40-45 minutes your coffee is ready for serving.

ATTENTION: If the coffee machine works without water, that causes exaggerated warmth and safety thermostat cuts the power that goes to the resistance to protect your machine.

- Put water in your coffee machine
- Push on the start button. Resistance will start.

It should be cleaned twice before the first usage and in a month in a way that stated below.

- Put decomposer in the water part (Put bleacher in the breath part in tea machines)
After that, boil the water 20 minutes. After 20 minutes, pour the water. Then make tea, and pour it as well. (Never drink the tea that you make after cleaning) After all those phases, the cleaning process ends. Now that you can use your coffee or tea machine.

In concern with Warranty;
Points that customers must pay attention;

This warranty by given Kayalar doesn't include that repair the breakdown when the machine is used except usual conditions. Also below conditions are out of warranty.

1. Damage and breakdowns because of use errors.
2. When damage and breakdowns occur during loading, unloading and carrying.
3. When damage and breakdowns occur that the machine is used in false voltage level drop or excessive in voltage or incorrect electrical wiring.
4. Damage and breakdowns because of fire and natural disaster.
5. Damage and breakdowns because of using the machine without grounded wiring.

The above breakdowns are repaired for a fee.

Warranty period is valid just one year and breakdowns because of production. Otherwise any rights and compensation cannot be claimed for any conditions.

If there is not commercial invoice with stamp and signature, the date of production that stated on the product will be taken into account for the beginning date of warranty.

When date of sale is not clear on the machine or invoice, warranty will not be valid.

FIRST JOB SECURITY

FIRST JOB SECURITY

The machine can not be used by children and people not read this manual guide.

All sorts of general maintenance and repair operations must be made by the authorized service.

The feeder circuits must be removed when working on electrical system of the device.

ATTENTION

Don't use plotter articles such as; sand paper, wire brush when you clean tea maker and coffee machine surface.