






Straight

PEAN (ROCHESTER)
04-273-14 - 04-280-30
04-273-14 14 cm
04-274-16 16 cm
04-275-18 18 cm
04-276-20 20 cm
04-277-22 22 cm
04-278-24 24 cm
04-279-26 26 cm
04-280-30 30 cm




Curved

PEAN (ROCHESTER)
04-281-14 - 04-288-30
04-281-14 14 cm
04-282-16 16 cm
04-283-18 18 cm
04-284-20 20 cm
04-285-22 22 cm
04-286-24 24 cm
04-287-26 26 cm
04-288-30 30 cm



Straight

KOCHER (OCHSNER)
04-289-14 - 04-296-31
04-289-14 14 cm
04-290-16 16 cm
04-291-18 18 cm
04-292-20 20 cm
04-293-22 22 cm
04-294-24 24 cm
04-295-26 26 cm
04-296-31 31 cm



Curved

KOCHER (OCHSNER)
04-297-14 - 04-304-31
04-297-14 14 cm
04-298-16 16 cm
04-299-18 18 cm
04-300-20 20 cm
04-301-22 22 cm
04-302-24 24 cm
04-303-26 26 cm
04-304-31 31 cm



DISSECTING KNIVES
Fig. 1 - 10
01-100-15 - 01-109-17



Fig. 1
01-100-15
15 cm



Fig. 2
01-101-15
15 cm



Fig. 3
01-102-16
16 cm



Fig. 4
01-103-16
16 cm



Fig. 5
01-104-16
16 cm



Fig. 6
01-105-15
15 cm



Fig. 7
01-106-15
15 cm



Fig. 8
01-107-16
16 cm




Fig. 9
01-108-16
16 cm



Fig. 10
01-109-17
17 cm

SECTION 03

Forceps



DE BAKEY
03-151-15 - 03-152-20
03-151-15
15 cm
03-152-20
20 cm

DE BAKEY
03-153-15 - 03-156-30
03-153-15
15 cm
03-154-20
20 cm
03-155-24
24 cm
03-156-30
30 cm

DE BAKEY
03-157-15 - 03-160-30
03-157-15
15 cm
03-158-20
20 cm
03-159-24
24 cm
03-160-30
30 cm

DE BAKEY
03-161-20 - 03-163-30
03-161-20
20 cm
03-162-24
24 cm
03-163-30
30 cm

DE BAKEY
03-164-20
20 cm

DE BAKEY
03-165-15
15 cm

GERALD
03-166-17
17.5 cm
03-167-23
23 cm