

9.1 Types of menus

NOTE: For details about how to select a menu, see "Basic controls" in this manual.



Touch panel display example

(1) Direct switches, (2) tabs, (3) Function menus

Menus are broadly classified into direct switches (1 in figure above) and function menus (3 in figure above).

Selecting a direct switch starts the corresponding function.

Function menus (3 in figure above) group modes and functions into tabs for display.

You can assign functions to direct switches and the function menu with input device presets.

Reference information

1.2.1 Touch panel menus on page 26

10.7.4 Assigning functions on page 343

9.2 Direct switches

This section explains functions that can be assigned to direct switches.

The functions shown in this section can be assigned to custom switches, foot switches, or the custom keyboard (F1 to F12 keys).

B

Menu name	Description
Assist Line	Displays and hides the lines for a head-case scale.
Auto-optimizer	Starts the auto optimization process.
Auto-optimizer Reset	Resets the auto optimization process.
Auto FHR+	Starts Auto FHR+.
BCF (B)	Applies or removes the BCF image filter if the [HI REZ] setting is On.
Bottom Display	In 360° radial display, the lower 180° portion is displayed.