

Accessories

Accessories for LD Mechanic Sphygmomanometer.

For comfortable and safe use of LD sphygmomanometers, the manufacturer recommends to use only original components.

The use of original components guarantees reliable measurement results and allows avoiding the device operation problems.

All components are certified, tested and approved for use.

DESCRIPTION	PHOTO	DESCRIPTION	PHOTO
LD-S01A Pneumatic bladder with 1 tube, for adults, for sphygmomanometers LD-81, LD-91		LD-S014 + LD-S016 Pump with check valve for sphygmomanometers LD-60, LD-61, LD-70, LD-70NR, LD-71, LD-71A, LD-80, LD-100	
LD-S02A Pneumatic bladder with 2 tubes, for adults, for sphygmomanometers LD-70, LD-70NR, LD-71, LD-71A, LD-100		LD-S050 + LD-S016 Pump with check valve for sphygmomanometer LD-81	
LD-S013 Manometer for sphygmomanometers LD-60, LD-61, LD-70, LD-70NR, LD-71, LD-71A, LD-80		LD-S015 Air valve for sphygmomanometers LD-60, LD-61, LD-70, LD-70NR, LD-71, LD-71A, LD-80, LD-100	

