

VISION										Product fiche and information - Water heaters														
I Load profile					IV Annual electricity consumption [kWh/annum]					VII Storage volume [l]					Sound power level									
II Water heating energy efficiency class					V Thermostat temperature setting [°C]					VIII Mixed water at 40°C [l]					15 [dB]									
III Water heating energy efficiency [%]					VI Daily electricity consumption [kWh]					IX Water heating energy efficiency [%]														
		Regulation EU 812/2013				Regulation EU 814/2013						Regulation EU 812/2013				Regulation EU 814/2013								
Модел / Model	I	II	III	IV	V	VI	VII	VIII	IX	Модел / Model	I	II	III	IV	V	VI	VII	VIII	IX					
HABITAT EWH 30	S	C	33	556	60	2,665	-	-	33,1	HABITAT EWH 80	M	C	36	1423	60	6,671	-	124	36,1					
HABITAT EWH 50	M	C	36	1411	60	6,598	-	79	36,4	HABITAT EWH 100	M	C	37	1396	60	6,515	-	156	36,7					
During product installation, use, service, and maintenance it is compulsory to comply strictly with all instructions in the user guide for installation and usage, as well as with product warranty card.																								
Once the product lifetime is terminated it must be dumped in accordance with the provision of legislation in force (regulations and directives) concerning its correct disassembly, disposal, and recycling, as well protection of mankind and the environment.																								
VISION										Product fiche and information – Hot water storage tanks														
I Energy efficiency class					II Standing loss [W]					III Storage volume [l]					IV Storage volume [l]					V Standing loss [W]				
EU regulation	812/2013				814/2013	EU regulation	812/2013				814/2013	EU regulation	812/2013				814/2013							
Модел / Model	I	II	III	IV	V	Модел / Model	I	II	III	IV	V	Модел / Model	I	II	III	IV	V							
BC 500K	B	60	491	491,4	60,0	VISION 150F ErP-B	B	45	145	145,3	44,7	VISION 500 ErP-B	B	60	476	476,4	59,8							
BC 750F	C	116	748	748,2	115,6	VISION 150FT	B	54	141	141,3	54,4	VISION 500DUAL ErP-B	B	62	465	465,3	62,3							
BC 750K	B	75	748	748,2	75,4	VISION 150M	B	55	142	142,3	54,7	VISION 750 ErP-B	B	83	738	738,4	83,4							
BC 1000F	C	131	961	961,4	130,8	VISION 150MDUAL	B	54	140	140,4	54,4	VISION 750 ErP-C	C	123	738	738,4	122,7							
BC 1000K	B	87	961	961,4	87,3	VISION 200	B	59	186	186,4	59,4	VISION 750DUAL ErP-B	B	87	721	721,4	87,2							
BC 2000	C	178	2020	2020,1	178,4	VISION 200DUAL ErP-B	B	56	184	184,3	55,6	VISION 750DUAL ErP-C	C	127	721	721,4	126,8							
VISION 80	B	44	73	73,4	44,4	VISION 200FM ErP-B	B	52	186	186,4	52,3	VISION 1000 ErP-B	B	93	936	936,3	92,9							
VISION 80FT	B	45	75	75,3	45,3	VISION 300 ErP-B	B	50	264	264,3	50,2	VISION 1000 ErP-C	C	135	936	936,3	134,7							
VISION 100	B	48	91	91,3	47,6	VISION 300DUAL ErP-B	B	52	258	258,4	51,8	VISION 1000DUAL ErP-B	B	94	920	920,3	94,3							
VISION 100FT	B	48	91	91,3	47,8	VISION 300N ErP-B	B	50	264	264,3	50,2	VISION 1000DUAL ErP-C	C	137	920	920,3	136,8							
VISION 120	B	51	112	112,4	50,8	VISION 300NDUAL ErP-B	B	52	258	258,4	51,8													
VISION 120FT	B	51	112	112,4	51,1																			
During product installation, use, service, and maintenance it is compulsory to comply strictly with all instructions in the user guide for installation and usage, as well as with product warranty card.																								
Once the product lifetime is terminated it must be dumped in accordance with the provision of legislation in force (regulations and directives) concerning its correct disassembly, disposal, and recycling, as well protection of mankind and the environment.																								