## tempmate. M2


## OPERATION INSTRUCTIONS






RECORD Green LED





**1** Keep green button pressed for minimum 5 seconds to start recording



02 Add started tempmate.®-M2 to your shipment



∩ Connect stopped logger directly to USB port



 ↑4 The PDF report will be generated automatically





Start Logger





Not started Low battery



5 sec.

Stop Logger



Recording-OK Recording-Alarm



2 times

Set Mark Mark limit full



Stopped-OK Stopped-Alarm



