

Instructions

Accessories

1		R 1/8	003H6852		SW 12 (14 Nm)	SW 10
		R 3/8	003H6853		SW 12 (14 Nm)	SW 17
		R 1/2	003H6854		SW 12 (14 Nm)	SW 22
		–	003H6860		SW 12 (14 Nm)	SW 12 (14 Nm)
2		G 1/8	003H6931 003H6932		SW 12 (14 Nm)	SW 14
3		R 1/8	003H6857		SW 12 (14 Nm)	SW 10
		R 3/8	003H6858		SW 12 (14 Nm)	SW 17
		R 1/2	003H6859		SW 12 (14 Nm)	SW 22



