


ELETRONIC RACK F07S11



Pos.	Code	Description
1	E68S96	C.S. Conv. & Starter Interf.
2	E68S30	C.S. Back Plane
3	E68S45	C.S. Modulo Vulcano UC3C
4	E68SC7	C.S. Logic Board
5	E68S33	C.S. Filament Board
6	E68S41	C.S. PSU 8.5kW
7	E68S37	C.S. Schermo RF S1000H8
8	E50A50	Cable conn. conv. FB-I
9	E50A51	Cable conn. conv. PWM
10	F04S11	Converter
11	E55A30	Line Filter FN660B-16/06
12	E58A03	STATIC RELAY
13	E54A16	Resistor 1K
14	E62A34	Conn. Pann. M7P
15	E62A38	Conn. Pann. F7P
16	E62A35	Conn. Pann. F4P
17	E55A47	Cap. 250V 33uF
18	E55A29	Cap. 400V 40uF (40x94)