

Reiniger
Cleaner
Nettoyant

BÜRO / OFFICE / BUREAU

Druckluftreiniger

Air Duster

Aérosol dépoussiérant



Zur Reinigung von unzugänglichen Stellen in EDV- und Bürogeräten (Computertastaturen, Druckern, CD-ROM- / Diskettenlaufwerken, Kopiergeräten, Fax, etc.).

An ecologically friendly, flammable cleaner for inaccessible areas of electronic equipment (computer keyboards, CD-ROM / disk drives, printers, fax, etc.).

Pour nettoyer les endroits inaccessibles dans les appareils informatiques et de bureau (claviers d'ordinateurs, imprimantes, lecteurs de CD-ROM / disquettes, photocopieuses, fax, etc.).



ARTICLE	CONTENT	PCS. PER CARTON
55030001	400 ml	12

Fingertip

Fingeranfeuchter

Finger moistener

Humidificateur de doigts



Die hygienische Alternative. Mit Fingertip lassen sich zudem störende, durch das Blättern verursachte, Hautirritationen an der Fingerspitze vermeiden.

The hygienic alternative. With Fingertip, annoying skin irritations on the tip of your fingers caused by leafing through papers can be avoided.

L'alternative hygiénique. Le Fingertip permet en outre d'éviter de gênantes irritations cutanées causées par le défilement des pages.



ARTICLE	CONTENT	PCS PER BOX	PCS PER CARTON
18526150	20 ml	12	120