Reusable Heater Wire Adaptors



☐ Inspiratory Heater Wire Adaptor for reusable circuits Lemo™ style

For use with the MR850 humidifier when paired with an inspiratory heated, reusable circuit





Dual Heater Wire Adaptor for reusable circuits Lemo™ style

For use with the MR730 humidifier when paired with a dual heated, reusable circuit


900MR558



Inspiratory Heater Wire Adaptor for reusable circuits Lemo™ style

For use with the MR730 humidifier when paired with an inspiratory heated, reusable circuit

900MR033



Airway Thermometer

- For measuring gas temperature when used in conjunction with the MR410 humidifier
- Available in packs of 3

Reusable Humidification Chmabers

Reusable Humidification Chambers

MR370

Adult Humidification Chamber



Inlet Port: 22mm F Outlet Port: 22mm M

900MR066


Absorbent Paper Refill Pack



- For use with MR370 humidification chamber
- Each pack contains 100 sheets

MR340

Infant Humidification Chamber



Inlet Port: 15mm F Outlet Port: 22mm M

900MR065

Absorbent Paper Refill Pack



- For use with MR340 Humidification chamber
- Each pack contains 100 sheets

900MR530 900MR533 900MR534 900MR535 900MR405 900MR406

Adaptor

- 22 mm F to 22mm M/ 15mm F
- Available in as single item, 50
- 900MR530L = 50

Adaptor

- 15mm M/ 10mm F to 15mm M/ 10mm F
- Available as single item, 50, 100
- 900MR533L = 50
- 900MR533C = 100

Adaptor

- 22mm M / 15mm F to 22mm M / 15mm F
- Available as single item, 50, 100
- 900MR534L = 50
- 900MR534C = 100

Adaptor

- 22mm M/ 15mm F to 15mm M/ 10 mm F
- Available as single item

Adaptor


- 22mm F to 15mm M
- Available as single item

Adaptor

- 22mm F to 10mm M
- Available as single item

Water Trap

- 2 x 22mm M/ 15mm F ports
- Spring load valve maintains circuit seal when emptying the water trap
- Available as single item, 100
- 900MR139C = 100



900MR139



Reusable Components


900MR130 900MR131

Elbow Adaptor

- 22mm F to 22mm M / 15mm F
- Available as single item, 50, 100
- 900MR130L = 50
- 900MR130C = 100


Elbow Adaptor with Temperature Port

- 22mm F to 22mm M / 15mm F
- Available as single item, 100
- 900MR131C = 100



Adaptor


- 10mm M to 10mm M
- Available in packs of 10



900MR143

Adaptor

- 10mm M to 15mm M/ 10mm F
- Available as single item




Adaptor

- 10mm M to 15mm M / 11mm F
- Designed for use with Dräger circuits
- Available as single item




Adaptor

- 22 mm F
- Used to connect oxygen/air tubing to the humidification chamber
- Available as single item



Adaptor

- 22 mm M/ 15mm F
- Used to connect oxygen/air tubing to the humidification chamber
- Available as single item




900MR178

Adaptor

- 12 mm M to 15mm M/ 10mm F
- · Available as single item


Reusable Infant Breathing Circuits



Infant Single Heated Flow Breathing Circuit kit

Flows ≥ 4 L/min


- 1.1 (44") inspiratory heated
- 0.3m (12") incubator extention
- 1.8m (71") non heated expiratory
- 0.7m (28") ventilator connection



Infant Single Heated Breathing Circuit kit

Flows < 4 L/min

- 1.1 (44") inspiratory heated
- 0.3m (12") incubator extention
- 1.8m (71") non heated expiratory
- 0.7m (28") ventilator connection



Infant Single Heated Breathing Circuit kit

Flows ≥ 5 L/min


1.3m (52") heated inspiratory



Adult Invasive Ventilation Breathing Circuits & Chambers

Dual Heated

with chamber



RT200

RT212

Adult Breathing Circuit Dual heated with EVAQUA® expiratory limb, autofeed chamber and filter


- 1.5 heated inspiratory limb
- 1.8m heated EVAQUA[®] expiratory limb
- 0.5m humidifier connection tube
- MR290 autofeed humidification chamber
- RT019 Inspiratory/Expiratory filter
- RT028 Circuit hanger
- Available in cartons of 10

Adult Breathing Circuit Dual heated with autofeed chamber

- 1.5m heated inspiratory limb
- 1.5m heated expiratory limb
- 0.5m humidifier connection tube
- MR290 autofeed humidification chamber
- Available in cartons of 10

Inspiratory Heated

with chamber




Adult Breathing Circuit Inspiratory heated with autofeed chamber

- 1.5m heated inspiratory limb
- 1.76m unheated expiratory limb with water trap
- 0.5m humidifier connection tube
- MR290 autofeed humidification chamber
- Available in cartons of 10

Adult Breathing Circuit Inspiratory heated with autofeed chamber

- 1.5m heated inspiratory limb
- 2.0m unheated expiratory limb with water trap
- 0.5m humidifier connection tube
- MR290 autofeed humidification chamber
- Available in cartons of 10






Infant Invasive Breathing Circuits & Chamber Kits

Flows < 4 L/min

with chamber



RT226

ΔB

Infant Breathing Circuit Kit Dual heated with EVAQUA® expiratory limb


- 1.1m heated inspiratory limb
- 0.3m incubator extension
- EVAQUA[®] heated expiratory limb
- 0.6m humidifier connection tube with nitric oxide port
- Pressure line
- Adaptor kit
- MR290 autofeed humidification chamber
- Available in cartons of 10

Infant Low Flow Breathing Circuit Kit

- 1.1m heated inspiratory line
- 0.3m incubator extension
- Unheated expiratory limb with water trap
- 0.6m humidifier connection tube with nitric oxide port
- Pressure line
- Adaptor kit
- MR290 autofeed humidification chamber
- Available in cartons of 10



without chamber



Infant Low Flow Breathing Circuit

- 1.1m heated inspiratory line
- 0.3m incubator extension
- Unheated expiratory limb with water trap
- 0.6m humidifier connection tube with nitric oxide port
- Pressure line
- Adaptor kit
- Available in cartons of 10



900MR530 900MR533 900MR534 900MR535 900MR405 900MR406

Adaptor

- 22 mm F to 22mm M/ 15mm F
- Available in as single item, 50
- 900MR530L = 50

Adaptor

- 15mm M/ 10mm F to 15mm M/ 10mm F
- Available as single item, 50, 100
- 900MR533L = 50
- 900MR533C = 100

Adaptor

- 22mm M / 15mm F to 22mm M / 15mm F
- Available as single item, 50, 100
- 900MR534L = 50
- 900MR534C = 100

Adaptor

- 22mm M/ 15mm F to 15mm M/ 10 mm F
- Available as single item

Adaptor


- 22mm F to 15mm M
- Available as single item

Adaptor

- 22mm F to 10mm M
- Available as single item

Water Trap

- 2 x 22mm M/ 15mm F ports
- Spring load valve maintains circuit seal when emptying the water trap
- Available as single item, 100
- 900MR139C = 100




900MR139



Airway Temperature Probes




900MR860-869 Fig. Temperature/Flow Probes for MR850 Humidifier **Right Angle Airway Probe**



900MR863	for use with circuits 0.7m (28") in length
900MR868	for use with circuits 1.1m (44") in length
900MR860	for use with circuits 1.3m (52") in length
900MR869	for use with circuits 1.5m (60") in length
900MR861	for use with circuits 1.8m (72") in length


900MR560-571



Temperature Probes for MR700 & HC500 Series Humidifiers **Right Angle Airway Probe**

900MR563	for use with circuits 0.7m (28") in length
900MR568	for use with circuits 1.1m (44") in length
900MR560	for use with circuits 1.3m (52") in length
900MR569	for use with circuits 1.5m (60") in length
900MR561	for use with circuits 1.8m (72") in length
900MR571	for use with circuits 2.5m (92") in length

900MR208



Reflective Shield for Temperature Probe

- Protects airway temperature probe from radiant heat to improve humidifier performance with infant radiant warmers
- Available in packs of 20

900MR033



Airway Thermometer

- For measuring gas temperature when used in conjunction with the MR410 humidifier
- Available in packs of 3