


3 Register and Download Software (Cont.)

4. Finish Registration: Tap on "Yes" to enter the vehicle software download screen. Refer to Figure D. To download it later, tap on "No".




2. Download the diagnostic software

Tap "Update" on the update page to start downloading. Once downloading finished, the software packages will be installed automatically. Note: When downloading the diagnostic software or checking for updates it is important to make sure the tool has a strong Wi-Fi connection.

4 Vehicle Connection


1. OBD II Vehicle Connection

- A Directly plug the VCI into vehicle's DLC
B Using OBD II extension cable




2. Non-OBD II Vehicle Connection

- A Via Cigarette Lighter Cable




4 Vehicle Connection (Cont.)

- B Via Battery Clamps Cable



5 Start Diagnostics

For new users, please follow the operation chart as below to get familiar with and start using this tool.



Preparation

Before diagnosing, please do the following:

- Switch the ignition on.
- Vehicle battery voltage range should be 9-18Volts.
- Throttle should be in a closed position.

Notes:

1. To enjoy more service and functions, you are suggested to check for updates on a frequent basis and keep updated with the latest available software.
2. For details on Intelligent Diagnosis, refer to User Manual.

THANK YOU FOR CHOOSING LAUNCH!

If you have any questions or comments please forward them to:

+86 755 8455 7891

overseas.service@cnlaunch.com