| Connectors | | | |
|------------|---|---|--|
| BP12 | HP Cuff connector(male bayonet) | | |
| BP16 | HP Air Hose connector to connect monitor plug | | |
| BP19 | HP /Spacelab monitor NIBP socket | | |
| BP15 | Female Bayonet connector | | |
| BP15-S | Female bayonet socket of NIBP on monitor | | |
| BP22 | GE/ Ohmeda Air hose (dual tubes) connector on Equipment Side | 6 | |
| BP24 | GE Air hose (dual tubes) connector on Equipment Side | | |
| BP40 | Drager NIBP air hose connector assemblies ,to connector equipment end | | |
| BP17 | Quick connect submin male connector | | |
| BP18 | quick connect submin female connector | | |