

## 7.5 Entering Passwords

The password entry screen is displayed only if Password Protection in the Setting Screen is set during installation of the equipment.






Figure 7.1 Password Entry Screen

- 1 Enter a 4-digit numeric password using the numerical keys.

Pass the  key to return to the normal screen from the password entry screen.



- 2 If the entered password is correct, setup screen is displayed.



# 8

---

## Troubleshooting

This chapter explains the messages displayed by the equipment and how to remedy them.