



HydroCel Geodesic Sensor Net™

Sponged (routine), Spongeless (LTM), and Magnetic resonance (MR) Nets

Size Chart

8403488-58 (20181210)

How to Use the Size Chart

Always base your Net size selection on the circumference of your patient's head, not on your patient's age.

Stage	Head Circum. and Net Size	General Age or Head Size		Channel Counts				Monitoring Type		
		Males	Females	32	64	128	256	Routine	LTM	MR
Preterm infant	28 – 30 cm	Preterm Small		✓	✓	✓		✓		
	30 – 32 cm	Preterm Medium		✓	✓	✓		✓		
	32 – 34 cm	Preterm Large		✓	✓	✓		✓		
Infant	34 – 36 cm	Neonate	Neonate	✓	✓	✓		✓		✓
	36 – 37 cm	Birth – 2 weeks	Birth – 1 month	✓	✓	✓		✓		✓
	37 – 38 cm	2 weeks – 1 month	1 – 2 months	✓	✓	✓		✓		✓
	38 – 40 cm	1 – 2 months	2 – 3 months	✓	✓	✓		✓		✓
	40 – 42 cm	2 – 3 months	3 – 6 months	✓	✓	✓		✓		✓
	42 – 43 cm	3 – 5 months	6 – 7 months	✓	✓	✓		✓		✓
	43 – 44 cm	5 – 7 months	7 – 9 months	✓	✓	✓		✓		✓
	44 – 47 cm	7 – 15 months	9 – 21 months	✓	✓	✓		✓		✓
Pediatric	47 – 51 cm	Pediatric Small		✓	✓	✓		✓	✓	✓
	51 – 54 cm	Pediatric Large		✓	✓	✓	✓	✓	✓	✓
Adult	54 – 56 cm	Adult Small		✓	✓	✓	✓	✓	✓	✓
	56 – 58 cm	Adult Medium		✓	✓	✓	✓	✓	✓	✓
	58 – 61 cm	Adult Large		✓	✓	✓	✓	✓	✓	✓
	61 – 64 cm	Adult Extra Large		✓	✓	✓	✓	✓	✓	✓

For questions or additional assistance, please contact us at:



Electrical Geodesics, Inc. (EGI)
500 E 4th Avenue, Suite 200
Eugene, OR 97401 USA

+1.541.687.7962 • supportteam@egi.com • www.egi.com

