Data: 04.01.2022

Subject: Letter confirmation

Dear Partners,

Air Ventilation

We would like to inform you that for to maintain the correct temperature regime of the oxygen station, and correct ventilations of the container, our screw air compressors must have the air ventilation channels for the supply of the cooling air flow and to remove the heated exhaust air flow outside. The channel cross section is calculated individually for each compressor model depending on its capacity.

Here below you can find technical information for compressors from 22,0 kW up 75,0 kW

	Inlet opening,m2	Free duct cross section,m2
22,0 kW	0,94	0,29
30,0 kW	1,35	0,42
45,0 kW	1,60	0,48
55,0 kW	2,00	0,59
75,0 kW	2,30	0,68

COMPRA

COMPRAG GmbH SIMONSHÖFCHEN 30 42327 WUPPERTAL, DEUTSCHLAND

Air conditioning

The container must be equipped with an air conditioner to cool the interior. Air conditioner model, BTE 12

Igor Ortenberg GeschaftsfOhrer