



**Test report No. 15519hd**

EVALUATION OF FUNGICIDAL OR YEASTICIDAL ACTIVITY IN FOOD, INDUSTRIAL,  
DOMESTIC AND INSTITUTIONAL AREAS (EN 1650)

**Name of the product: CHEMISEPT MED**

Batch number: 196300919

Date of test report: 25/11/2019

Client, representative:  
Chemi-Pharm Ltd.  
Tänassilma tee 11  
Tänassilma küla  
Saku vald, 76406  
ESTONIA

Test report No. 15519hd

EVALUATION OF FUNGICIDAL OR YEASTICIDAL ACTIVITY IN FOOD, INDUSTRIAL, DOMESTIC AND INSTITUTIONAL AREAS (EN 1650)

Name of the product: CHEMISEPT MED  
Batch number: 196300919  
Order number: 19040  
Manufacturer: Chemi-Pharm Ltd.  
Client, representative: Chemi-Pharm Ltd., Tännassilma tee 11, Tännassilma, 76406 Harju maakond, Estonia  
Maris Millner, +372-51-77-090  
Date of delivery: 04.10.2019  
Test material conditions: No specific features, sample in the manufacturers tare  
Storage conditions: In room temperature, dark  
Active substance – conc.: Ethyl alcohol 72.5% w/w, isopropyl alcohol 7.5% w/w  
Appearance of the product: Transparent liquid  
Test concentration: 80%; 50%; 10%  
Contact time: 60 s  
Interfering substance: 0.3 g/l bovine albumin = clean conditions; 3.0 g/l bovine albumin = dirty conditions  
Rinsing liquid: Tryptone 1 g/l + NaCl 9 g/l  
Neutralizer: -  
Test organisms: *Aspergillus brasiliensis* ATCC 16404  
Testing method: EVS-EN 1650:2019  
Quantitative suspension test for the evaluation of fungicidal or yeasticidal activity of chemical disinfectants and antiseptics used in food, industrial, domestic and institutional areas.  
Testing date: 25.10.2019 – 28.10.2019  
Results: look appendix 1-2



  
Mele Aas-Valleriani  
Microbiologist

Date of test report: 25.11.2019

Appendix 1

TEST RESULTS (suspension test)

EVS-EN 1650:2019; Phase 2, step 1;  
Membrane filtration method;  
Rinsing liquid: Tryptone 1 g/l + NaCl 9 g/l;  
Test organism: *Aspergillus brasiliensis* ATCC 16404;  
Test temperature: +20° C; Incubation temperature: +30 ± 1° C  
Interfering substance: 0.3 g/l bovine albumin = clean conditions; 3.0 g/l bovine albumin = dirty conditions  
Nordic Tersus Laboratory LLC.; Date of test: 25.10.2019  
Responsible person: Nele Aas-Valleriani

Validation and controls

Clean and dirty conditions

Validation suspension $N_{vo}$			Experimental conditions (A)			Filtration control (B)			Method validation (C)		
$V_{C1}$	$V_{C2}$	$\bar{x}$	$V_{C1}$	$V_{C2}$	$\bar{x}$	$V_{C1}$	$V_{C2}$	$\bar{x}$	$V_{C1}$	$V_{C2}$	$\bar{x}$
43	37	40	38	41	39.5	38	43	40.5	36	39	37.5
$30 \leq \bar{x} N_{vo} \leq 160$ ? yes X; no <input type="checkbox"/>			$\bar{x} A$ is $\geq 0.5 \bar{x} N_{vo}$ ? yes X; no <input type="checkbox"/>			$\bar{x} B$ is $\geq 0.5 \bar{x} N_{vo}$ ? yes X; no <input type="checkbox"/>			$\bar{x} C$ is $\geq 0.5 \bar{x} N_{vo}$ ? yes X; no <input type="checkbox"/>		

Test suspension and test

Test suspension:	$N$	$V_{C1}$	$V_{C2}$	$\bar{x}_{wm} = 1.66 \times 10^7$ ; $\log N = 7.22$ $N_0 = N/10$ ; $\log N_0 = 6.22$ $6.17 \leq \log N_0 \leq 6.70$ ; yes X; no <input type="checkbox"/>
$N$ and $N_0$	$10^{-5}$	150	150	
	$10^{-6}$	27	23	

### Experimental results

Concentration of the product	Dilution step	$V_{C1}$	$V_{C2}$	$N_a$ (= $\bar{x}$ *10)	log $N_a$	logR	Contact time	Conditions
10%	-	>165	>165	>1650	>3.22	<3.00	30 s	Clean
50%	-	>165	>165	>1650	>3.22	<3.00	30 s	Clean
80%	-	<14	<14	<140	<2.15	>4.07	30 s	Clean
10%	-	>165	>165	>1650	>3.22	<3.00	60 s	Clean
50%	-	>165	>165	>1650	>3.22	<3.00	60 s	Clean
80%	-	<14	<14	<140	<2.15	>4.07	60 s	Clean
10%	-	>165	>165	>1650	>3.22	<3.00	30 s	Dirty
50%	-	>165	>165	>1650	>3.22	<3.00	30 s	Dirty
80%	-	<14	<14	<140	<2.15	>4.07	30 s	Dirty
10%	-	>165	>165	>1650	>3.22	<3.00	60 s	Dirty
50%	-	>165	>165	>1650	>3.22	<3.00	60 s	Dirty
80%	-	<14	<14	<140	<2.15	>4.07	60 s	Dirty

#### Explanations:

$V_C$  = count per ml (one plate or more)

$\bar{x}$  = average of  $V_{C1}$  and  $V_{C2}$  (1. + 2. duplicate)

$N$  = cfu/ml microbes in testsuspension

$N_0$  = cfu/ml at the start of the contact time (t=0)

$N_{vo}$  = cfu/ml in the validation suspension (t=0)

$N_a$  = surviving microbes after the test

R = reduction factor (R=  $N_0/ N_a$ ; LogR=Log $N_0$  - Log  $N_a$ )

Appendix 2

Interpretation:

The ready to use product CHEMISEPT MED (batch no. 196300919) was tested according to the test method 1650:2019. The test was performed at  $20\text{ °C} \pm 1\text{ °C}$ , under clean and dirty conditions during contact times of 30 s and 60 s. The membrane filtration method was used for testing the product's effectiveness against the reference strain *Aspergillus brasiliensis* ATCC 16404. Under clean and dirty conditions the tested product was effective against the reference strain within contact times tested.

Conclusion:

The surviving count of the reference strains showed at least 4 lg reduction meaning that the ready to use product CHEMISEPT MED is effective against *A.brasiliensis* ATCC 16406 under clean and dirty conditions within 30 s.



.....  
Nata Aas-Valleriani  
Microiologist  
25.11.2019