Vaccine Scattering

Cessna 172S

SUPPLEMENT No.

Vaccine Scattering

Serial No.	Registration No.
172S9346	OK - ELN

complete AFM. this supplement is to be used in conjunction with the Scattering is installed. The information contained within the efficient operation of the airplane when the Vaccine This supplement supplies the information necessary for

Scattering is installed. must remain in this AFM at all times when the Vaccine This suplement is a permanent part of this AFM and

172S, is approved under the autority of DOA ref. EASA.21J.094 Revision No. NZ AE/160-DLP1 to AFM Supplement

Approved (CVE): Ing. Miroslav Mikel

Date: 20. 08. 2017

NZ AE/160-DLP1

August 20/17

1/4

August 20/17

CESSNA MODEL 172S

SECTION 9 SUPPLEMENTS

LOG OF APPROVED SUPPLEMENTS

NO.

SUPPLEMENT NAME

REVISION LEVEL EQUIPMENT INSTALLED

Vaccine Scattering

172S, is approved under the autority of DOA ref. EASA.21J.094 Revision No. NZ AE/160-DLP1 to AFM Supplement

Approved (CVE): Ing. Miroslav Mikel

Date: 20, 08, 2015

12

NZ AE/160-DLP1

Vratimovská 69/3 00 Ostrava - Ky DIČ: CZ471520

PILOT'S OPERATING HANDBOOK SUPPLEMENT

SECTION 9
SUPPLEMENTS

LOG OF REVISION

				Rev.
				Revised Pages
		ž		Description of Revision
				CAA Approved
(,	_/	Date

Intentionally left blank

Vratimovská 69/335
718 00 Ostrava Kunčicky
DIČ: CZ4/155086

CONFORM CU ORIGINALUL

2/2

2/4

NZ AE/160-DLP1

August 20/17

NZ AE/160-DLP1

August 20/17

CESSNA MODEL 172S

SUPPLEMENT PILOT'S OPERATING HANDBOOK

Vaccine Scattering

GENERAL - Not Affected SECTION 1

SECTION 2 LIMITATIONS

If the the dropping equipment is installed, the aeroplane must be operated in the NORMAL CATEGORY only.

The speed is to be kept between 80 -105 KIAS during the vaccine

application process. It is required that except for the pilot the dropping equipment

operator is on board of the plane as well.

EMERGENCY PROCEDURES - Not Affected SECTION 3

SECTION 4
NORMAL PROCEDURES - Not Affected

PERFORMANCE - Not Affected SECTION 5

WEIGHT & BALANCE/EQUIPMENT LIST - Not Affected SECTION 6

AIRPLANE & SYSTEMS DESCRIPTIONS SECTION 7

The dropping equipment for rabies vaccine scattering is installed. The dropping equipment operator sits on the right seat rotated be fastened. backwards during takeoff and landing. The operator's seat belts shall

August 20/15

Vratimovsk 69/35
718 00 Ostrava - Kurčičky
DIČ: CZ47155086

NZ AE/160-DLP1

3/4

Vaccine Scattering

PILOT'S OPERATING HANDBOOK SUPPLEMENT

The engine power setting – as required to keep the horizontal flight. The dropping equipment operator does not have to be fastened by seat belts during the dropping equipment operation.

SECTION 8 AIRPLANE HANDLING, SERVICE & MAINTENANCE Not Affected

SECTION 9
SUPPLEMENTS

Issued Vaccine Scattering supplement.

Vratimovská 69/335 718 00 Ostrava – Kunčičk DIČ: CZ47/65086

August 20/15

4/4

CONFORM CU ORIGINALUL

NZ AE/160-DLP1