



BY CLEAN ENDÜSTRİYEL BULAŞIK MAKİNESİ PARLATICI

TEKNİK BİLGİLER

ÖZELLİKLER	BİRİM	
Appearance	*	Berrak sıvı
Ph(20 ⁰ C)		1-2
Yoğunluk (20 ⁰ C)	g/cm ³	900-1,080 g/ml
Viskozite	⁰ C	yaklaşık 600-1000 mPa.s
Koku	-	Karakteristik
Çözünme	-	Su ile kolayca karışır.

DETAY BİLGİLER

PACKAGING	Available in 5lt, 20lt, and 30lt HDPE containers.
USAGE AREAS & FEATURES	<ul style="list-style-type: none">• Specially developed for use in automatic dishwashing machines in professional kitchens.• Highly effective rinse and shine agent.• Ensures dishes dry quickly and spot-free.• Leaves no residue on washed items.• Prevents limescale buildup and provides shine.• Prevents excessive foaming in the washing tank.• Effective in all water hardness levels.• Fragrance-free, leaves no scent on dishes.
STORAGE CONDITIONS & SHELF LIFE	<ul style="list-style-type: none">• Store in a cool and dry place with the container tightly closed.• Shelf life: 3 years unopened, 6 months after opening.• Transport: Carry the material in tightly closed drums or storage containers.• Storage: Keep in a cool place. Do not damage the label. Keep tightly closed and upright. Stack a maximum of 4 units.
PRODUCT USAGE	<ul style="list-style-type: none">• Used with liquid dosing pumps in industrial dishwashers.• Applied in the final rinse water of dishwashing machines.• Use 0.3-0.5 g per liter of water, depending on water hardness.• Dosage: 3-6 ml per 1 liter.• Dosage amount should be adjusted by the automatic dosing unit.• Rinse temperature should be at least 80⁰C and at most 90⁰C.
CONSUMER NOTICE	<ul style="list-style-type: none">• Always read the usage instructions.• Do not use for hand, face, body, or food cleaning.• Keep the container tightly closed.• Keep out of the reach of children.• In case of contact with skin, wash with plenty of water.• Do not inhale in its pure form.
HEALTH & SAFETY	✓ Relevant information is detailed in the product's MSDS (Material Safety Data Sheet), available upon request.

RULOPAK İSTANBUL - MERKEZ (HEADQUARTERS)

Adres

Yakuplu Bakırcılar Sanayi Sitesi, Orkide Cd. No:16 Beylikdüzü İSTANBUL / TÜRKİYE

Telefon

[+90 212 876 90 90](tel:+902128769090)

Faks

[+90 212 876 85 00](tel:+902128768500)

E-mail

info@rulopak.com

RULOPAK KIRAÇ FABRİKA

Adres

Osmangazi mahallesi 3144. Sk. No:5-6 Kiraç-Esenyurt/ istanbul

Telefon

[+90 212 876 90 90](tel:+902128769090)