









REPORT OF ANALYSIS No. L13764/22/JSHR

Client ECOCHIM-GRUP SRL OR. OTACI, STR. VOITOVICI 21		Sample description (according to declaration of Client) DEZINFECTANT UNIVERSAL BIO-DEZ
2059 CHIŞINĂU		Lot/Batch: -
		Production date: 28.01.2022 Expiration date: 28.01.2025 Sampling date: - Sampling quantity: 2 PCS X 1000 ML Sample temperature: 15°C Reception hour: 13:30 Responsible for sampling: CRESTINOV ALEXANDR
Sample received:	2022-02-10	Sample condition with no objections
Analysis completed (the date of performance of the laboratory activity):	2022-03-23	Order of 2022-02-09
Report dated:	2022-03-23	The samples were delivered by Client

Test	Method	Unit	Result
* Quantitative suspension test for the evaluation of bactericidal activity of chemical disinfectants and antiseptics ¹⁾	PN-EN 1276:2019-12		Product diluted to 80% and 50%, shows bactericidal activity at 60 seconds, 20°C, in dirty conditions (3,0g/L bovine albumin) at reference strains: Pseudomonas aeruginosa ATCC 15442, Escherichia coli ATCC 10536, Staphylococcus aureus ATCC 6538, Enterococcus hirae ATCC 10541.
Quantitative suspension test for the			Product diluted to 80% shows fungicidal activity at 60 seconds, 20°C, in dirty conditions (3,0g/L bovine albumin) at reference strains: Candida albicans ATCC 10231 and Aspergillus brasiliensis ATCC 16404.
evaluation of fungicidal or yeasticidal activity of chemical disinfectants and antiseptics ²⁾	PN-EN 1650:2008+A1:2013-08		Product diluted to 50% shows yeasticidal activity at 60 seconds, 20°C, in dirty conditions (3,0g/L bovine albumin) at reference strain: Candida albicans ATCC 10231. Product diluted to 50% does not show fungicidal activity at 60 seconds, 20°C, in dirty conditions (3,0g/L bovine albumin) at reference strain: Aspergillus brasiliensis ATCC 16404.

¹⁾ The results of the analysis in attachment No 1 to the report of analysis.

THE END OF THE REPORT

Authorized by: Sylwia Ziętek, Analyst Specialist, Cosmetics Microbiology Laboratory Approved by: Hanna Wachowska, Laboratory Director (Approved with electronic signature)

Laboratory: Tychy 43-100, Goździków 1

The results relate to the analysed samples only. Unless otherwise specified given expanded measurement uncertainty was estimated for the coverage factor k=2 at 95% confidence level. Sampling uncertainty has not been taken into consideration. Unless otherwise specified when conformity is stated J.S. Hamilton Poland Sp. z o.o. applies the simple acceptance decision rule in accordance with ILAC-G8:09/2019. This Report cannot be reproduced partially without a prior written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in original copy of the Report. The service confirmed by this Report is subject to the General Terms and Conditions of Services of J.S. Hamilton Poland Sp. z o.o. published on www.hamilton.com.pl

* Test method accredited; # Test performed by external provider

Page 1 / 1



²⁾ The results of the analysis in attachment No 2 to the report of analysis.



A) IDENTIFICATION OF THE SAMPLE	DEZINFECTANT UNIVERSAL BIO-DEZ
	Lot/Batch: -
	Production date: 28.01.2022
	Expiration date: 28.01.2025
Name of the product	Sampling date: -
·	Sampling quantity: 2 PCS X 1000 ML
	Sample temperature: 15°C
	Reception hour: 13:30
	Responsible for sampling: CRESTINOV ALEXANDR
	Ethyl alcool 72-76% CAS 64-17-5 CE 200-578-6
Active substance	Benzalkonium chloride 0,024-0,029% CAS 68424-85-1 CE 270-325-2
	Methylthioninium chloride 0,00024% CAS 61-73-4 CE 200-515-2
Aspect of the received product	Blue liquid in plastic clear container
B) TEST METHOD AND ITS VALIDATI	ON-
,	PN-EN 1276:2019-12
	Chemical disinfectants and antiseptics – Quantitative suspension test for the
Method	evaluation of bactericidal activity of chemical disinfectants and antiseptics
	used in food, industrial, domestic and institutional areas – Test method and
	requirements (phase 2, step 1)
Neutralizer	Sodium thiosulphate 3 g/l, polysorbate 80 30 g/l, lecithin 3 g/l
C) EXPERIMENTAL CONDITIONS	
Product test concentrations (%V/V)	0,01%, 50%, 80%
Aspect of product dilutions	80% and 50% blueish; 0,01% colourless
Test temperature	20°C
Contact time	60 seconds
Interfering substance	Dirty conditions: 3,0 g/l bovine albumin
Product diluent	Sterile hard water
Stability of the mixture (interfering	
substance and diluted product in	Stable
sterile hard water)	
Temperature of incubation	37±1°C
	Escherichia coli ATCC 10536
Identification of the bacterial and	Pseudomonas aeruginosa ATCC 15442
fungal strains used:	Staphylococcus aureus ATCC 6538
Ü	Enterococcus hirae ATCC 10541
	All controls and validation were between the basic limits.
	At least one concentration showed a log reduction lower than 5 log.
Special remarks	At least one concentration showed a log reduction higher than 5 log.
- F	No precipitate formed during the test procedure (the test mixtures were
	homogeneous).

Date: 23.03.2022

Authorized by: Sylwia Ziętek, Analyst Specialist, Cosmetics Microbiology Laboratory

Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.



TABLE 1. RESULTS OF THE TEST FOR BACTERICIDAL ACTIWITY OF THE PRODUCT

INTERFERING SUBSTANCE: 3,0 g/I BOVINE ALBUMIN - DIRTY CONDITIONS

CONTACT TIME: 60 seconds TEST TEMPERATURE: 20°C

PRODUCT TEST CONCENTRATIONS: 0,01%, 50%, 80%

criteria	300 ≤ N	v ≤ 16	600	30 ≤ Nv0 ≤	160	A ≥ 0,5*N _{v0}	acceptable	9	B ≥ 0,5*N _{v0}	acceptable		C ≥ 0,5*N _{v0}	acceptable	9
Enetrococcus hirae ATCC 10541		132	14	1 136	137	85	81	83	71	75	73	68	71	70
Pseudomonas aeruginosa ATCC 15442		114	10	110	110	77	76	77	63	61	62	55	59	57
Staphylococcus aures ATCC 6538		121	12	124	125	91	82	87	69	66	68	65	62	64
Escherichia coli ATCC 10536		115	11	117	117	88	85	87	77	71	74	63	66	65
	VC1	ν	/C2	Nv	Nvo	VC1	VC2	Α	VC1	VC2	В	VC1	VC1	С
TEST ORGANISIVI		VA		SUSPENSI	ON	,	VALIDATIO	NΑ	V	ALIDATION B		V	ALIDATION	С
TEST ORGANISM	1		1//11	DATION										

TEST ORGANISM				TEST SU	SPENSION			
	-6	-6	-7	-7	N	IgN	N ₀	IgN₀
Escherichia coli ATCC 10536	192	199	18	17	1,9E+08	8,29	1,9E+07	7,29
Staphylococcus aures ATCC 6538	169	166	15	16	1,7E+08	8,22	1,7E+07	7,22
Pseudomonas aeruginosa ATCC 15442	184	188	18	19	1,9E+08	8,27	1,9E+07	7,27
Enetrococcus hirae ATCC 10541	174	182	17	18	1,8E+08	8,25	1,8E+07	7,25
criteria	1,5*10 ⁸ ≤ N	≤ 5*10 ⁸	8,17 ≤ logN	≤ 8,70	1,5*107 ≤ N	5 ≤ 5*107	7,17 ≤ logN ₀	≤ 7,70

TEST ORGANISM				0,01%					50%					80%		
	N	VC1	VC2	Na	lg Na	lg R	VC1	VC2	Na	lg Na	lg R	VC1	VC2	Na	lg Na	lg R
Escherichia coli ATCC 10536	1,9E+08	>330	>330	>3300	>3,52	<3,75	0	0	<140	<2,15	>5,14	0	(<140	<2,15	>5,14
Staphylococcus aures ATCC 6538	1,7E+08	>330	>330	>3300	>3,52	<3,67	0	0	<140	<2,15	>5,07	0	(<140	<2,15	>5,07
Pseudomonas aeruginosa ATCC 15442	1,9E+08	>330	>330	>3300	>3,52	<3,77	0	0	<140	<2,15	>5,12	0	(<140	<2,15	>5,12
Enetrococcus hirae ATCC 10541	1,8E+08	>330	>330	>3300	>3,52	<3,74	16	17	165	2,22	5,03	0	(<140	<2,15	>5,10
criteria	lg R≥5															

Vc- number of cfu/ ml (one or two plates)

Nv- validation suspension

Nvo- Nv/10

A- validation of test conditions

B- neutralizer validation

C- validation dilution-neutralization

N- test suspension

No- N/10

Na- number of microorganisms cfu/ml in the test suspension

R- reduction No/Na

lg- logarithm 10

Date: 23.03.2022

Authorized by: Sylwia Ziętek, Analyst Specialist, Cosmetics Microbiology Laboratory

Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.



ENCLOSURE No. 2 TO REPORT OF ANALYSIS NO. L13764/22/JSHR

Name of the product	DEZINFECTANT UNIVERSAL BIO-DEZ
	Lot/Batch: -
	Production date: 28.01.2022
	Expiration date: 28.01.2025
	Sampling date: -
	Sampling quantity: 2 PCS X 1000 ML
	Sample temperature: 15°C
	Reception hour: 13:30
	Responsible for sampling: CRESTINOV ALEXANDR
Active substance	Ethyl alcool 72-76% CAS 64-17-5 CE 200-578-6
	Benzalkonium chloride 0,024-0,029% CAS 68424-85-1 CE 270-325-2
	Methylthioninium chloride 0,00024% CAS 61-73-4 CE 200-515-2
Aspect of the received	Blue liquid in plastic clear container
product B) TEST METHOD AND ITS VA	NUDATION
DJ 1E31 WEITIOD AND 113 VA	PN-EN 1650:2019-12 – Chemical disinfectants and antiseptics – Quantitative
	suspension test for the evaluation of fungicidal or yeasticidal activity of chemical
	disinfectants and antiseptics used in food, industrial, domestic and institutional areas
	- Test method and requirements (phase 2, step 1)
Neutralizer	Polisorbate 80- 30 g/l, saponin- 30 g/l, lecithin 3g/l
C) EXPERIMENTAL CONDITION	
Product test concentrations	0,01%, 50%, 80%
Aspect of product dilutions	80% and 50% blueish; 0,01% colourless
Test temperature	20°C
Contact time	60 seconds
Interfering substances	Dirty conditions: 3,0 g/l bovine albumin
Product diluent	Sterile hard water
Stability of the mixture	
(interfering substance and	
diluted product in sterile	Stable
hard water)	
Temperature of incubation	30°C ± 1°C
Identification of the	Candida albicans ATCC 10231
bacterial and fungal strains	Aspergillus brasiliensis ATCC 16404
used	
Special remarks	All controls and validation were between the basic limits.
-	At least one concentration showed a log reduction lower than 5 log.
	At least one concentration showed a log reduction higher than 5 log.
	No precipitate formed during the test procedure (the test mixtures were homogeneous).

Date: 23.03.2022

Authorized by: Sylwia Ziętek, Analyst Specialist, Cosmetics Microbiology Laboratory

Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.

Page 1 / 2 Form PO-10/05b of 20.01.2020



ENCLOSURE No. 2 TO REPORT OF ANALYSIS NO. L13764/22/JSHR

TABLE 1. RESULTS OF THE TEST FOR BACTERICIDAL ACTIWITY OF THE PRODUCT

INTERFERING SUBSTANCE: 3,0 g/I BOVINE ALBUMIN - DIRTY CONDITIONS

CONTACT TIME: 60 seconds TEST TEMPERATURE: 20°C

PRODUCT TEST CONCENTRATIONS: 0,01%, 50%, 80%

TEST ORGANISM		VALIDATION VALIDATION SUSPENSION			VALIDATION A			,	VALIDATION	IB	VALIDATION C		
	VC1	VC2	Nv	Nv ₀	VC1	VC2	A	VC1	VC2	В	VC1	VC1	С
Candida albicans ATCC 10231	126	121	1235	124	92	85	89	79	75	77	73	66	70
Aspergillus brasiliensis ATCC 16404	115	118	1165	117	88	83	86	81	72	77	71	78	75
criteria	300 <n<sub>v<16</n<sub>	00 30 <n<sub>v0<</n<sub>	160	acceptable	$A \ge 0,5^*N_{v0}$		acceptable	B ≥ 0,5*N _{v0}		acceptable	C ≥ 0,5*N _{v0}		acceptable

TEST ORGANISM				TEST SUS	SPENSION			
	-5	-5	-6	-6	N	lg N	N ₀	lg N₀
Candida albicans ATCC 10231	189	192	18	19	1,9E+07	7,28	1,9E+06	6,28
Aspergillus brasiliensis ATCC 16404	>165	>165	21	22	2,2E+07	7,33	2,2E+06	6,33
	1,5*10 ⁷ ≤ N :	≤ 5*10 ⁷	acceptable			1,5*10 ⁶ ≤ N ₀ :	≤ 5*10 ⁶	acceptable
criteria	7,17 ≤ lg N :	7,17 ≤ lg N ≤ 7,70 acceptable 6,17 ≤ lg N ₀ ≤ 6						acceptable

TEST ORGANISM	N		0,01%				50%				80%					
		VC1	VC2	Na	lg Na	lg R	VC1	VC2	Na	lg Na	lg R	VC1	VC2	Na	lg Na	lg R
Candida albicans ATCC 10231	1,9E+07	>330	>330	>3300	>3,52	<2,76	0	0	<140	<2,15	>4,13	0	0	<140	<2,15	>4,13
Aspergillus brasiliensis ATCC 16404	2,2E+07	>165	>165	>1650	>3,22	<3,11	>165	>165	>1650	>3,22	<3,11	2	5	<140	<2,15	>4,18
criteria	lg R≥4															

Vc- number of cfu/ ml (one or two plates)

Nv- validation suspension

Nvo- Nv/10

A- validation of test conditions

B- neutralizer validation

C- validation dilution-neutralization

N- test suspension

No- N/10

Na- number of microorganisms cfu/ml in the test suspension

R- reduction No/Na

lg- logarithm 10

Date: 23.03.2022

Authorized by: Sylwia Ziętek, Analyst Specialist, Cosmetics Microbiology Laboratory

Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.











REPORT OF ANALYSIS No. 136987/21/JSHR/Z2

Replaces Report of Analysis No. 136987/21/JSHR of 2021-04-14

Client ECOCHIM-GRUP SRL		Sample description (according to declaration of Client) DEZINFECTANT UNIVERSAL "BIO-DEZ"	
OR. OTACI, STR. VOITOVICI 21 2059 CHISINĂU		Sample quantity: 2 pcs x 1 L	
2000 (11)114/10		Production date: 26.01.2021	
		Expiration date: 26.01.2024	
		Sampling date: 22.02.2021	
		Sample temperature: 15°C	
		Reception hour: 15:00	
		Responsible for sampling: Crestinov Alexandr	
Sample received:	2021-03-18	Sample condition with no objections	
Analysis completed (the date of performance of the laboratory activity):	2021-04-14	Order of 2021-03-09	
Report dated:	2021-07-27	The samples were delivered by Client	

Test	Method	Unit	Result
* Chemical disinfectants and antiseptics - Hygienic handrub - Test method and requirements (phase 2, step 2) ¹⁾	PN-EN 1500:2013-07		The preparation has bactericidal effect against transient microorganisms used in the hygienic procedure of hand disinfection - a single rubbing of 3ml of the preparation for 60 seconds.

¹⁾ The results of the analysis in attachment No 1 to the report of analysis.

Identification of the change: test result

THE END OF THE REPORT

Authorized by:

Approved by: Hanna Wachowska, Laboratory Director (Approved with electronic signature)

Laboratory: Tychy 43-100, Goździków 1

The results relate to the analysed samples only. Unless otherwise specified given expanded measurement uncertainty was estimated for the coverage factor k = 2 at 95% confidence level. Sampling uncertainty has not been taken into consideration. Unless otherwise specified when conformity is stated J.S. Hamilton Poland Sp. z o.o. applies the simple acceptance decision rule in accordance with ILAC-G8:09/2019. This Report cannot be reproduced partially without a prior written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in original copy of the Report. The service confirmed by this Report is subject to the General Terms and Conditions of Services of J.S. Hamilton Poland Sp. z o.o. published on www.hamilton.com.pl

* Test method accredited; # Test performed by external provider

Page 1 / 1





A) IDENTYFICATION OF THE SA	MPLE:
Name of the product	DEZINFECTANT UNIVERSAL "BIO-DEZ"
	Sample quantity: 2 pcs x 1 L
	Production date: 26.01.2021
	Expiration date: 26.01.2024
	Sampling date: 22.02.2021
	Sample temperature: 15°C
	Reception hour: 15:00
	Responsible for sampling: Crestinov Alexandr
The active substance	Ethyl alcohol 72-76% CAS 64-17-5 CE 200-578-6
	Benzalkonium chloride 0,024-0,029% CAS 68424-85-1 CE 270-325-2
	Methylthioninium chloride 0,00024% CAS 61-73-4 and 200-515-2
B) TEST METHOD:	
Method	EN 1500:2013 Chemical disinfectants and antiseptics - Hygienic handrub - Test method and requirements (phase 2, step 2)
Neutralizer	Polysorbate 80 30 g/l, saponine 30g/l, histidine 1g/l, cysteine 1g/l
C) EXPERIMENTAL CONDITIONS	S:
Product test concentrations (%V/V)	100%
Test temperature	20°C
Contact time	3ml of the preparation for 60s
Incubation temperature	36±1 °C
Test-organism	E. coli K12 NCTC 10538

Date: 27.07.2021

Authorized by: Daria Depa, Senior Specialist Analyst, Cosmetics Microbiology Laboratory Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.



Table 1. PROCEDURE FOR REFERENCE HYGIENIC HANDRUB

PRODUCT: Standard 2-propanol 60% (V/V) TEST ORGANISM: *E. coli* K12 NCTC 10538

NUMBER IN CONTAMINATION FLUID: 2,4 x 10⁸ cfu/ml

VC	olunteer		r	number of cfu p	er plate from o	dilution 10x			
	Hand		prevalues			postva	lues		Reduction
Nr	left/right	x10 ⁻⁴	x10 ⁻⁵	log x	$x10^{0}$	x10 ⁻¹	x 10 ⁻²	log y	log z
	I	288	29		61	7	0		
1	r	247	22	6,42	33	3	0	1,65	4,77
	I	167	17		51	5	0		
2	r	291	28	5,81	36	4	0	1,63	4,18
	I	175	11		42	5	0		
3	r	275	25	6,33	29	2	0	1,54	4,79
	I	220	21		30	3	0		
4	r	192	19	6,31	68	6	0	1,65	4,66
	ĮI.	164	15		37	3	0		
5	r	301	33	6,35	52	5	0	1,64	4,71
_	I	200	20		23	2	0		
6	r	198	18	6,30	37	4	0	1,46	4,83
_	I	287	22		60	6	0		
7	r	288	29	6,45	42	5	0	1,70	4,75
_	ĮI.	298	28		31	4	0		
8	r	213	21	6,40	58	5	0	1,63	4,77
_	I	283	23		34	3	0		
9	r	311	33	5,96	51	5	0	1,62	4,34
	I	313	32		53	6	0		
10	r	251	25	6,45	36	4	0	1,65	4,80
44	II.	175	18	0.05	54	5	0	4.00	4.00
11	ir I	295	22	6,35	47	3	0	1,69	4,66
40		183	19	F 74	72	7	0	4 74	4.00
12	l r	171	17	5,74	36 29	4	0	1,71	4,03
10		206	22 33	6.44	29 49	2 5	0	1 57	4.04
13	I I	317 295	28	6,41	55	6	0	1,57	4,84
14		295	25 25	6,45	64	7	0	1 70	4,68
14	1	248	22	0,45	72	7	0	1,78	4,00
15	r	256	26	6,40	66	6	0	1,84	4,56
10	li	301	31	0,40	46	5	0	1,04	4,50
16	ľ	261	26	6,45	27	3	0	1,55	4,90
10		259	24	0,43	41	4	0	1,00	4,90
17	l'r	271	28	6,42	22	1	0	1,47	4,96
17	- li	259	22	0,72	61	6	0	1,77	7,50
18	r r	288	23	6,43	33	3	0	1,65	4,78
	li	223	21	0,10	35	4	0	1,00	1,70
19	l _r	205	20	6,33	45	5	0	1,60	4,72
	li	297	28	5,55	54	6	0	.,	-,,
20	r	257	24	5,90	28	3	0	1,59	4,31
X _{śr}				6,28				1,63	
S	\dashv			0,23				0,09	
3				0,23				0,09	0,20

log x-logarithm of the average value of the initial left and right hand

log y-logarithm of the average value of the final left and right hand

log z-logarithm reduction

x śr- overall average of log x, log y, log z

Date: 27.07.2021

Authorized by: Daria Depa, Senior Specialist Analyst, Cosmetics Microbiology Laboratory

Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.

Page 2 / 6



Table 2. HYGIENIC HANDRUB PROCEDURE WITH THE PRODUCT

PRODUCT P 136987/21/JSHR

TEST ORGANISM: E. coli K12 NCTC 10538

NUMBER IN CONTAMINATION FLUID: 2,4 x 108 cfu/ml

VO	lunteer			umber of cfu pe	er plate from o				
	Hand		prevalues			postva			Reduction
Nr	left/right	x10 ⁻⁴	x10 ⁻⁵	log x	$x10^{0}$	x10 ⁻¹	x 10 ⁻²	log y	log z
	I	132	14		103	11	1		
1	r	224	21	6,24	92	9	0	1,98	4,26
	I	>330	125		89	7	0		
2	r	304	31	6,27	78	4	0	1,68	4,59
	I	144	15		97	9	0		
3	r	132	11	6,14	78	5	0	1,93	4,21
	I	328	34		87	8	0		
4	r	>330	85	6,20	99	9	0	1,89	4,32
	I	164	11		116	11	2		
5	r	132	12	6,16	99	8	0	2,03	4,13
	I	>330	121		61	3	0		
6	r	320	32	6,27	83	9	0	1,67	4,60
	I	328	33		61	4	0		
7	r	288	29	6,49	71	7	0	1,81	4,68
	l l	>330	58		91	9	0		
8	r	>330	22	5,51	72	6	0	1,82	3,69
_	l l	336	36		79	8	0		
9	r	>330	21	5,90	106	12	2	1,96	3,94
	I	296	28		74	7	0		
10	r	>330	41	6,02	85	9	0	1,90	4,12
	l l	228	21		93	8	0		
11	r	104	11	6,19	80	5	0	1,93	4,26
	I	>330	48		107	11	1		
12	r	200	20	5,97	94	9	0	1,98	4,00
	ľ	248	25		112	14	2		
13	r	212	22	6,36	113	11	1	2,06	4,31
4.4		>330	48		89	8	0	4.05	4.07
14	ır	255	22	6,02	91	9	0	1,95	4,07
45	<u>'</u> .	278	28	0.04	99	7	0	4 77	4.57
15	ır	169	17 11	6,34	67	6	0	1,77	4,57
16		178 255		6 22	104 69	11 7	1 0	1.00	4.20
10	r	274	25 28	6,32	79	8	0	1,93	4,39
17		274	24	6.40	107	12	2	1.07	4 44
17	r	225	22	6,40	92	9	0	1,97	4,44
10	r			6 21	66	7		1 00	4 42
18	1	183 199	19 17	6,31	53	5	0	1,89	4,42
19	r	252	23	6,35	89	8	0	1,83	4,51
19	- 	266	22	0,33	97	9	0	1,03	4,51
20	r	231	21	6,39	68	7	0	1,91	4,48
	+	201		6,19	00]	/	- 0	1,89	4,48
Xśr	-								
S				0,22				0,10	0,25

 \log x-logarithm of the average value of the initial left and right hand \log y-logarithm of the average value of the final left and right hand

log z-logarithm reduction

x śr- overall average of log x, log y, log z

Date: 27.07.2021

Authorized by: Daria Depa, Senior Specialist Analyst, Cosmetics Microbiology Laboratory

Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.

Page 3 / 6



Table 3. LIST OF COMPUTED IG VALUES AND IG REDUCTIONS

volu	inteer	R 2-	propanol 60%	(V/V)		Р	
Nr		log x	log y	log z	log x	log y	log z
1	R-P	6,42	1,65	4,77	6,24	1,99	4,25
2	R-P	5,81	1,63	4,18	6,27	1,91	4,36
3	R-P	6,33	1,54	4,79	6,14	1,93	4,21
4	R-P	6,31	1,65	4,66	6,20	1,96	4,24
5	R-P	6,35	1,64	4,71	6,16	2,03	4,13
6	P-R	6,30	1,46	4,83	6,27	1,84	4,43
7	P-R	6,45	1,70	4,75	6,49	1,81	4,68
8	P-R	6,40	1,63	4,77	5,51	1,90	3,61
9	P-R	5,96	1,62	4,34	5,90	1,96	3,94
10	P-R	6,45	1,65	4,80	6,02	1,90	4,12
11	R-P	6,35	1,69	4,66	6,19	1,93	4,26
12	R-P	5,74	1,71	4,03	5,97	2,00	3,97
13	R-P	6,41	1,57	4,84	6,36	2,06	4,31
14	R-P	6,45	1,78	4,68	6,02	1,95	4,07
15	R-P	6,40	1,84	4,56	6,34	1,90	4,43
16	P-R	6,45	1,55	4,90	6,32	1,93	4,39
17	P-R	6,42	1,47	4,96	6,40	1,97	4,44
18	P-R	6,43	1,65	4,78	6,31	1,89	4,42
19	P-R	6,33	1,60	4,72	6,35	1,83	4,51
20	P-R	5,90	1,59	4,31	6,39	1,91	4,48
X 20		6,28	1,63	4,65	6,19	1,93	4,26
X10(R-P)		6,26	1,67	4,59	6,19	1,97	4,22
X10 (P-R)		6,31	1,59	4,72	6,20	1,90	4,30

Criteria:

Rs (R-P) = 4,59-4,22=0,37 Rs (P-R)= 4,72-4,30=0,42 Abs= 0,37-0,42=-0,05<2 logx(R)= 6,28>5

logx(P) = 6,19>5logz(P), logz(R) > 3

Validation conditions of neutralizer and methods have been satisfied

Date: 27.07.2021

Authorized by: Daria Depa, Senior Specialist Analyst, Cosmetics Microbiology Laboratory

Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.



Table 4. COMPUTATION OF INDIVIDUAL DIFFERENCES OF Ig R-P

volunteer	log	RF	difference	difference	
	R	Р	R-P	high to low	Range +/-
1	4,77	4,25	0,52	1,16	1
2	4,18	4,36	-0,18	0,68	2
3	4,79	4,21	0,59	0,61	3
4	4,66	4,24	0,42	0,59	4
5	4,71	4,13	0,58	0,58	5
6	4,83	4,43	0,40	0,53	6
7	4,75	4,68	0,07	0,52	7
8	4,77	3,61	1,16	0,52	8
9	4,34	3,94	0,40	0,51	9
10	4,80	4,12	0,68	0,42	10
11	4,66	4,26	0,40	0,40	11
12	4,03	3,97	0,06	0,40	12
13	4,84	4,31	0,53	0,40	13
14	4,68	4,07	0,61	0,36	14
15	4,56	4,43	0,13	0,21	15
16	4,90	4,39	0,51	0,13	16
17	4,96	4,44	0,52	0,07	17
18	4,78	4,42	0,36	0,06	18
19	4,72	4,51	0,21	-0,17	-19
20	4,31	4,48	-0,17	-0,18	-20
	sum of ranks	(+): 171			
	sum of ranks	(-): 39			

Table 5. SORTING OF INDIVIDUAL DIFFERENCES AND COMPUTATION FOR HODGES-LEHMANN 97,5% UPPER CONFIDENCE LIMITS FOR THE DIFFERENCE IN Ig BETWEEN R-P

	_									
_		1,16	0,68	0,61	0,59	0,58	0,53	0,52	0,52	0,51
1	1,16	1,16								
2	0,68	0,92	0,68							
3	0,61	0,89	0,65	0,61						
4	0,59	0,87	0,63	0,60	0,59					
5	0,58	0,87	0,63	0,59	0,58	0,58				
6	0,53	0,85	0,61	0,57	0,56	0,55	0,53			
7	0,52	0,84	0,60	0,57	0,56	0,55	0,53	-0,52		
8	0,52	0,84	0,60	0,56	0,55	0,55	0,53	-0,52	-0,52	
9	0,51	0,83	0,59	0,56	0,55	0,54	0,52	-0,52	-0,51	-0,51
10	0,42	0,79	0,55	0,52	0,50	0,50	0,48	-0,47	-0,47	-0,21
11	0,40	0,78	0,54	0,51	0,49	0,49	0,47	-0,46	-0,46	-0,20
12	0,40	0,78	0,54	0,51	0,49	0,49	0,47	-0,46	-0,46	
13	0,40	0,78	0,54	0,50	0,49	0,49	0,47	-0,46		
14	0,36	0,76	0,52	0,49	0,47	0,47	0,45			
15	0,21	0,69	0,45	0,41	0,40	0,39				
16	0,13	0,65	0,41	0,37	0,36					
17	0,07	0,62	0,38	0,34						
18	0,06	0,61	0,37							
19	-0,17	0,50								
20	-0,18									

Date: 27.07.2021

Authorized by: Daria Depa, Senior Specialist Analyst, Cosmetics Microbiology Laboratory

Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.

Page 5 / 6



Table 6. WILCOXON'S TMATCHED PAIRS SIGNED-RANKS TEST: CRITICAL VALUES LESS WITH RANG SUM (+) OR (-) AT DIFFERENT LEVELS OF SIGNIFICANCE

n	one-side	d level of sign	ificance
	0,05	0,025	0,01
18	47	40	32
19	53	46	27
20	60	52	43
21	68	59	49
22	75	66	56

For the designated level of significance 0,025 for n=20 the value read from the table 6 is 52.

Hence c = 52+1 = 53.

For the distribution of 53 Table 5 assigns a value of 0,55 which is less than the agreed inferiority margin of 0,6.

Therefore, the hypothesis of inferiority of PP compared to the reference RP is rejected.

The test preparation (PP) is non-inferior to RP.

Date: 27.07.2021

Authorized by: Daria Depa, Senior Specialist Analyst, Cosmetics Microbiology Laboratory

Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.



RAPORT DE INCERCARE NR. 79165/22/ROBCH/Z1

Inlocuieste Raportul de Incercare Nr. 79165/22/ROBCH din 07.03.2022

Client		Numărul eșantionului:	
ECOCHIM-GRUP SRL		Sample number	
OR. OTACI, STR. VOITOVICI 21		Descriere obiect de incercat (conform cu declaratia Clientului)	
2059 CHIŞINĂU		Dezinfectant Universal "Bio-Dez"	
		Lot/Batch: -	
		Production date: -	
		Expiration date: 18.02.2025	
		Sampling date: 18.02.2022	
		Sampling quantity: 1x 500ml	
		Sample temperature: 20°C	
		Reception hour: 12:30	
		Responsible for sampling: Crestinov Alexandr	
Entransi Halian va an Steath ena an Rosa a Union a cheantach na taoinn a t-aire an ann an an t-aire		Sample condition with no objections	
Data primirii obiectului de incercat:	07.03.2022		
Data finalizarii incercarii:	08.09.2022	Comanda din 07.03.2022	
Data eliberarii raportului:	08.09.2022	Probele au fost prelevate si livrate de catre Client.	

Parametrii de testare	Metoda de testare	Unitate de masura	Rezultat
# * Chemical disinfectants and antiseptics. Surgical hand disinfection. Test method and requirements (phase 2, step 2)	EN 12791:2016+A1:2017	1231	Test method performed by the subcontractor; the results are taken in full from the test report No S68/2022-1, issued by the subcontractor. The results of the analysis are listed starting with enclosure No1 to report of analysis.

Elaborat de: Mariana Ilinca, Sef Laborator Microbiologie Autorizat de: Mariana Ilinca, Sef Laborator Microbiologie

Aprobat de catre: Alina-Roxana Mihai, General Manager (Aprobat cu semnatura electronica)

Laborator: Bucuresti 041914, sos. Berceni nr.8

Responsabilitatea esantionarii/ prelevarii probelor apartine solicitantului. Rezultatele se refera numai la obiectul supus incercarii. Daca nu se specifica altfel, incertitudinea de masurare a fost estimata pentru coeficientul K= 2 si nivel de incredere 95%. Fara aprobarea scrisa a laboratorului acest raport de incercare nu poate fi reprodus decat integral. Responsabilitatea S.C. J.S. HAMILTON ROMANIA S.R.L. se refera exclusiv la rezultatele si declaratiile prezentate in raportul original. Opiniile si interpretarile continute in prezentul raport de incercare nu sunt acoperite de acreditarea RENAR. Pentru detalii suplimentare va rugam sa solicitati Certificatul de Acreditare la adresa de email bucharest@hamilton.com.pl

* Metoda de testare acreditata # Test efectuat de catre subcontractor

ø Incercari neacreditate Pagina 1 / 1 PGL 09 F 01 Ed. 1 Rev. 2



A) IDENTYFICATION OF THE SAMPLE	
Name of the product/Details about the product	Dezinfectant Universal "Bio-Dez"
	Date of manufacture: 18.02.2022
	Manufacturer: Ecochim-Grup SRL, Petricani St 21/3, Chişinău
	2059, Moldavsko
	Incoming date: 7.3.2022
	Storing conditions: room temperature, dark area.
	Subject of testing: Surgical handrub - immediate effect
	Active ingredients: CAS: 68424-85-
	Alkyldimethylbenzylamoniumchloride 0.029% CAS: 64-17-5 Ethyl
	alcohol 73.0%
B) TEST METHOD	
Performed in accredited subcontracted partner	Testing of disinfecting efficiency of chemical disinfecting and
laboratory: Scope of Accreditation No. 1273	antiseptic agents on carriers
Determination of surgical hand disinfection (EN	SOP-M-19-00 (EN 12791:2016+A1:2017)
12791:2016+A1:2017) of the product Dezinfectant	501 W 15 00 (ER 12751.2010 (M1.2017)
Universal "Bio-Dez"	
C) Description: Testing the efficacy of chemica	al disinfectants and antiseptics
Sampling date:	18.2.2022
Sample delivered:	7.3.2022
Testing date:	16.8 31.8.2022
D) EXPERIMENTAL CONDITIONS	
Effect:	immediate effect
Period of analysis:	16.08.2022 - 31.08.2022
Test temperature:	20 °C ± 1 °C
Test method:	dilution neutralization method
Appearance of the product:	Blue liquid
The test concentration:	100%
The volume of the product:	2 x 7 ml
The application time:	2 x 45 s
Procedure:	handrub
The soap:	soft soap from linseed oil
Reference item:	CAS 71-23-8 1-propanol p.a., 60% (V/V)
	person: 2 x 3 ml, according to reference surgical hand disinfection
procedure, the total application volume is 6 ml	person 2 in p min, were running to reference purgreun numbu unbinnernen
The application time:	2 x 1.5 min, according to reference surgical hand disinfection
11	procedure, the total application time is 3 min
Neutralization medium:	Dey-Engley Neutralizing Broth M 1062
Surgical hand disinfection procedure with product:	handrub procedure, immediate effect
Requirements:	The mean reduction for immediate effect of a product shall at least be
*	not inferior to that achieved by a specified reference product (60%)
	volume concentration of propan-1-ol). To demonstrate additionally a
	"sustained effect", the mean reduction for the 3 h effect of a product
	shall be superior to that achieved by the reference product
Test procedure:	1. Determination of the presence of microorganisms in the product
-	2. Determination of the prevalue – number of cfu sampled immediately
	before treatment from the hand
	3. Determination of the postvalue – number of cfu sampled after

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore. *Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

 $Tel.+40\ 21\ 634\ 10\ 81\ bucharest@hamilton.com.pl,\ www.hamilton.com.pl$

Enclosore no. 1 subcontracted tests



	treatment from the hand 4. Expression and interpretation of results - reduction factor - ratio of
	prevalue and postvalue, generally expressed by decimal logarithms
The standard:	EN 12791:2016+A1:2017 Chemical disinfectants and antiseptics –
	Surgical hand disinfection – Test method and requirements (phase
	2/step 2) November 2017

The number of CFU in the tested product: 0 CFU/ml

Testing the efficacy of chemical disinfectant L21229/22/JSHR on Pseudomonas aeruginosa ATCC 15442

Test suspensions

N	Vl	V2	lgN	lgN ₀	
10	192	170	ZWOM SALE	to senior	
10	27	15	8,26	7,26	
	3000	$\Phi = 1.84 \text{x} 10^8$	8.17 ≤ lgN ≤ 8.7	$7.17 < lgN_0 < 7.7$	

Verification of methodology

Va	lidation of suspension (Nvo)	Method valid (C), conditions: 80 %, 90 s, distilled water, 20°C			
Vol	31	V _{c3}	29		
V _{c2}	60	Va2	55		
	30 < 45,5 < 160	42 > 0.5 Nvo			

Testing the efficacy of chemical disinfectant L21229/22/JSHR on Staphylococcus aureus ATCC 6538

Test suspensions

N	Vl	V2	lgN	IgNo		
10-6	304	252	58	2270		
10-7	20	33	8,44	7,44		
G-555 X6	TENCA.	$\Phi = 2.77 \times 10^8$	8.17 < lgN < 8.7	7,17 < lgN ₀ < 7,7		

Verification of methodology

Validation of suspension (Nvo)			s: 80 %, 90 s, distilled water, 20°C	
Vel	69	Vel	72	
Ve2	53	V _{e2} 42		
	30 < 61 < 160		57 > 0.5 Nuo	

Testing the efficacy of chemical disinfectant L21229/22/JSHR on Enterococcus hirae ATCC 10541

Test suspensions

N	VI	V2	lgN	lgN_0		
10	166	192	학교조기 <i>가</i>	9554V		
10-7	18	21	8,26	7,26		
-002: 301	57.00	$\Phi = 1.8 \times 10^8$	8,17 < lgN < 8,7	$7.17 < \lg N_0 < 7.7$		

Verification of methodology

V	alidation of suspension (Nvo)	Method valid.(C), conditions: 80 %, 90 s, distilled water, 20°C				
Vel	52	Val	46			
V _{e2}	40	V ₂₂ 42				
	30 < 46 < 160	44 > 0.5 Nvo				

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



Testing the efficacy of chemical disinfectant L21229/22/JSHR on Escherichia coli K 12 NCTC 10538

Test suspensions

N	Vl	V2	lgN	lgN_0
10	>330	>330	33580	00T-86K
10-7	49	33	8,61	7,61
W15: 00		$\Phi = 4.1 \text{x} 10^8$	8.17 < lgN < 8.7	7,17 < lgNo < 7,7

Verification of methodology

Validation of suspension (Nvo)			tions: 80 %, 90 s, distilled water, 20°C
Vel	113	Val	103
Ve2	103	V _{c2}	110
	30 < 108 < 160		1065 > 05 Nvo

Testing the efficacy of chemical disinfectant L21229/22/JSHR on Candida albicans ATCC 10231

Test suspensions

N	Vl	V2	lgN	lgNo
10-5	155	144		
10 ⁻⁶	17	15	7,18	6,18
		$\Phi = 1.5 \text{x} 10^7$	$7.17 \le \lg N \le 7.7$	$7.17 \le \lg N_0 \le 7.7$

Verification of methodology

Validation of suspension (Nw)		Method valid.(C), cond	litions: 80 %, 90 s, distilled water, 20°C
Vel	41	Vel	21
Ve2	34	Ve2	28
30 < 37.5 < 160		St. Addition to	24,5 > 0,5 Nvo

Note: Vc = value is the number of cfu per ml, $\Phi = average\ Vc1\ a\ Vc2\ (1. + 2.\ duplicate\ Vc\ values)$, $N = the\ number\ of\ cfu/ml$ of the bacterial test suspension, $Nv_0 = the\ number\ of\ cfu/ml$ of the bacterial test suspension at the beginning of the contact time = 0, $C = the\ number\ of\ surviving\ bacteria\ per\ ml\ in\ control\ tests$

Acceptance criteria for test results:

Only if the results of the test procedure fulfil the following requirements, they shall be accepted for further evaluation, otherwise the test shall be repeated:

- a) A complete set of results from at least 23, but maximum 28 volunteers shall be available. All complete sets of results shall be used for further evaluation.
- b) The overall means of the 1g prevalues for RP and PP shall be both at least 3,50.
- c) The absolute difference of mean differences between lg reductions of RP and PP of group RP \rightarrow PP and group PP \rightarrow RP shall be less than 2,00
- d) All quotients of weighted mean counts between 5 and 15.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



ENCLOSORE NO. 1 SUBCONTRACTED TESTS TO REPORT OF ANALYSIS NO 79165/22/ROBCH Conclusion:

The acceptance criteria for the test results were met.

From table in EN 12791:2016+A1:2017 of critical values for Wilcoxon's matched-pairs signed-ranks test the entry for n = 24 and a one sided 0,025 level of significance, the critical value of 81 is found. Hence c = 81 + 1 = 82. The pairwise differences are sorted in descending order. The 82nd value is 0,59. Hence the Hodges-Lehmann upper one sided 97,5% confidence limit for the difference in 1g Rs between RP and PP is 0,59, which is less than the agreed inferiority margin of 0,75. Therefore the hypothesis of inferiority of PP is rejected and it can be concluded that the test preparation PP is non-inferior to RP.

The tested product: Dezinfectant Universal "Bio-Dez"

Batch number: Not specified

Standard: EN 12791:2016+A1:2017
Test method: dilution neutralization method

Effect: immediate effect

Conditions:

Application time: 2 x 45 s Volume of the product: 2 x 7 ml Concentration: 100%

The tested product is suitable to be used as surgical hand disinfection.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page 4 of 4

		immediate effect										
Volunteer	Chronological		Reference hand disi	nfection proced	ıre RP			Reference hand	Irub procedure v	with product PP		Difference
	Sequence	N prevalues	N postvalues	lg prevalues	lg postvalues	lg R	N prevalues	N postvalues	lg prevalues	lg postvalues	lg R	RP - PP
1	RP	7,30E+04	7,90E+02	4,86	2,90	1,96	6,40E+04	7,70E+02	4,81	2,89	1,92	0,04
2	RP	7,90E+04	6,60E+03	4,90	3,82	1,08	9,00E+04	1,00E+04	4,95	4,00	0,95	0,13
3	RP	7,10E+04	1,88E+03	4,85	3,27	1,58	1,06E+05	1,20E+03	5,03	3,08	1,95	-0,37
4	RP	7,90E+04	8,50E+02	4,90	2,93	1,97	5,80E+04	1,00E+02	4,76	2,00	2,76	-0,79
5	RP	9,60E+04	9,60E+03	4,98	3,98	1,00	8,90E+04	1,12E+04	4,95	4,05	0,90	0,10
6	RP	8,50E+04	2,44E+03	4,93	3,39	1,54	1,70E+04	6,70E+03	4,23	3,83	0,40	1,14
7	RP	7,70E+04	7,10E+03	4,89	3,85	1,04	1,02E+04	2,21E+03	4,01	3,34	0,67	0,37
8	RP	6,80E+04	3,80E+02	4,83	2,58	2,25	1,29E+05	9,30E+03	5,11	3,97	1,14	1,11
9	RP	5,60E+04	4,90E+03	4,75	3,69	1,06	8,30E+04	5,10E+03	4,92	3,71	1,21	-0,15
10	RP	7,10E+04	9,90E+03	4,85	4,00	0,85	7,60E+04	9,40E+03	4,88	3,97	0,91	-0,06
11	RP	1,02E+05	1,01E+04	5,01	4,00	1,01	6,90E+04	9,30E+03	4,84	3,97	0,87	0,14
12	RP	9,40E+04	1,07E+04	4,97	4,03	0,94	1,11E+05	1,24E+04	5,05	4,09	0,96	-0,02
13	PP	7,90E+04	2,91E+03	4,90	3,46	1,44	9,80E+04	7,80E+03	4,99	3,89	1,10	0,34
14	PP	9,10E+04	6,10E+03	4,96	3,79	1,17	7,80E+04	8,00E+03	4,89	3,90	0,99	0,18
15	PP	7,50E+04	3,08E+03	4,88	3,49	1,39	1,12E+04	1,56E+03	4,05	3,19	0,86	0,53
16	PP	5,20E+04	9,30E+02	4,72	2,97	1,75	1,10E+05	2,01E+02	5,04	2,30	2,74	-0,99
17	PP	8,50E+04	6,50E+03	4,93	3,81	1,12	1,02E+05	1,23E+04	5,01	4,09	0,92	0,20
18	PP	1,06E+04	2,04E+02	4,03	2,31	1,72	6,50E+03	7,50E+02	3,81	2,88	0,93	0,79
19	PP	8,00E+04	1,10E+03	4,90	3,04	1,86	1,68E+04	4,80E+02	4,23	2,68	1,55	0,31
20	PP	1,10E+05	6,00E+03	5,04	3,78	1,26	9,90E+04	8,60E+03	5,00	3,93	1,07	0,19
21	PP	6,30E+04	2,76E+02	4,80	2,44	2,36	8,70E+04	2,86E+03	4,94	3,46	1,48	0,88
22	PP	5,50E+04	4,40E+02	4,74	2,64	2,10	5,30E+04	7,10E+03	4,72	3,85	0,87	1,23
23	PP	1,18E+05	9,70E+02	5,07	2,99	2,08	8,20E+04	6,50E+03	4,91	3,81	1,10	0,98
24	PP	1,04E+05	7,60E+02	5,02	2,88	2,14	1,16E+05	1,35E+04	5,06	4,13	0,93	1,21
Ø	Overall	7,81E+04	3,94E+03	4,86	3,34	1,52	7,34E+04	6,14E+03	4,76	3,54	1,22	
S		2,23E+04	3,62E+03	0,20	0,55	0,48	3,68E+04	4,43E+03	0,38	0,61	0,59	
n				24	24	24			24	24	24	
Ø	$RP \rightarrow PP$			4,89	3,54	1,35			4,79	3,57	1,22	0,13
S				0,07	0,51	0,48			0,33	0,64	0,66	
n				12	12	12			12	12	12	
Ø	PP → RP			4,83	3,13	1,70			4,72	3,51	1,21	0,49
S				0,28	0,53	0,42			0,44	0,61	0,53	
n				12	12	12			12	12	12	

			Sorting of individua	l differences and	computation for	r Hodges-Lehma	n 97,5% upper c	onfidence limits	S				
	Sorted differences				Mean pairwise	differences (di	+dii)/2						
1	1,23	1,23											
2	1,21	1,22	1,21										
3	1,14	1,19	1,18	1,14									
4	1,11	1,17	1,16	1,13	1,11								
5	0,98	1,11	1,10	1,06	1,05	0,98							
6	0,88	1,06	1,05	1,01	1,00	0,93	0,88						
7	0,79	1,01	1,00	0,97	0,95	0,89	0,84	0,79					
8	0,53	0,88	0,87	0,84	0,82	0,76	0,71	0,66	0,53				
9	0,37	0,80	0,79	0,76	0,74	0,68	0,63	0,58	0,45	0,37			
10	0,34	0,79	0,78	0,74	0,73	0,66	0,61	0,57	0,44	0,36	0,34		
11	0,31	0,77	0,76	0,73	0,71	0,65	0,60	0,55	0,42	0,34	0,33	0,31	
12	0,20	0,72	0,71	0,67	0,66	0,59	0,54	0,50	0,37	0,29	0,27	0,26	0,20
13	0,19	0,71	0,70	0,67	0,65	0,59	0,54	0,49	0,36	0,28	0,27	0,25	0,20
14	0,18	0,71	0,70	0,66	0,65	0,58	0,53	0,49	0,36	0,28	0,26	0,25	
15	0,14	0,69	0,68	0,64	0,63	0,56	0,51	0,47	0,34	0,26	0,24		
16	0,13	0,68	0,67	0,64	0,62	0,56	0,51	0,46	0,33	0,25			
17	0,10	0,67	0,66	0,62	0,61	0,54	0,49	0,45	0,32				
18	0,04	0,64	0,63	0,59	0,58	0,51	0,46	0,42					
19	-0,02	0,61	0,60	0,56	0,55	0,48	0,43						
20	-0,06	0,59	0,58	0,54	0,53	0,46							
21	-0,15	0,54	0,53	0,50	0,48								
22	-0,37	0,43	0,42	0,39									
23	-0,79	0,22	0,21										
24	-0,99	0,12											

log R = decimal log reduction; RP \rightarrow PP sequence: first RP, second PP; PP \rightarrow RP sequence: first PP, second RP; \emptyset = mean; s = standard deviation; n = number of values (volunteer) Difference of mean Rs (RP \rightarrow PP): 1,35 - 1,22 = 0,13; Difference of mean Rs (PP \rightarrow RP): 1,70 - 1,21 = 0,49; Absolute difference of differences: |0,13-0,49|=0,36 The median is between the 12th and 13th value: |0,20+0,19|/2=0,195

The mean pairwise differences that do not exceed the median (here: 0,195) are computed. From table in EN 12791:2016+A1:2017 of critical values for Wilcoxon's matched-pairs signed-ranks test the entry for n = 24 ans a one-sided P = 0,025 level of significance, the critical value of 81 is found. Hence c = 81 + 1 = 82. The pairwise differences are sorted in descending order. The 82nd value is 0,59. Hence the Hodges-Lehmann upper one sided 97,5% confidence limit for the difference in Ig Rs between RP and PP is 0,59, which is less than the agreed inferiority margin of 0,75.

Therefore the hypothesis of inferiority of PP is rejected and it can be concluded that the test preparation PP is non-inferior to RP.

Propan-1-ol batch No.: K52972497115, expiry date 31.12.25

60%, 2 x 3 ml, 2 x 1,5 min, immediate effect, hand disinfection procedure

	Volunteer			Numb	er of CFU per p	plate from dilut	tion 10 ^x		
		Hand		Prevalues		Im	mediate postval	ues]
No	Sequence	(left or right)	-1	-2	-3	0	-1	-2	7
1	$RP \rightarrow PP$	1	>330	>330	<u>73</u>	>330	<u>79</u>	<14	_
2	$RP \rightarrow PP$	1	>330	>330	<u>79</u>	>330	>330	<u>66</u>	
3	$RP \rightarrow PP$	1	>330	>330	<u>71</u>	>330	<u>186</u>	<u>21</u>]
4	$RP \rightarrow PP$	1	>330	>330	<u>79</u>	>330	<u>85</u>	<14	
5	$RP \rightarrow PP$	1	>330	>330	<u>96</u>	>330	>330	<u>96</u>	
6	$RP \rightarrow PP$	1	>330	>330	<u>85</u>	>330	<u>241</u>	<u>27</u>	
7	$RP \rightarrow PP$	r	>330	>330	<u>77</u>	>330	>330	<u>71</u>	
8	$RP \rightarrow PP$	r	>330	>330	<u>68</u>	>330	<u>38</u>	<14	
9	$RP \rightarrow PP$	r	>330	>330	<u>56</u>	>330	>330	<u>49</u>	
10	$RP \rightarrow PP$	r	>330	>330	<u>71</u>	>330	>330	<u>99</u>	
11	$RP \rightarrow PP$	r	>330	>330	<u>102</u>	>330	>330	<u>101</u>	
12	$RP \rightarrow PP$	r	>330	>330	<u>94</u>	>330	>330	<u>107</u>	
13	$PP \rightarrow RP$	1	>330	>330	<u>79</u>	>330	<u>292</u>	<u>28</u>	
14	$PP \rightarrow RP$	1	>330	>330	<u>91</u>	>330	>330	<u>61</u>	
15	$PP \rightarrow RP$	1	>330	>330	<u>75</u>	>330	<u>306</u>	<u>33</u>	
16	$PP \rightarrow RP$	1	>330	>330	<u>52</u>	>330	<u>93</u>	<14	
17	$PP \rightarrow RP$	l	>330	>330	<u>85</u>	>330	>330	<u>65</u>	
18	$PP \rightarrow RP$	1	>330	<u>106</u>	<14	<u>201</u>	<u>23</u>	<14	
19	$PP \rightarrow RP$	r	>330	>330	<u>80</u>	>330	<u>110</u>	<14	
20	$PP \rightarrow RP$	r	>330	>330	<u>110</u>	>330	>330	<u>60</u>	
21	$PP \rightarrow RP$	r	>330	>330	<u>63</u>	<u>269</u>	<u>35</u>	<14	
22	$PP \rightarrow RP$	r	>330	>330	<u>55</u>	>330	<u>44</u>	<14	
23	$PP \rightarrow RP$	r	>330	>330	<u>118</u>	>330	<u>97</u>	<14	
24	$PP \rightarrow RP$	r	>330	>330	<u>104</u>	>330	<u>76</u>	<14	

Period of analysis: 16.8.2022 - 31.8.2022

16.8.-17.8.2022, 30.8.-31.8.2022

Prepared by: Mgr. Alena Holíková

Product Dezinfectant Universal "Bio-Dez"

100%, 2 x 7 ml, 2 x 45 s, immediate effect, handrub

	Volunteer		Number of CFU per plate from dilution 10^{x}								
		Hand		Prevalues		Im	mediate postvalı	ies			
No	Sequence	(left or right)	-1	-2	-3	0	-1	-2			
1	$RP \rightarrow PP$	r	>330	>330	<u>64</u>	>330	<u>77</u>	<14			
2	$RP \rightarrow PP$	r	>330	>330	<u>90</u>	>330	>330	<u>101</u>			
3	$RP \rightarrow PP$	ŗ	>330	>330	<u>106</u>	>330	<u>120</u>	<14			
4	$RP \rightarrow PP$	r	>330	>330	<u>58</u>	<u>99</u>	<14	<14			
5	$RP \rightarrow PP$	r	>330	>330	<u>89</u>	>330	>330	<u>112</u>			
6	$RP \rightarrow PP$	r	>330	<u>168</u>	<u>19</u>	>330	>330	<u>67</u>			
7	$RP \rightarrow PP$	1	>330	<u>102</u>	<14	>330	<u>216</u>	<u>27</u>			
8	$RP \rightarrow PP$	1	>330	>330	<u>129</u>	>330	>330	<u>93</u>			
9	$RP \rightarrow PP$	1	>330	>330	<u>83</u>	>330	>330	<u>51</u>			
10	$RP \rightarrow PP$	1	>330	>330	<u>76</u>	>330	>330	<u>94</u>			
11	$RP \rightarrow PP$	1	>330	>330	<u>69</u>	>330	>330	<u>93</u>			
12	$RP \rightarrow PP$	1	>330	>330	<u>111</u>	>330	>330	<u>124</u>			
13	$PP \rightarrow RP$	r	>330	>330	<u>98</u>	>330	>330	<u>78</u>			
14	$PP \rightarrow RP$	r	>330	>330	<u>78</u>	>330	>330	<u>80</u>			
15	$PP \rightarrow RP$	r	>330	<u>112</u>	<14	>330	<u>156</u>	<u>16</u>			
16	$PP \rightarrow RP$	r	>330	>330	<u>110</u>	<u>198</u>	<u>23</u>	<14			
17	$PP \rightarrow RP$	r	>330	>330	<u>102</u>	>330	>330	<u>123</u>			
18	$PP \rightarrow RP$	r	>330	<u>65</u>	<14	>330	<u>75</u>	<14			
19	$PP \rightarrow RP$	1	>330	<u>164</u>	<u>21</u>	>330	<u>48</u>	<14			
20	$PP \rightarrow RP$	1	>330	>330	<u>99</u>	>330	>330	<u>86</u>			
21	$PP \rightarrow RP$	1	>330	>330	<u>87</u>	>330	<u>284</u>	<u>31</u>			
22	$PP \rightarrow RP$	1	>330	>330	<u>53</u>	>330	>330	<u>71</u>			
23	$PP \rightarrow RP$	1	>330	>330	<u>82</u>	>330	>330	<u>65</u>			
24	$PP \rightarrow RP$	1	>330	>330	<u>116</u>	>330	>330	<u>135</u>			

Period of analysis: 16.8.2022 - 31.8.2022

16.8.-17.8.2022, 30.8.-31.8.2022

Prepared by: Mgr. Alena Holíková



REPORT OF ANALYSIS No. 80248/21/ROBCH

Client		Sample number:
ECOCHIM-GRUP SRL		80248/21/ROBCH
OR. OTACI, STR. VOITOVIC	121	Sample description (according to declaration of Client)
2059 CHIŞINĂU		DEZINFECTANT UNIVERSAL "BIO-DEZ"
		Lot: -
		Data fabricatie: 01.10.2021
		Data expirarii: 01.10.2024
		Data prelevarii: -
		Cantitate prelevata: 2 x 500 ml
		Responsabil prelevare: CRESTINOV ALEXANDR
		Ora receptiei probei: 15:30
6	144.0.004	Temperatura receptie proba: 15°C
Sample received:	11.10.2021	Sample condition with no objections
Tests performed:	21.10.2021	The state of the s
Tests completed:	13.12.2021	Order of 11.10.2021
Report dated:	13.12.2021	Sampling and delivery were carried out by client.

Test	Method	Unit	Result
# * Fungicidal activity in medical area. Chemical disinfectants and antiseptics. Quantitative suspension test for the evaluation of fungicidal or yeasticidal activity in the medical area. Test method and requirements (phase 2, step 1).	EN 13624:2014	ā	Test method performed by the subcontractor; the results are taken in full from the test report No D/21/B0644, issued by the subcontractor. The results of the analysis are listed starting with enclosure No1 to report of analysis.

Elaborated by: Mariana Ilinca, Manager of Microbiological Laboratory Authorized by: Mariana Ilinca, Manager of Microbiological Laboratory

Approved by: Alina-Roxana Mihai, General Manager (Approved with qualified electronic signature)

Laboratory: Bucuresti 041914, sos. Berceni nr.8

Responsabilitatea esantionarii/ prelevarii probelor apartine solicitantului. Rezultatele se refera numai la obiectul supus incercarii. Daca nu se specifica altfel, incertitudinea de masurare a fost estimata pentru coeficientul K= 2 si nivel de incredere 95%. Fara aprobarea scrisa a laboratorului acest raport de incercare nu poate fi reprodus decat integral. Responsabilitatea S.C. J.S. HAMILTON ROMANIA S.R.L. se refera exclusiv la rezultatele si declaratiile prezentate in raportul original. Opiniile si interpretarile continute in prezentul raport de incercare nu sunt acoperite de acreditarea RENAR. Pentru detalii suplimentare va rugam sa solicitati Certificatul de Acreditare la adresa de email bucharest@hamilton.com.pl

* Test method accredited # Test performed by external provider

ø Non accredited methods

Page 1 / 1





A) IDENTYFICATION OF THE SAMPLE	
Name of the product/Details about the product	DEZINFECTANT UNIVERSAL "BIO-DEZ"
Traine of the product Bethis dood the product	Expiration date: 01.10.2024.
	Manufacturer (supplier): Ecochim-Grup SRL.
	Storing conditions: Dry, without sun, 5-25 Celsius degree.
	Conditions of use: Hygienic handrub, surface disinfection,
	medical instruments disinfection, surgical handrub
Active compound/s and its concentration/s	Ethyl alcohol 72-76%, CAS 64-17-5 and CE 200-578-6. Benzalkonium chloride 0.024-0.029%, CAS 68424-85-1 and CE 270-325-2, Methylthionibium chloride 0.00024%, CAS 61-73-4 and 200-515-2
Concentrations requested for the assay	Pure (80%).
B) TEST METHOD	
Performed in accredited contracted partner	UNE-EN 13624:2014 Chemical disinfectants and antiseptics.
laboratory, Scope of Accreditation Nr. 648/LE1286	Quantitative suspension test for the evaluation of the fungicidal
Report Registration No. D/21/B0644	or yeasticidal activity in the medical area. Test method and
Quantitative evaluation assay of yeasticidal activity	requirements (phase 2, step 1). AENOR.
under dirty conditions, in the medical area (phase 2,	
step 1), with product Desinfectant Universal"Bio-	
Dez", (UNE-EN 13624: 2014 Standard).	
Testing method	Procedure DESIN-1058-b // EN 13624:2014
C) INFORMATION ABOUT SAMPLE REC	
Date of reception of order with test conditions	21.10.2021
Date of reception of the sample	25.10.2021
Aspect of the received product	Blue liquid in plastic package
D) METHOD OF ASSAY AND ITS VALIDA	TION (UNE-EN 13624: 2014 Standard)
Method used	Dilution-neutralization
Neutralizer	Tryptone 5 g/L, yeast extract 2.5 g/L, dextrose 10 g/L, sodium
	thioglycolate 1 g/L, sodium thiosulfate 1 g/L, sodium bisulphite
	2.5 g/L, soy lecithin 7 g/L, polysorbate-80 5 g/L, glycine 1 g/L,
	1-histidine 1 g/L and Saponin 30 g/L.
E) EXPERIMENTAL CONDITIONS	
Assay period	2021/11/08 to 2021/11/14.
Solvent of the product used in the assay	Sterile distilled water.
Product concentrations for the assay	Pure (80%), 50%, 0.1%
Aspect of the dilutions of the product	Pure (80%) and 50% blue liquid;
	0.1% transparent.
Contact time	60 seconds
Assay temperature	+20°C ± 1°C
Interfering substance	Bovine serum albumin 3 g/L and erythrocytes 3 mL/L.
Stability of the mixture (interfering substance and product diluted in sterile distilled water)	Stable
Temperature of incubation	+30°C± 1°C
Identification of the strain used	Candida albicans CECT-1394 (ATCC 10231)

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore. *Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page 1 of 3



ENCLOSORE NO. 1 SUBCONTRACTED TESTS TO REPORT OF ANALYSIS NO 80248/21/ROBCH Results of the assay

See tables 1 and 2. See table 3. Evaluation of yeasticidal activity......

Number of replicates per assay organism

Special remarks

- All controls and validation were between the basic limits.
- At least one concentration of the sample showed a log reduction lower than 4 log.
- At least one concentration of the sample showed a log reduction higher than 4 log.
- The highest concentration that can be assayed in the test (80%) is due to the mixtures to perform the assay.

1.

No precipitate formed during the test procedure (the test mixtures were homogeneous).

Conclusion

The product Desinfectant Universal"Bio-Dez", batch not indicated, when is pure (80%), shows yeasticidal activity after 60 seconds at 20°C ± 1°C, under dirty conditions (bovine serum albumin 3 g/L and erythrocytes 3 mL/L), for the reference strain Candida albicans (CECT 1394 = ATCC 10231), when tested as required by the UNE-EN 13624: 2014 Standard.

Note: The results obtained correspond to the sample received in the laboratory.

Quality Assurance Review:

The assay development and the results obtained have been supervised by the Director of the study.

The Quality Assurance Director has inspected the development of the assay, proving that has been realized following the proper procedure and using the adequate media, materials, and reagents, following the Good Laboratory Practices (GLPs) as well and the final report contains the primary data obtained.

Reference

UNE-EN 13624: 2014. Chemical disinfectants and antiseptics. Quantitative suspension test for the evaluation of the fungicidal or yeasticidal activity in the medical area. Test method and requirements (phase 2, step 1). AENOR.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



ENCLOSORE NO. 1 SUBCONTRACTED TESTS TO REPORT OF ANALYSIS NO 80248/21/ROBCH Results of the assay with *Candida albicans* (CECT 1394 = ATCC 10231).

Seeding: Pour plates. No. of plates: 1 /mL.

Table 1.-Validation and controls.

	ispensio idation (Control of experimental conditions (A)			Control of neutralizer (B)			Validation of the method (C) Sample concentration: Pure (80%)		
Vc_1	86	X= 90	Vc1	72	X= 74	Vc_1	75	X = 73	Vc1	66	X=
V_{C2}	94		Vc2	76	10	Vc2	71		Vc2	61	63.5
30 ≤ x	of Nv₀ ≤ Yes	≦ 160?			$x \text{ of } B \text{ es } \ge 0.5 X \text{ de}$ $Nv_0, \text{ or } 0.0005 Nv_B$? Yes			$x \text{ of } C \text{ es } \ge 0.5 X \text{ of}$ $Nv_0?$ $Y \text{ es}$			
	ispensio idation (Vc1:	79 1	Vc2: 77	30≤2	X=78 de Nv _E 160? Yes	3 a/1000 ≤			

Table 2. -Suspension of the assay.

- 11	N	Vc_1	Vc_2	$Xwm = 3.35 \times 10^7$
Suspension of assay (N and N ₀)	10-5	>330	>330	$\log N = 7.53$ $N_0 = N/10$
	10-6	32	35	$lg N_0 = 6.53$ 6.17 \le $lg N_0 \le 6.70$? Yes

Table 3.-Results of the activity assays with the sample.

Concentrations of the sample (%)	Dilutions steps	Vc1	Vc2	Lg Na = lg (X x 10 or Xmw x 10)	LgR (lg $N_0 = 6.53$)	Time of contact (seconds)	
D (000/)	Na ⁰	<14	<14	~2.15	>4.20	60	
Pure (80%)	Na ⁻¹	<14	<14	<2.15	>4.38	60	
500/	Na^0	<14	<14	-2.15	> 4.20	60	
50%	Na-1	<14	<14	<2.15	>4.38	60	
0.10/	Na ⁰	>330	>330	> 4.50	-0.01	20	
0.1%	Na-1	>330	>330	>4.52	<2.01	60	

Explanations:

Vc = number per mL (one or two plates); Xwm = ponderated mean of X.

 $X = \text{mean of Vc}_1$ and Vc_2 (duplicate of 1 + 2); R (reduction): ($\lg R = \lg N_0 - \lg N_0$).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



RAPORT DE INCERCARE NR. 1071/23/ROBCH/Z1

Inlocuieste Raportul de Incercare Nr. 1071/23/ROBCH din 02.03.2023

Client		Numărul eEantionului:
ECOCHIM-GRUP SRL		1071/23/ROBCH
STRADA PETRICANI 21/3		Descriere obiect de incercat (conform cu declaratia Clientului)
2059 CHIŞINĂU		Dezinfectant Universal "Bio-Dez"
		Lot: -
		Data fabricatie: 13.12.2022
		Data expirarii: 13.12.2025
		Data prelevarii: 13.12.2021
		Cantitate prelevata:500 ml
		Responsabil prelevare: Cristinov Alexandr
		Ora receptiei probei: 08:00
		Temperatura receptie proba: 15°C
	I	Sample condition with no objections
Data primirii obiectului de incercat:	11.01.2023	
Data finalizarii incercarii:	02.03.2023	Comanda din 11.01.2023
Data eliberarii raportului:	02.08.2023	Probele au fost prelevate si livrate de catre Client.

Parametrii de testare	Metoda de testare	Unitate de masura	Rezultat
# * Fungicidal activity in medical area. Chemical disinfectants and antiseptics. Quantitative suspension test for the evaluation of fungicidal or yeasticidal activity in the medical area. Test method and requirements (phase 2, step 1).	EN 13624:2014	1	Test method performed by the subcontractor; the results are taken in full from the test report No D/23/B0019, issued by the subcontractor. The results of the analysis are listed starting with enclosure No1 to report of analysis.

Responsabil incercare: Mariana Ilinca, Sef Laborator Microbiologie Validat de: Mariana Ilinca, Sef Laborator Microbiologie

Autorizat de: Alina-Roxana Mihai, General Manager (Aprobat cu semnatura electronica)

Laborator: Bucuresti 041914, sos. Berceni nr.8

Responsabilitatea esantionarii/ prelevarii probelor apartine solicitantului. Rezultatele se refera numai la obiectul supus incercarii. Daca nu se specifica altfel, incertitudinea de masurare a fost estimata pentru coeficientul K= 2 si nivel de incredere 95%. Fara aprobarea scrisa a laboratorului acest raport de incercare nu poate fi reprodus decat integral. Responsabilitatea S.C. J.S. HAMILTON ROMANIA S.R.L. se refera exclusiv la rezultatele si declaratiile prezentate in raportul original. Opiniile si interpretarile continute in prezentul raport de incercare nu sunt acoperite de acreditarea RENAR. Pentru detalii suplimentare va rugam sa solicitati Certificatul de Acreditare la adresa de email bucharest@hamilton.com.pl

st Metoda de testare acreditata # Test efectuat de catre subcontractor

Pagina 1/1 ø Incercari neacreditate PGL 09 F 01 Ed. 1 Rev. 3

J.S. Hamilton Romania S.R.L.
Sos.Berceni nr.8, sector 4, 041902 Bucuresti, Romania, Tel.+40 21 634 10 81



A) IDENTYFICATION OF THE SAMPLE	
Name of the product/Details about the product	Dezinfectant Universal "Bio-Dez" Manufacturer(supplier): Ecochim-Grup Condition of use: Instrument disinfection, surface disinfection without mechanical action textile disinfection
Solvent of the product recommended by the manufacturer	Not indicated
Active(S) substance (S) and its concentration(s)	Ethyl alcool 72-76%, CAS 64-17-5 and CE 200-578-6 Benzalkonium chloride 0.024-0.029%, CAS 68424-85-1 and CE 270-325-2 Methylthionibium chloride 0.00024%, CAS 61-73-4 and 200-515-2.
Concentrations requested for the assay	80% and 97%.
B) TEST METHOD	
Performed in accredited subcontracted partner laboratory: Scope of Accreditation Nr. 648/LE1286 Report no.: D/23/B0019 and D/23/B0413- Quantitative evaluation assay of fungicidal activity in Medicine (phase 2, step1), with the product "Dezinfectant Universal "Bio-Dez". (EN 13624: 2022 Standard)	EN 13624: 2022. Chemical disinfectants and antiseptics. Quantitative suspension test for the evaluation of the fungicidal or yeasticidal activity in the medical area. Test method and requirements (phase 2, step 1).
Testing method	EN 13624: 2022
Method	Dilution-neutralization
Neutralizer	Tryptone 5 g/L, yeast extract, 2.5 g/L, dextrose 10g/L, sodium thioglycolate 1g/L, sodium thiosulfate 1g/L, sodium bisulfide 2.5 g/L, soya lecithin 7 g/L, polysorbate-80 5 g/L, glycine 1 g/L, l-histidine 1 g/L and saponin 30 g/L.
C) INFORMATION ABOUT SAMPLE RECEPTION	1 0
Date of reception of the sample	2023/01/13
Date of reception of order with test conditions	2023/01/16.
Date of reception of order with test conditions (test at 97%)	2023/06/14
Aspect of the received product	Blue liquid in plastic package
D) EXPERIMENTAL CONDITIONS	
Assay period	2023/02/08 to 2023/02/17 (test at 80%). 2023/07/05 to 2023/07/15 (test at 97%).
Solvent of the product used in the assay	Sterile distilled water (test at 80%). Not applicable (test at 97%).
Product concentrations for the assay	First test: 80%, 50% and 0.1% Second test: 97%.
Aspect of the dilutions of the product	97%, 80% and 50% blue liquid; 0.1% transparent liquid.
Contact time	90 seconds
Assay temperature	+20°C ± 1°C
Interfering substance	Bovine serum albumin 3 g/L plus erythrocytes 3 mL/L.
Stability of the mixture (interfering substance and product	Formation of flocs at 97% concentration and stable at
diluted in sterile distilled water)	80%, 50% and 0,1%.
Temperature of incubation	+30°C ± 1°C
Identification of the origin of viral stains and number of passes	-Aspergillus brasiliensis (CECT 2574 = ATCC 16404) Candida albicans (CECT 1394 = ATCC 10231).
Passes	(CECT 13) 1 111 CC 10231).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



Results of the assay

Special remarks

- All controls and validation were between the basic limits.
- For a valid test, at least one concentration must show a log reduction equal or higher than 4 log.
- Formation of flocs has been observed when mixed the product at 97% with the interference substance and the inoculum.
- No precipitate formed during the test procedure (test mixtures at 80%, 50 % and 0.1% were homogeneous).

Conclusion

The product Dezinfectant Universal "Bio-Dez", batch 1071/23//ROBCH, at 80% does not show fungicidal activity, after 90 seconds at 20°C ±1°C, under dirty conditions (bovine serum albumin 3 g/L and erythrocytes 3 mL/L), because it does not show activity against Aspergillus brasiliensis (CECT 2574 = ATCC 16404) although it shows activity against Candida albicans (CECT 1394 = ATCC 10231), when tested as required by the EN 13624: 2022 Standard.

The product Dezinfectant Universal "Bio-Dez", batch 1071/23/ROBCH, at 80% shows yeasticidal activity, after 90 seconds at 20°C ±1°C, under dirty conditions (bovine serum albumin 3 g/L and erythrocytes 3 mL/L), for the strain Candida albicans (CECT 1394 = ATCC 10231), when tested as required by the EN 13624: 2022 Standard.

The product **Dezinfectant Universal "Bio-Dez"**, batch 1071/23/ROBCH, at 97% concentration requested by the client, shows fungicidal activity, after 90 seconds at 20°C ±1°C, under dirty conditions (bovine serum albumin 3 g/L plus erythrocytes 3ml/L), against the reference strains *Aspergillus brasiliensis* (CECT 2574 = ATCC 16404) and *Candida albicans* (CECT 1394 = ATCC 10231), when tested as required by the EN 13624: 2022 Standard.

Note: The results obtained correspond to the sample received in the laboratory.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay with Aspergillus brasiliensis (CECT 2574 = ATCC 16404).

First test at 80%.

Seeding: Pour plates. No. of plates: 4/mL.

Table 1.-Validation and controls.

	spension dation (A		Control of experimental conditions (A)		Control of the neutralizer (B)			Validation of the method (C) Sample concentration: 80%			
Vc1	72	X=	Vc1	68	X=	Vc1	61	X =	Vc1	63	X=
Vc2	78	75	Vc2	66	67	Vc2	65	63	V_{C2}	69	66
30 ≤ <i>X</i>	of Nvo: Yes	≤ 160?	17000 TOURS - 17000 TOURS - 17000 TOURS		$X \text{ of } B \text{ es} \ge 0.0005$ Nv_B ? Yes		$X \text{ of } C \text{ is } \ge 0.5x$ $X \text{ of } Nv_0$? Yes				
	pension lation (A 10 LET 14 TO 1	Vc ₁ : 7	9	Vc2: 76	X = 77.5 $30 \le X \text{ de } Nv_B/10$ 160? Yes		/1000 ≤			

Table 2.-Suspension of the assay.

	N	Vc_1	V_{C2}	$Xwm = 2.94 \times 10^7$
Suspension of assay (N and N_{θ})	10-5	291	297	lgN = 7.47 $N_0 = N/10$
	10-6	29	30	$lg N_0 = 6.47$ $6.17 \le lg N_0 \le 6.70$?; Yes

Table 3.- Results of the activity test with the sample.

Concentrations of the sample (%)	Dilutions steps	Vc_1	Vc2	$Lg Na = lg$ $(X \times 10 \text{ o}$ $Xwm \times 10)$	Lg R (Lg N ₀ =6.47)	Time of contact (seconds)	
D (00.0/)	Na ⁰	>660	>660	4.05	2.42	00	
Pure (80 %)	Na ⁻¹	115	108	4.05	2.42	90	
50 %	Na^0	>660	>660	>4.00	-1 65	00	
30 %	Na ⁻¹	>660	>660	>4.82	<1.65	90	
0.10/	Na ⁰	>660	>660	>4.00	-1 65	00	
0.1 %	Na ⁻¹	>660	>660	>4.82	<1.65	90	

Explanations:

Vc = number per mL (one or two plates); Xwm = ponderated mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1 + 2); R(\text{reduction}): (\lg R = \lg N_0 - \lg N_0).$

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



ENCLOSORE NO. 1 SUBCONTRACTED TESTS TO REPORT OF ANALYSIS NO 1071/23/ROBCH/Z1 Counts per plate:

(N)
$$10^{-5} = 70 + 73 + 74 + 74$$
; $71 + 75 + 76 + 75$; $10^{-6} = 6 + 7 + 8 + 8$; $8 + 7 + 7 + 8$;

Product:

Pure (80%)
$$\rightarrow$$
 Na⁻¹ 28 + 27 + 31 + 30; 27 + 28 + 26 + 27;
50% \rightarrow Na⁻¹ = >165 + >165 + >165 + >165; >165 + >165 + >165 + >165;
0.1% \rightarrow Na⁻¹ = >165 + >165 + >165 + >165; >165 + >165 + >165 + >165;
 $A = 17 + 16 + 18 + 17$; 17+16+16+17;
 $B = 15 + 16 + 15 + 15$; 16+15+16+18;
 $C = 15 + 16 + 16 + 16$; 17+18+16+18;
 $N_{V0} = 18 + 17 + 19 + 18$; 19+20+20+19;
 $N_{VB} = 19 + 20 + 20 + 20$; 19+19+19+19;

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. \emptyset Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay with Aspergillus brasiliensis (CECT 2574 = ATCC 16404). Second test at 97%.

Seeding: plate pouring; No. of plates: 4/mL.

Table 1.-Validation and controls.

	spension dation (Control orimenta		A 1000	ntrol of itralizer	2-000	Validation of the method (C) Sample concentration: 97%			
Vc1	101	X=	Vc_1	80	X=	Vc1	85	X =	Vc1	80	X=	
Vc2	100	100.5	Vc2	82	2007 0		82	83.5	Vc2	82	81	
30 ≤ <i>X</i>	30 ≤ X of N _{V0} ≤ 160? Yes		$X \text{ of } A \text{ is } \ge 0.5x$ $X \text{ if } Nv_0$? Yes			13 2 4 0 0 0 0 4 3 0	Bes≥ (Vv _B ? Ye		100	of C is 2 of Nv ₀ ?		
Suspension of validation (Nv _B)		Vc ₁ : 1	02 V	c ₂ : 102	30 ≤ X	X = 100 de Nv_B 160? Ye	/1000 ≤					

Table 2.-Suspension of the assay.

	N	Vc_1	V_{C2}	$Xwm = 1.99 \times 10^8$
Suspension of assay (N and N_{θ})	10-6	199	200	lgN = 8.30 $N_0 = N/10$ $lg N_0 = 7.30$
	10-7	19	20	7.17 ≤ lgN ₀ ≤ 7.70?; Ye

Table 3.- Results of the activity test with the sample.

Concentrations of the sample (%)	Dilutions steps	Vc1	Vca	$Lg Na = lg$ $(X \times 10 \text{ o}$ $Xwm \times 10)$	Lg R (Lg No=7.30)	Time of contact (seconds)
	Na ⁰	<14	<14	1	8	
97%	Na ⁻¹	<14	<14	<2.15	>5.15	90
	Na ⁻²	<14	<14		20.83745/0 M. 10	186-0365

Explanations:

Vc = number per mL (one or two plates); Xwm = ponderated mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1+2); R(\text{reduction}): (\lg R = \lg N_0 - \lg Na).$

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



Counts per plate:

(N)
$$10^{-6} = 48 + 52 + 50 + 49$$
; $49 + 50 + 51 + 50$; $10^{-7} = 4 + 5 + 5 + 5$; $4 + 5 + 6 + 5$.

Sample:

$$97\% = Na^0 = 0 + 0 + 0 + 0; 0 + 0 + 0 + 0;$$

$$A = 19 + 20 + 22 + 19$$
; $21 + 20 + 22 + 19$; $B = 24 + 20 + 21 + 20$; $19 + 21 + 22 + 20$; $C = 20 + 21 + 20 + 19$; $20 + 22 + 20 + 20$; $N_{V0} = 28 + 26 + 24 + 23$; $25 + 24 + 26 + 25$; $N_{VB} = 27 + 24 + 26 + 25$; $25 + 24 + 27 + 26$.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page 6 of 8

Date: 02.08.2023

Authorized by: Mariana Ilinca, Manager of Microbiological laboratory

Aprobat de: Mihai Alina-Roxana, General manager (Approved with qualified electronic signature)



Results of the assay with Candida albicans (CECT 1394 = ATCC 10231).

First test at 80%.

Seeding: Pour plates. No. of plates: 1 /mL.

Table 4.-Validation and controls.

	spension dation (I	Circle Control	ex	ontrol perimenditions	ntal	50000	entrol of utralizer	14-12-4	Validation of the method (C) Sample concentration: 80%			
Vc1	96	X=	Vc1	83	X=	Vc1	87	X =	Vc1	82	X=	
Vc2	100	98	Vc2	89	86	Vc2	100	93.5	V_{C2}	85	83.5	
30 ≤ <i>X</i>	of Nv ₀ : Yes	≤ 160?		f <i>A</i> is ≥ f <i>Nv</i> ₀ ?			$X \text{ of } B \text{ es } \ge 0.0005$ Nv_B ? Yes			$X \text{ of } C \text{ is } \ge 0.5x$ $X \text{ of } Nv_0$? Yes		
Suspension of validation (Nv _B)		Vc ₁ : 8	85 J	′c₂: 87	F-1350-00-00-00	X = 86 de Nv_B 160? Ye	/1000 ≤					

Table 5. -Suspension of the assay.

	N	Vc1	Vc2	$Xwm = 3.65 \times 10^7$
Suspension of assay (N and No)	10-5	>330	>330	lg N = 7.56 $N_0 = N/10$
SM - SM	10-6	38	35	$\lg N_0 = 6.56$ 6.17 $\leq \lg N_0 \leq$ 6.70? Yes

Table 6.-Results of the activity assays with the sample.

Concentrations of the sample (%)	Dilutions steps	Va	Vc2	Lg Na = 1g (X x 10 o Xwm x 10)	Lg R (Lg No=6.56)	Time of contact (seconds)	
D (00.04)	Na ⁰	<14	<14		(Activities)	700	
Pure (80 %)	Na-1	<14	<14	<2.15	>4.41	90	
50.0/	Na^0	>330	>330	2.04	2.62	-00	
50 %	Na ⁻¹	88	87	3.94	2.62	90	
0.1.0/	Na ⁰	>330	>330	~ 4.50	~~~	-00	
0.1 %	Na ⁻¹	>330	>330	>4.52	<2.04	90	

Explanations:

Vc = number per mL (one or two plates); Xwm = ponderated mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1+2); R \text{ (reduction): } (\lg R = \lg N_0 - \lg N_0).$

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay with Candida albicans (CECT 1394 = ATCC 10231). Second test at 97%.

Seeding: plate pouring; No. of plates: 1/mL.

Table 4.-Validation and controls.

		sion of n (Nv ₀)	ex	Control perimenditions	ntal	1,500	ontrol o utralize	The Control of the Co	Validation of the method (C) 97%			
Vc1	89	X = 87	Vc1	80	X=	Vc1	81	X=	Vc1	80	X=	
V_{C2}	85		Vc2	79	79.5	Vc2	83	82	Vc2	76	78	
$30 \le X \text{ of } Nv_0 \le 160$?			X of A is $\geq 0.5 \times X$ of N_{10} ? Yes			0.740.3002-050	A STATE OF THE STA	5 x X of)5 Nv _B ?	X of C	is ≥ 0.: Nvo? Yes	5 x X of	
Suspension of validation (NvB)		Vc1:	87 I	°c2: 89	1	X = 88 de Nv _E 160? Y	2/1000 ≤	0				

Table 5. -Suspension of the assay.

value of the second	N	Vc1	Vc_2	$Xwm = 4.95 \times 10^8$
Suspension of assay (N and N ₀)	10-6	>330	>330	lg N = 8.69 $N_0 = N/10$
and separate in a service of the ser	10-7	51	48	$lg N_0 = 7.69$ 7.17 $\leq lg N_0 \leq 7.70$? Yes

Table 6.-Results of the activity assays with the sample.

Concentrations of the sample (%)	Dilutions steps	Vc1	Vcı	$Lg Na = lg$ $(X \times 10 \text{ o}$ $Xwm \times 10)$	Lg R (Lg No=7.69)	Time of contact (seconds)
	Na ⁰	<14	<14	di .		
97%	Na ⁻¹	<14	<14	<2.15	>5.54	90
	Na-2	<14	<14] .		

Explanations:

Vc = number per mL (one or two plates); Xwm = ponderated mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1+2); R \text{ (reduction): } (\lg R = \lg N_0 - \lg N_0).$

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



ENCLOSURE No. 1 TO REPORT OF ANALYSIS NO. L21206/22/JSHR

A) IDENTIFICATION OF THE SAMPLE							
_	Dezinfectant Universal "Bio-Dez"						
	Lot/Batch: -						
	Production date: -						
	Expiration date: 18.02.2025						
Name of the product	Sampling date: 18.02.2022						
·	Sampling quantity: 1x 500ml						
	Sample temperature: 20°C						
	Reception hour: 12:30						
	Responsible for sampling: Crestinov Alexandr						
	Ethyl alcool 72-76%, CAS 64-17-5 and CE 200-578-6						
Active substance	Benzalkonium chloride 0,024-0,029%, CAS 68424-85-1 and CE 270-325-2						
	Methylthionibium chloride 0,00024%, CAS 61-73-4 and CE 200-515-2						
B) TEST METHOD AND ITS VALIDATION	ON						
	PN-EN 13697+A1:2019-08						
	Chemical disinfectants and antiseptics – Quantitative non-porous						
	surface test for the evaluation of bactericidal and/or fungicidal activity						
Method	of chemical disinfectants used in food, industrial, domestic and						
	institutional areas – Test method and requirements without						
	mechanical action (phase 2, step 2)						
Neutralizer	Polisorbate 80- 30 g/l, saponine- 3 g/l, cysteine- 1g/l, histidine- 1g/l,						
	sodium thiosulfate 7,5g/l						
C) EXPERIMENTAL CONDITIONS	Ţ						
Product test concentrations (%V/V)	0,01%, 50%, 100%						
Test temperature	20°C+/-1°C						
Contact time	60 seconds bacteria						
Interfering substance	Dirty conditions: 3,0g/l bovine albumin						
Product diluent	Sterile hard water						
Temperature of incubation	36±1°C bacteria						
Identification of the bacterial and	Pseudomonas aeruginosa ATCC 15442						
fungal strains used:	Escherichia coli ATCC 10536						
rangar strains asca.	Staphylococcus aureus ATCC 6538						
	Enterococcus hirae ATCC 10541						
	Litter occoccus fill de ATCC 103-11						

Date: 13.04.2022

Authorized by: Daria Depa, Senior Specialist Analyst, Cosmetics Microbiology Laboratory Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.



ENCLOSURE No. 1 TO REPORT OF ANALYSIS NO. L21206/22/JSHR

TABELE nr 1: RESULTS OF BACTERICIDAL/FUNGICIDAL ACTIVITY TESTS OF THE PREPARATION

INTERFERING SUBSTANCE: 3,0g/I BOVINE ALBUMIN - DIRTY CONDITIONS

CONTACT TIME: 60 seconds bacteria TEST TEMPERATURE: 20°C +/-1°C

PRODUCT TEST CONCENTRATIONS: 0,01%, 50%, 100%

	В.	BACTERIAL/FUNGAL TEST SUSPENSION : N					VALIDATION NT				VALIDATION NC				
TEST ORGANISM	DILUTION	VC1	VC2	AVERAGE	N	DILUTION	VC1	VC2	AVERAGE	NT	DILUTION	VC1	VC2	AVERAGE	NC
Pseudomonas aeruginosa ATCC 15442	1,00E-07	189	185	185	7,66	1E-04	82	81	82	6,91	1E-04	72	77	75	6,87
	1,00E-08	14	18												
Escherichia coli ATCC 10536	1,00E-06	163	166	164	6,61	1E-04	77	73	75	6,88	1E-04	66	69	68	6,83
	1,00E-07	14	17												
Staphylococcus aureus ATCC 6538	1,00E-06	158	162	159	6,60	1E-04	72	76	74	6,87	1E-04	78	77	78	6,89
	1,00E-07	15	14												
Enterococcus hirae ATCC 10541	1,00E-06	172	181	174	6,64	1E-04	81	88	85	6,93	1E-04	83	78	81	6,91
	1,00E-07	14	16						1						

	WATER CONTROL N _C											
TEST ORGANISM	DILUTION	VC1	VC2	AVERAGE	Nc	Nts						
Pseudomonas aeruginosa ATCC 15442	1E-04	115	121	118	7,07	>100						
Escherichia coli ATCC 10536	1E-04	114	105	110	7,04	>100						
Staphylococcus aureus ATCC 6538	1E-04	106	102	104	7,02	>100						
Enterococcus hirae ATCC 10541	1E-04	112	115	114	7,05	>100						

 $NC-N_C \le \pm 0.3 \log$

Bacteria 6,57≤ N ≤ 7,10 Nc>4 log P.aeruginosa clean conditions 7,57≤ N ≤ 8,10

	TEST PROCEDURE FOR CONCETRATIONS % (V/V)																				
	0,01%						50%							100%							
TEST ORGANISM	DILUTION	VC1	VC2	AVERAGE	Nd	R=Nc-Nd	Nts	DILUTION	VC1	VC2	AVERAGE	Nd	R=Nc-Nd	Nts	DILUTION	VC1	VC2	AVERAGE	Nd	R=Nc-Nd	Nts
Pseudomonas aeruginosa ATCC 15442	1,00E-01	>330	>330	>330	>4,52	<2,55	>100	1,00E-01		(0	<0,1	>6,97	0	1,00E-01	1 (0	0	<0,1	>6,97	0
Escherichia coli ATCC 10536	1,00E-01	>330	>330	>330	>4,52	<2,52	>100	1,00E-01		(0	<0,1	>6,94	0	1,00E-01	1 (0	0	<0,1	>6,94	. 0
Staphylococcus aureus ATCC 6538	1,00E-01	>330	>330	>330	>4,52	<2,50	>100	1,00E-01		(0	<0,1	>6,92	0	1,00E-01	1 (0	0	<0,1	>6,92	0
Enterococcus hirae ATCC 10541	1,00E-01	>330	>330	>330	>4,52	<2,53	>100	1,00E-01		(0	<0,1	>6,95	0	1,00E-01	1 (0	0	<0,1	>6,95	0

CRITERIA:

Bactericidal activity- R ≥ 4 log

Vc- number of cfu/ ml (one or two plates)

N- test suspension (jtk) *0,025

NT- validation of the neutralization-dilution method NC- neutralizer control

Nc- water control (log)

Nts- number of residual cfu recovered from test surface

Nd- number of microorganisms on the surface after applying the product (log)

R- reduction Nc-Nd (log)

Date: 13.04.2022

Authorized by: Daria Depa, Senior Specialist Analyst, Cosmetics Microbiology Laboratory

Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.

Page 2 / 2











REPORT OF ANALYSIS No. L102366/22/JSHR

Client ECOCHIM-GRUP SRL OR. OTACI, STR. VOITOVICI 21 2059 CHIŞINĂU		Sample description (according to declaration of Client) Dezinfectant Universal "Bio-Dez" Lot/Batch: - Production date: 21.09.2022 Expiration date: 21.09.2025 Sampling date: 29.09.2022 Sampling quantity: 1x 500ml Sample temperature: 17°C Reception hour: 12:30 Responsible for sampling: Crestinov Alexandr
Sample received:	2022-10-19	Sample condition with no objections
Analysis completed (the date of performance of the laboratory activity):	2022-12-05	Order of 2022-10-18
Report dated:	2022-12-05	The samples were delivered by Client

Test	Method	Unit	Result
* Bactericidal and/or fungicidal activity of disinfectants on non-porous surfaces - quantitative method ¹⁾	PN-EN 13697+A1:2019-08		Product undiluted (100%) shows fungicidal activity at 60 seconds, 20°C, ir dirty conditions (3g/L bovine albumin) at reference strains: Candida albicans ATCC 10231 and Aspergillus brasiliensis ATCC 16404. Product diluted to 50% shows yeasticida activity at 60 seconds, 20°C, in dirty conditions (3g/L bovine albumin) at reference strain: Candida albicans ATCC 10231.

¹⁾ The results of the analysis in attachment No 1 to the report of analysis.

THE END OF THE REPORT

Authorized by: Agnieszka Erber, Cosmetics Microbiology Laboratory Manager

Approved by: Hanna Wachowska, Laboratory Director (Approved with electronic signature)

The results relate to the analysed samples only. Unless otherwise specified given expanded measurement uncertainty was estimated for the coverage factor k=2 at 95% confidence level. Sampling uncertainty has not been taken into consideration. Unless otherwise specified when conformity is stated J.S. Hamilton Poland Sp. z o.o. applies the simple acceptance decision rule in accordance with ILAC-G8:09/2019. This Report cannot be reproduced partially without a prior written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in original copy of the Report. The service confirmed by this Report is subject to the General Terms and Conditions of Services of J.S. Hamilton Poland Sp. z o.o. published on www.hamilton.com.pl

* Test method accredited; # Test performed by external provider

Page 1/1

Form PO-10/02a of 20.01.2020





ENCLOSURE No. 1 TO REPORT OF ANALYSIS NO. L102366/22/JSHR

Name of the product	Dezinfectant Universal "Bio-Dez"
	Ethyl alcohol 72-76%, CAS 64-17-5 and CE 200-578-6
Active substance	Benzalkonium chloride 0,024-0,029%, CAS 68424-85-1 and CE 270-325-2 Methylthioninium chloride 0,00024%, CAS 61-73-4 and 200-515-2
B) TEST METHOD AND ITS VALIDATI	
Method	PN-EN 13697+A1:2019-08 Chemical disinfectants and antiseptics — Quantitative non-porous surface test for the evaluation of bactericidal and/or fungicidal activity of chemical disinfectants used in food, industrial, domestic and institutional areas — Test method and requirements without mechanical action (phase 2, step 2)
Neutralizer	Polisorbate 80- 30 g/l, saponine- 3 g/l, cysteine- 1g/l, histidine- 1g/l, sodium thiosulfate 7,5g/l
C) EXPERIMENTAL CONDITIONS	
Product test concentrations (%V/V)	0,01%, 50%, 100%
Test temperature	20°C+/-1°C
Contact time	1 minute fungi
Interfering substance	Dirty conditions: 3,0 g/l bovine albumin
Product diluent	Sterile hard water
Temperature of incubation	30±1°C fungi
Identification of the bacterial and fungal strains used:	Aspergillus brasiliensis ATCC 16404 Candida albicans ATCC10231

Date: 01.12.2022

Authorized by: Agnieszka Erber, Manager, Cosmetics Microbiology Laboratory Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of J.S. Hamilton Poland Sp. z o.o. Responsibility of J.S. Hamilton Poland Sp. z o.o. is restricted exclusively to the results and statements presented in an original copy of the enclosure.

Page 1 / 2

Form PO-10/05b of 20.01.2020



ENCLOSURE No. 1 TO REPORT OF ANALYSIS NO. L102366/22/JSHR

TABELE nr 1 : RESULTS OF BACTERICIDAL/FUNGICIDAL ACTIVITY TESTS OF THE PREPARATION

INTERFERING SUBSTANCE: 3,09/1 BOVINE ALBUMIN - DIRTY CONDITIONS

CONTACT TIME: 60 seconds fungi

TEST TEMPERATURE: 20°C

PRODUCT TEST CONCENTRATIONS: 0,01%, 50%,100%

	BA	BACTERIAL/FUNGAL TEST SUSPE	L TEST SUSPER	ENSION: N			>	ALIDATION NT				VAL	ALIDATION NC		
TEST ORGANISM	DRUTTON	VC1	VC2	AVERAGE	z	DELITION	VC1	VC2	AVERAGE	Þ	DILUTION	VC1	702	AVERAGE	NG
Aspergillus brasiliensis ATGC 16404	1,00E-05	184	191	187	2,67	1E-03	74	9/	75	5,88	15-03	99	19	67	
4	1,00E-06	18	Q1								P				
Candida albicans ATCC10231	1,00E-06	180	179	180	6,65	1E-03	69	65	19	5,83	15-03	28	64	62	
	1,005-07	18	18							0					

5,82

		W	WATER CONTR	IOL No		
TEST ORGANISM	DILUTION	VCI	VC2	AVERAGE	SN SN	NIS
Aspergilus brasiliensis ATCC 16404 Candida albicans ATCC10231	1E-03	125	127	126	6,10	>100

Fungl 5,57 ≤ N ≤ 6,10 Nc>3 log Cablicans 6,57 ≤ N ≤ 7,10 clean conditions NC-N_c ≤ ±0,3 log NT-Nc s ±0,3 log

	7-001	AVERAGE	9	0	
	1	VC2	W.		
		JCI			
		DILLITION VC	1,00E-01	1,00E-01	
			>165	0	
		Ruchic-Mei Mik	<1,90	26,00	
S % (V/V)		12	×4.22	<0.1	
ONCETRATION	20%	AVERAGE NA	>165	0.0	
TEST PROCEDURE FOR CO	1000	VC2	>165		
ST PROCE			>165	0	
1		DELITION VC!	1.00E-01	1,00E-01	
			>165	>100	
		N/B	1,88	<1.58	
		R=Nc-Md			
		PN	>4,22	>4,52	
	01%	AVERAGE	>165	>330	
	0.0	0	55	>165	>330
		>	>165	>330	
		VCT	-	1	
		DILUTION	1,00E-0	1,00E-0	
		TEST ORGANISM	Aspergillus brasiliensis ATCC 16404	Sandida albicans ATCC10231	

3,32

CRITERIA:

Fungicidal activity- R ≥ 3 log

Vc- number of chu'm (one or twe plates)
N- test suspension (jtk) "0,025
NT- validation of the neutralization-dilution method

NC- neutralizer control

NG- water control (log)

Nts- number of residual cfu recovered from feat surface
Nds- number of microorganisms on the surface after applying the product (log)

R- reduction No-Nd (log)

Date: 01,12,2022

Authorized by: Agnieszka Erber, Manager, Cosmetics Microbiology Laboratory Approved by: Hanna Wachowska, Laboratory Director (Approved with qualified electronic signature)

This enclosure is an inseparatable part of the report of analysis and cannot be reproduced partially without a priori written consent of 1.S. Hamilton Poland Sp. 2 0.0. Responsibility of 1.S. Hamilton Poland Sp. 2 0.0. is restricted exclusively to the reconstructed of an original copy of the enclosure.

Page 2 / 2

Form PO-10/05b of 20,01,2020

J.S. HAMILTON POLAND Sp. z o.o.
LABORATORIUM BADAWCZE

Ul. Chwaszczyńska 180, 81-571 Gdynia, POLAND tel. +48 58 766 99 00



REPORT OF ANALYSIS No. 80249/21/ROBCH

Client		Sample number:			
ECOCHIM-GRUP SRL		80249/21/ROBCH			
OR. OTACI, STR. VOITOVIC	I 21	Sample description (according to declaration of Client)			
2059 CHIŞINĂU		DEZINFECTANT UNIVERSAL "BIO-DEZ"			
		Lot: -			
		Data fabricatie: 01.10.2021			
		Data expirarii: 01.10.2024			
		Data prelevarii: -			
		Cantitate prelevata: 1 x 500 ml			
		Responsabil prelevare: CRESTINOV ALEXANDR			
		Ora receptiei probei: 15:30			
	[12]	Temperatura receptie proba: 15°C			
Sample received:	11.10.2021	Sample condition with no objections			
Tests performed:	21.10.2021	The state of the s			
Tests completed:	13.12.2021	Order of 11.10.2021			
Report dated:	13.12.2021	Sampling and delivery were carried out by client.			

Test	Method	Unit	Result
# * Quantitative suspension test for the evaluation of bactericidal activity in medical area	EN 13727:2012+A2:2015	ā	Test method performed by the subcontractor; the results are taken in full from the test report No D/21/B0645, issued by the subcontractor. The results of the analysis are listed starting with enclosure No1 to report of analysis.

Elaborated by: Mariana Ilinca, Manager of Microbiological Laboratory Authorized by: Mariana Ilinca, Manager of Microbiological Laboratory

Approved by: Alina-Roxana Mihai, General Manager (Approved with qualified electronic signature)

Laboratory: Bucuresti 041914, sos. Berceni nr.8

Responsabilitatea esantionarii/ prelevarii probelor apartine solicitantului. Rezultatele se refera numai la obiectul supus incercarii. Daca nu se specifica altfel, incertitudinea de masurare a fost estimata pentru coeficientul K= 2 si nivel de incredere 95%. Fara aprobarea scrisa a laboratorului acest raport de incercare nu poate fi reprodus decat integral. Responsabilitatea S.C. J.S. HAMILTON ROMANIA S.R.L. se refera exclusiv la rezultatele si declaratiile prezentate in raportul original. Opiniile si interpretarile continute in prezentul raport de incercare nu sunt acoperite de acreditarea RENAR. Pentru detalii suplimentare va rugam sa solicitati Certificatul de Acreditare la adresa de email bucharest@hamilton.com.pl

* Test method accredited # Test performed by external provider

ø Non accredited methods

Page 1 / 1





A) IDENTYFICATION OF THE SAMPLE Name of the product/Details about the product	DEZINFECTANT UNIVERSAL "BIO-DEZ"
rame of the product Details about the product	Expiration date: 01.10.2024.
	Manufacturer (supplier): Ecochim-Grup SRL.
	Storing conditions: Dry, without sun, 5-25 Celsius degree.
	Conditions of use: Hygienic handrub, surface disinfection,
	medical instruments disinfection, surgical handrub
Active compound/s and its concentration/s	Ethyl alcohol 72-76%, CAS 64-17-5 and CE 200-578-6.
Active compounds and its concentrations	Benzalkonium chloride 0.024- 0.029%, CAS 68424-85-1 and
	CE 270-325-2, Methylthionibium chloride 0.00024%, CAS 61-
	73-4 and 200-515-2
Concentrations requested for the assay	Pure (80%).
B) TEST METHOD	1 410 (0070).
Performed in accredited contracted partner laboratory,	UNE-EN 13727: 2012 + A2: 2015. Chemical disinfectants and
Scope of Accreditation Nr. 648/LE1286	antiseptics. Quantitative suspension test for the evaluation of
Report Registration No. D/21/B0645	bactericidal activity of chemical disinfectants for instruments
Quantitative evaluation assay of the bactericidal activity	used in Medicine. Test method and requirements (phase 2, step
under dirty conditions, in the medical area (phase 2, step	1). AENOR.
1) with product Desinfectant Universal "Bio-Dez", (UNE-	
EN 13727: 2012 + A2: 2015 Standard).	
Testing method	DESIN-1031-b //EN 13727: 2012 + A2: 2015
C) INFORMATION ABOUT SAMPLE RECEPT	ION
Date of reception of order with test conditions	21.10.2021
Date of reception of the sample	25.10.2021
Aspect of the received product	Blue liquid in plastic package
D) METHOD OF ASSAY AND ITS VALIDATION	N (UNE-EN 13727: 2012+A2: 2015 Standard.)
Method used	Dilution-neutralization
Neutralizer	Tryptone 5 g/L, yeast extract 2.5 g/L, dextrose 10 g/L, sodium
	thioglycolate 1 g/L, sodium thiosulfate 1 g/L, sodium bisulphite
	2.5 g/L, soya lecithin 7 g/L, polysorbate-80 5 g/L, glycine 1 g/L,
	1-histidine 1 g/L and saponin 30 g/L.
E) EXPERIMENTAL CONDITIONS	
Assay period	2021/11/10 to 2021/11/14.
Solvent of the product used in the assay	Sterile distilled water.
Product concentrations for the assay	Pure (80%), 50%, 0.1%
Aspect of the dilutions of the product	Pure (80%) and 50% blue liquid;
	0.1% transparent.
Contact time	60 seconds
Assay temperature	+20°C ± 1°C
Interfering substance	Bovine serum albumin 3 g/L and erythrocytes 3 mL/L.
Stability of the mixture (interfering substance and	Stable
product diluted in sterile distilled water)	
Temperature of incubation	+36°C± 1°C
Identification of the strain used	- Pseudomonas aeruginosa (CECT 116 = ATCC 15442).
	- Staphylococcus aureus (CECT 239 = ATCC 6538).
	- Enterococcus hirae (CECT 4081 = ATCC 10541).
	,

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore. *Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



ENCLOSORE NO. 1 SUBCONTRACTED TESTS TO REPORT OF ANALYSIS NO 80249/21/ROBCH Results of the assay

Assay of validation
 Evaluation of bactericidal activity
 See tables 1, 2, 4, 5, 7, 8, 10 and 11.
 See tables 3, 6, 9 and 12.

Number of replicates per assay organism .. 1

Special remarks

- All controls and validation were between the basic limits.
- At least one concentration of the sample showed a log reduction lower than 5 log.
- At least one concentration of the sample showed a log reduction higher than 5 log.
- The highest concentration that can be assayed in the test (80%) is due to the mixtures to perform the assay.
- No precipitate formed during the test procedure (the test mixtures were homogeneous).

Conclusion

The product Desinfectant Universal"Bio-Dez", batch not indicated, when is pure (80%), shows bactericidal activity after 60 seconds at 20°C ± 1°C, under dirty conditions (bovine serum albumin 3 g/L and erythrocytes 3 mL/L), for the reference strains Pseudomonas aeruginosa (CECT 116 = ATCC 15442), Staphylococcus aureus (CECT 239 = ATCC 6538), Enterococcus hirae (CECT 4081 = ATCC 10541) and Escherichia coli K12 (CECT 433 = NCTC 10538), when tested according to UNE-EN 13727: 2012 + A2: 2015 Standard.

Note: The results obtained correspond to the sample received in the laboratory.

Quality Assurance Review:

The assay development and the results obtained have been supervised by the Director of the study.

The Quality Assurance Director has inspected the development of the assay, proving that has been realized following the proper procedure and using the adequate media, materials, and reagents, following the Good Laboratory Practices (GLPs) as well and the final report contains the primary data obtained.

Reference

 UNE-EN 13727: 2012 + A2: 2015. Chemical disinfectants and antiseptics. Quantitative suspension test for the evaluation of bactericidal activity of chemical disinfectants for instruments used in Medicine. Test method and requirements (phase 2, step 1). AENOR.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay (Bactericidal suspension) with Pseudomonas aeruginosa (CECT 116 = ATCC 15442).

Seeding: Pour plate; No. of plates: 1/mL.

Table 1.-Validation and controls

	ispensio idation		ez	Control operime	ntal	Contr	ol of net (B)	utralizer	r Sampl	idation (nethod (e conce Pure (80)	(C) ntration:
Vc1	61	X=	Vc1	53	X= 54	Vc1	46	X= 48	Vc1	42	X=
Vc	56	58.5	Vc2 55		Vc2	50	-	Vc2	37	39.5	
30 ≤ x	of Nv ₀ : Yes	≤ 160?	x of	4 es ≥ 0 Nv ₀ ? Yes	,5 X de	100	B es ≥ 0 or 0.000 Yes	* Sec. 1942 1950 1950	x of	C es ≥ 0 Nv_0 ? Yes	.5 <i>X</i> of
	ispensio idation (Vc ₁ :	57	7c2: 63	30≤3	X=60 de Nv _E 160? Yes) ₃ /1000 ≤			

Table 2.-Suspension of the assay

	N	Vc1	Vc2	5,025
Suspension of assay (N and N_{θ})	10-6	217	234	$Xwm = 2.25 \times 10^8$, $\lg N = 8.35$ $N_0 = N/10$; $\lg N_0 = 7.35$
	10-7	21	22	7.17 ≤ lg No ≤ 7.70? Yes

Table 3.-Results of the activity assays with the sample

Concentrations of the sample (%)	Dilutions steps	Vc1	Vc2	$Lg Na = 1g$ $(X \times 10 \text{ o}$ $Xwm \times 10)$	Lg R (Lg N ₀ =7.35)	Time of contact (seconds)
D (200/)	Na ⁰	<14	<14	-0.15	>6.00	60
Pure (80%)	Na-1	<14	<14	<2.15	>5.20	60
500/	Na ⁰	<14	<14	215	>5.00	60
50%	Na -1	<14	<14	<2.15	>5.20	60
0.10/	Na®	>330	>330	~4.50	~2.02	60
0.1%	Na -1	>330	>330	>4.52	<2.83	60

Explanations:

Vc = number per mL (one or two plates); Xwm = weighted mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1 + 2);$ Logarithmic reduction R: $(\lg R = \lg N_0 - \lg Na)$.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



Results of the assay (Bactericidal suspension) with Staphylococcus aureus (CECT 239 = ATCC 6538).

Seeding: Pour plate; No. of plates: 1/mL.

Table 4.-Validation and controls

	Suspension of Control validation (Nvo) experime condition		ntal	(A) (B)		rol of neutralizer (B)		Validation of the method (C) Sample concentration Pure (80%)			
Vc1	77	X= 74	Vc1	68	X=	Vc_1	75	X=	Vc1	70	X= 66
V_{C2}	71		Vc2	69	68.5	Vc2	82	78.5	Vc2	62	
$30 \le x \text{ of } Nv_0 \le 160$? Yes		x of A es ≥ 0,5 X de N₁₀? Yes		$x \text{ of } B \text{ es } \ge 0.5 X \text{ de}$ Nv_0 , or 0.0005 Nv_B ? Yes			$x \text{ of } C \text{ es } \ge 0.5 X \text{ of}$ Nv_0 ? Y es				
Suspension of validation (Nv_B)		Vc1: 7	79 I	°c2: 86	30≤2	X= 82. de Nv _B 160? Yes	5 ⁄1000 ≤				

Table 5.-Suspension of the assay

	N	Vc1	Vc2	
Suspension of assay (N and N_0)	10-6	>330	>330	Xwm = 3.40 x 10^8 , $\lg N = 8.53$ N ₀ = N/10; $\lg N_0 = 7.53$
	10-7	33	35	7.17 ≤ lg N ₀ ≤ 7.70? Yes

Table 6.-Results of the activity assays with the sample

Concentrations of the sample (%)	Dilutions steps	Vcı	V _{C2}	Lg Na = lg (X x 10 o Xwm x 10)	Lg R (Lg No=7.53)	Time of contact (seconds)	
- Alexandri	Na ⁰	<14	<14	-0.15	> 5.30	60	
Pure (80%)	Na -1	<14	<14	<2.15	>5.38		
500/	Na ⁰	<14	<14	c2.15			
50%	Na -1	<14	<14	<2.15	>5.38	60	
0.10/	Na ⁰	>330	>330	~4.50	~2.01	60	
0.1%	Na-1	>330	>330	>4.52	<3.01		

Explanations:

Vc = number per mL (one or two plates); Xwm = weighted mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1 + 2);$

Logarithmic reduction R: $(\lg R = \lg N_0 - \lg Na)$.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



ENCLOSORE NO. 1 SUBCONTRACTED TESTS TO REPORT OF ANALYSIS NO 80249/21/ROBCH Results of the assay (Bactericidal suspension) with *Enterococcus hirae* (CECT 4081 = ATCC 10541).

Seeding: Pour plate; No. of plates: 1/mL.

Table 7.-Validation and controls

Suspension of validation (Nvo)		Control of experimental conditions (A)			Control of neutralizer (B)			Validation of the method (C) Sample concentration: Pure (80%)			
Vc1	41	X = 43	Vc1	44	X=	Vc1	37	X=	Vc1	35	X = 36
V_{C2}	45		Vc2	43	41.5	Vc2	c2 40	38.5	Vc2 37		
30 ≤ x of Nv ₀ ≤ 160? Yes		x of A es ≥ 0,5 X de Nvo? Yes		$x \text{ of } B \text{ es } \ge 0.5 X \text{ de}$ Nv_0 , or 0.0005 Nv_B ? Yes		$x \text{ of } C \text{ es } \ge 0.5 X \text{ of}$ $Nv_0?$ $Y \text{ es}$					
Suspension of validation (NvB)		Vc ₁ :	39 I	/c ₂ : 42	30≤3	X= 40. de Nv _B 160? Yes	5 2/1000 ≤				

Table 8.-Suspension of the assay

	N	Vc1	Vc2	
Suspension of assay (N and N_{θ})	10-6	167	154	$Xwm = 1.61 \times 10^8$, $\lg N = 8.20$ $N_0 = N/10$; $\lg N_0 = 7.20$
	10-7	17	16	7.17 $\leq \lg N_0 \leq 7.70$? Yes

Table 9.-Results of the activity assays with the sample

Concentrations of the sample (%)	Dilutions steps	Vc1	Vc2	Lg Na = 1g (X x 10 o Xwm x 10)	Lg R (Lg No=7.20)	Time of contact (seconds)	
D (000/)	Na ⁰	<14	<14	-0.15	>5.05	60	
Pure (80%)	Na -1	<14	<14	<2.15	>5.05		
500/	Na ⁰	15	14	216	5.04	60	
50%	Na-1	<14	<14	2.16	5.04		
0.10/	Na ⁰	>330	>330	>4.50	-2.60	60	
0.1%	Na -1	>330	>330	>4.52	<2.68		

Explanations:

Vc = number per mL (one or two plates); Xwm = weighted mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1 + 2);$

Logarithmic reduction R: $(\lg R = \lg N_0 - \lg Na)$.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



ENCLOSORE NO. 1 SUBCONTRACTED TESTS TO REPORT OF ANALYSIS NO 80249/21/ROBCH Results of the assay (Bactericidal suspension) with Escherichia coli K12 (CECT 433 = NCTC 10538).

Seeding: Pour plate; No. of plates: 1/mL.

Table 10.-Validation and controls

Suspension of validation (Nve)		Control of experimental conditions (A)			Control of neutralizer (B)			Validation of the method (C) Sample concentration Pure (80%)		(C) ntration:	
Vc1	58	X= 60	Vc1	44	X= 45	Vc1	51	X= 50	Vc1	43	X= 41
Vc2	62	45	Vc2	46	100000000000000000000000000000000000000	Vcz	49		Vc2	39	
$30 \le x \text{ of } Nv_0 \le 160$? Yes		x of A es ≥ 0,5 X de Nv ₀ ? Yes			x of B es $\ge 0.5 X$ de Nv ₀ , or 0.0005 Nv _B ? Yes			$x \text{ of } C \text{ es } \ge 0.5 X \text{ of}$ Nv_0 ? Yes			
Suspension of validation (NvB)		Vc1:	54	7c2: 56	30≤3	X=55 de Nvz 160? Yes	5 2/1000 ≤				

Table 11.-Suspension of the assay

AV 1945 52 8645 52	N	Vc1	Vc2	
Suspension of assay (N and N_{θ})	10-6	241	259	$Xwm = 2.49 \times 10^8$, $\lg N = 8.4$ $N_0 = N/10$; $\lg N_0 = 7.40$
	10-7	22	25	$7.17 \le \lg N_0 \le 7.70$? Yes

Table 12.-Results of the activity assays with the sample

Concentrations of the sample (%)	Dilutions steps	Vcı	V _{C2}	Lg Na = lg (X x 10 o Xwm x 10)	Lg R (Lg N ₀ =7.40)	Time of contact (seconds)	
D (000/)	Na ⁰	<14	<14	-0.15	>5.05	60	
Pure (80%)	Na -1	<14	<14	<2.15	>5.25		
500/	Na ⁰	<14	<14	c2.15	> 5.05		
50%	Na -1	<14	<14	<2.15	>5.25	60	
0.10/	Na ⁰	>330	>330	~4.50	<2.00	60	
0.1%	Na -1	>330	>330	>4.52	<2.88		

Explanations:

Vc = number per mL (one or two plates); Xwm = weighted mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1 + 2);$

Logarithmic reduction R: $(\lg R = \lg N_0 - \lg Na)$.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



REPORT OF ANALYSIS No. 17898/21/ROBCH

Client		Sample number:
ECOCHIM-GRUP SRL		17898/21/ROBCH
OR. OTACI, STR. VOITOVIC	I 21	Sample description (according to declaration of Client)
2059 CHIŞINĂU		DEZINFECTANT UNIVERSAL "BIO-DEZ"
		Sample quantity: 1 pcs x 1 L
		Production date: 26.01.2021
		Expiration date: 26.01.2024
		Sampling date: 22.02.2021
		Sample temperature: 15°C
		Reception hour: 15:00
		Responsible for sampling: Crestinov Alexandr
Sample received:	15.03.2021	Sample condition with no objections
Tests performed:	21.04.2021	
Tests completed:	16.06.2021	Order of 15.03.2021
Report dated:	16.06.2021	Sampling and delivery were carried out by client.

Test	Method	Unit	Result
# * Chemical disinfectants and antiseptics. Quantitative suspension test for the evaluation of mycobactericidal activity of chemical disinfectants in the medical area including instrument disinfectants. Test methods and requirements (phase 2, step 1)	EN 14348: 2005	-	Test method performed by the subcontractor; the results are taken in full from the test report No D/21/B0152, issued by the subcontractor. The results of the analysis are listed starting with enclosure No1 to report of analysis.

Elaborated by: Mariana Ilinca, Manager of Microbiological Laboratory Authorized by: Mariana Ilinca, Manager of Microbiological Laboratory

Approved by: Alina-Roxana Mihai, General Manager (Approved with qualified electronic signature)

Laboratory: Bucuresti 041914, sos. Berceni nr.8

Responsabilitatea esantionarii/ prelevarii probelor apartine solicitantului. Rezultatele se refera numai la obiectul supus incercarii. Daca nu se specifica altfel, incertitudinea de masurare a fost estimata pentru coeficientul K= 2 si nivel de incredere 95%. Fara aprobarea scrisa a laboratorului acest raport de incercare nu poate fi reprodus decat integral. Responsabilitatea S.C. J.S. HAMILTON ROMANIA S.R.L. se refera exclusiv la rezultatele si declaratiile prezentate in raportul original. Opiniile si interpretarile continute in prezentul raport de incercare nu sunt acoperite de acreditarea RENAR. Pentru detalii suplimentare va rugam sa solicitati Certificatul de Acreditare la adresa de email bucharest@hamilton.com.pl

* Test method accredited # Test performed by external provider

ø Non accredited methods

Page 1/1 PGL 09 F 01 Ed. 1 Rev. 1





A) IDENTYFICATION OF THE SAMPLE	
Name of the product/Details about the product	DEZINFECTANT UNIVERSAL "BIO-DEZ"
The state of the s	Expiration date: 26.01.2024
	Manufacturer (supplier): ECOCHIM-GRUP
	Storing conditions: Dry, without sun, 5-25 Celsius
	degree.
	Conditions of use: Handrub
Active(S) substance (S) and its concentration(s)	Ethyl alcohol 72-76%, CAS 64-17-5 and CE 200-578-
Active(5) substance (5) and its concentration(5)	6; Benzalkonium chloride 0.024-0.029%, CAS 68424-
	85-1 and CE 270-325-2; Methylthioninium chloride
	0.00024%, CAS 61-73-4 and 200
Compositions requested for the essert	,
Concentrations requested for the assay	3%/ on May 5 the client requested to perform the test at
D) TECT METHOD	80% concentration (Pure).
B) TEST METHOD Denformed in accordited subscentra et al. months on lab anotomy. Soone	UNE-EN 14348: 2005. Chemical disinfectants and
Performed in accredited subcontracted partner laboratory: Scope of Accreditation Nr. 648/LE1286	
Report D/21/B0152 Mycobactericidal and tuberculocidal	antiseptics. Quantitative suspension test for the evaluation of mycobactericidal activity of chemical disinfectants in the
activity of chemical disinfectants in the medical area including	medical area including instrument disinfectants. Test
instrument disinfectants under clean conditions with the product	methods and requirements (phase 2, step 1). AFNOR
DEZINFECTANT UNIVERSAL "BIO-DEZ" with	metrous una requirements (prase 2, step 1). Til 1701
deviations from the standard (UNE-EN 14348: 2005 Standard)	
· · · · · · · · · · · · · · · · · · ·	S VALIDATION (UNE-EN 14348: 2005 Standard)
Testing method	DESIN-1052-b // EN 14348: 2005
Method used	Dilution-neutralization
Neutralizer	Tryptone 5 g/L, yeast extract 2.5 g/L, dextrose 10 g/L,
	sodium thioglycolate 1 g/L, sodium thiosulfate 1 g/L, sodium
	bisulphite 2.5 g/L, soya lecithin 7 g/L, polysorbate-80 5 g/L,
	glycine 1 g/L, 1-histidine 1 g/L and saponim 30 g/L.
D) INFORMATION ABOUT SAMPLE RECEPTION	
Date of reception of the sample	24.03.2021
Date of reception of order with test conditions	14.04.2021: 3% concentration
	05.05.2021: 80% concentration
Aspect of the received product	Blue liquid in plastic package.
E) EXPERIMENTAL CONDITIONS	2021/04/12 + 2021/05/24 /: 1 1: : : : : : : : : : : : : : : : :
Assay period	2021/04/12 to 2021/05/24 (including prior preparation of the
Colvent of the product used in the esser-	strains) Storile hard water
Solvent of the product used in the assay Product concentrations for the assay	Sterile hard water Pure (80%) 29% and 0.19%
Aspect of the dilutions of the product	Pure (80%), 3% and 0.1% Pure (80%) Blue liquid; 3% and 0.1% transparent
Contact time	60 seconds
Assay temperature	$20^{\circ}\text{C} \pm 1^{\circ}\text{C}$
Interfering substance	Bovine albumin 0.3 g/L
Stability of the mixture (interfering substance and product	stable
diluted in sterile hard water)	Suote
Temperature of incubation	36°C ± 1°C
Identification of the origin of viral stains and number of passes	Mycobacterium avium (ATCC 15769)
5 F F F F F F F F F F F F F F F F	<i>Mycobacterium terrae</i> (CECT 3028 = ATCC 15755)
	1 2 ()

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore. *Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

 $Tel.+40\ 21\ 634\ 10\ 81\ bucharest@hamilton.com.pl,\ www.hamilton.com.pl$

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page 1 of 5

Date: 09.06.2021

Authorized by: Mariana Ilinca, Manager of Microbiological laboratory

Aprobat de: Mihai Alina-Roxana, General manager (Approved with qualified electronic signature)



Results of the assay

Control and validation assays......
 Evaluation of mycobactericidal activity...
 See tables 1, 2, 4 and 5
 See tables 3 and 6.

 Number of replicates for each assay microorganism.....

1.

Special remarks

- All controls and validation were between the basic limits.
- One concentration of the sample at least showed a log reduction less than 4 log.
- One concentration of the sample at least showed a log reduction higher than 4 log.
- The highest concentration that can be assayed in the test (80%) is due to the mixtures to perform the assay.
- When the client requested to perform the test at 80% concentration, the test had been started, using hard water.

Conclusion

The product **DEZINFECTANT UNIVERSAL** "BIO-DEZ", batch not indicated, when tested pure (80%), shows mycobactericidal activity after 60 seconds at 20°C under clean conditions (bovine albumin 0.3 g/L), against *Mycobacterium avium* (ATCC 15769) and *Mycobacterium terrae* (CECT 3028 = ATCC 15755), when tested as required by **UNE-EN 14348: 2005** Standard with deviations from the standard since the dilutions of the product, ready to use, have been prepared in sterile hard water instead of in sterile distilled water. The client informed us that the product was ready to use once the test have been started.

Note: The results obtained correspond to the sample received in the laboratory.

Quality Assurance Review:

The assay development and the results obtained have been supervised by the Director of the study.

The Quality Assurance Director has inspected the development of the assay, proving that has been realized following the proper procedure and using the adequate media, materials and reagents, following as well the Good Laboratory Practices (GLPs) and the final report contains the primary data obtained.

Reference:

 UNE-EN 14348: 2005. Chemical disinfectants and antiseptics. Quantitative suspension test for the evaluation of mycobactericidal activity of chemical disinfectants in the medical area including instrument disinfectants. Test methods and requirements (phase 2, step 1). AENOR.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Table 1.-Assay with Mycobacterium avium (ATCC 15769): Validation and controls.

Suspension of validation (Nv ₀)		Control of experimental conditions (A)			Neutralizer (B)			Validation of the method (C) with sample concentration: Pure (80%)			
Vc1	135	X=	Vc1	125	V- 122	Vc1	121	V- 124	Vc1	130	X=
Vc_2	124	129.5	Vc2 119 X= 122		Vc2	127	X= 124	Vc2	119	124.5	
$30 \le x \text{ of } Nv_0 \le 160$? Yes		$x \text{ of } A \text{ is } \ge 0.5 \text{ x X of}$ Nv_0 ? Yes			$x \text{ of } B \text{ is } \ge 0.5 \text{ x of}$ Nv_0 ? Yes			$x \text{ of } C \text{ is } \ge 0.5 \text{ X of}$ Nv_0 ? Yes			

Table 2.- Assay with Mycobacterium avium (ATCC 15769): Suspension of the assay.

Suspension of	N	Vcı	Vc2	$X_{wm} = 4.85 \times 10^9 = 1g = 9.69$
the assay (Ny	10-7	>660	>660	$N_0 = N/10 = 1g = 8.69$
N_0)	10-8	51	46	$8.17 \le N_0 \le 8.70$? Yes

Table 3.- Assay with Mycobacterium avium (ATCC 15769).

Concentrations of the sample (%)	Dilutions	Vc1	Vc2	$Lg Na = lg$ $(X \times 10 \text{ o}$ $Xwm \times 10)$	LgR (lgN ₀ = 8.69)	Time of contact (seconds)	
7217	10°	<14	<14				
D (000/)	10-1	<14	<14	-0.15	>6.54	60	
Pure (80%)	10-2	<14	<14	<2.15			
	10-3	<14	<14				
	10°	>660	>660			60	
20/	10-1	>660	>660	> 6.00	<1.87		
3%	10-2	>660	>660	>6.82			
	10-3	>660	>660				
	10°	>660	>660				
0.1%	10-1	>660	>660	>6.82	<1.87	60	
0.1%	10-2	>660	>660	70.82	>1.87	00	
	10-3	>660	>660				

Observations:

$$Nv_0$$
: 74 + 61; 59 + 65;

B:
$$63 + 58$$
; $71 + 57$;

$$0.1\% 10^{-3}$$
; >330 +>330; >330 +>330;

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



Table 4.-Assay with *Mycobacterium terrae* (CECT 3028 = ATCC 15755): Validation and controls.

Suspension of validation (Nv ₀)		Control of experimental conditions (A)			Neutralizer (B)			Validation of the method (C) with sample concentration: Pure (80%)				
Vc1	53	V CC	Vc1	54	V- 50	Vc1	50	V- 10	Vc_1	49	X= 47	
Vc_2	57	X= 55	Vc_2	50	X= 52	Vc2	Vc2 48	X= 49	Vc2	45	A= 4/	
$30 \le x \text{ of } N\nu_0 \le 160$? Yes					$x \text{ of } B \text{ is } \ge 0.5 \text{ x of}$ Nv_0 ? Yes			$x \text{ of } C \text{ is } \ge 0.5 \text{ X of}$ Nv_0 ? Yes				

Table 5.- Assay with Mycobacterium terrae (CECT 3028 = ATCC-15755): Suspension of the assay.

Suspension of	N	Vc_1	Vc2	$X_{wm} = 2.19 \times 10^9 = 1g = 9.34$
the assay (N y	10-7	227	211	$N_0 = N/10 = 1g = 8.34$
N ₀)	10-8	21	22	$8.17 \le N_0 \le 8.70$? Yes

Table 6.- Assay with Mycobacterium terrae (CECT 3028 = ATCC 15755).

Concentrations of the sample (%)	Dilutions	Vc ₁	Vc2	Lg Na = lg (X x 10 o Xwm x 10)	LgR (lgN ₀ = 8.34)	Time of contact (seconds)
	10 ⁰	<14	<14			
D (000/)	10-1	<14	<14	<2.15	>6.19	60
Pure (80%)	10-2	<14	<14	<2.15		
	10-3	<14	<14			
	100	>660	>660			60
20/	10-1	>660	>660	>6.82	<1.52	
3%	10-2	>660	>660	>0.82		
	10-3	>660	>660			
	100	>660	>660	<u> </u>		
0.1%	10-1	>660	>660	>6.92	<1.52	60
	10-2	>660	>660	>6.82	\$1.52	60
	10-3	>660	>660			

Observations:

Explanations:

Vc: Counts per mL

Xwm: ponderated mean of X

X: Values of Vc_1 and $Vc_2(1. + 2. \text{ duplicates})$; R: reduction (LgR = lgN₀ - lgNa)

R: reduction (LgR = $\lg N_0 - \lg Na$)

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page 4 of 5



Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore. *Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania $Tel.+40\ 21\ 634\ 10\ 81\ bucharest@hamilton.com.pl,\ www.hamilton.com.pl$

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page 5 of 5

Date: 09.06.2021

Authorized by: Mariana Ilinca, Manager of Microbiological laboratory

Aprobat de: Mihai Alina-Roxana, General manager (Approved with qualified electronic signature)



REPORT OF ANALYSIS No. 60362/23/ROBCH

Sample number: Client **ECOCHIM-GRUP SRL** 60362/23/ROBCH OR. UNGHENI, STR. NAȚIONALĂ 119 Sample description (according to declaration of Client) - REPUBLICA MOLDOVA **Dezinfectant Universal "Bio-Dez"** Lot: -Data fabricatiei: 05.08.2023 Data expirare: 05.08.2026 Data receptiei probei: 23.08.2023 Cantitate prelevata:500 ml Responsabil prelevare: Cristinov Alexandr Ora receptiei probei: 12:30 Temperatura receptie proba: 17°C Sample received: 24.08.2023 Sample condition with no objections Tests performed: 30.08.2023 Tests completed: 30.10.2023 Order of 24.08.2023 Report dated: 30.10.2023 Sampling and delivery were carried out by client.

Test	Method	Unit	Result
# * Chemical disinfectants and antiseptics. Quantitative suspension test for the evaluation of virucidal activity in the medical area	UNE-EN 14476:2014 + A2:2019	-	Test method performed by the subcontractor; the results are taken in full from the test report No D/23/ V0259, issued by the subcontractor. The results of the analysis are listed starting with enclosure No1 to report of analysis.

Test responsible: Mariana Ilinca, Manager of Microbiological Laboratory Validated by: Mariana Ilinca, Manager of Microbiological Laboratory

Authorized by: Alina-Roxana Mihai, General Manager (Approved with qualified electronic signature)

Laboratory: Bucuresti 041914, sos. Berceni nr.8

Responsabilitatea esantionarii/ prelevarii probelor apartine solicitantului. Rezultatele se refera numai la obiectul supus incercarii. Daca nu se specifica altfel, incertitudinea de masurare a fost estimata pentru coeficientul K= 2 si nivel de incredere 95%. Fara aprobarea scrisa a laboratorului acest raport de incercare nu poate fi reprodus decat integral. Responsabilitatea S.C. J.S. HAMILTON ROMANIA S.R.L. se refera exclusiv la rezultatele si declaratiile prezentate in raportul original. Opiniile si interpretarile continute in prezentul raport de incercare nu sunt acoperite de acreditarea RENAR. Pentru detalii suplimentare va rugam sa solicitati Certificatul de Acreditare la adresa de email bucharest@hamilton.com.pl

* Test method accredited # Test performed by external provider

 $_{\odot}$ Non accredited methods Page 1 / 1 PGL 09 F 01 Ed. 1 Rev. 3





A) IDENTYFICATION OF THE SAMPLE	<u>, </u>
Name of the product/Details about the product	DEZINFECTANT UNIVERSAL "BIO-DEZ"
	Manufacturer(supplier): Ecochim-Grup
	Condition of use: Instrument disinfection, surface
	disinfection, hygienic handrub.
Active(s) Substance(s) and its concentration(s)	Ethyl alcool 72-76%, CAS 64-17-5 and CE 200-578-6,
(-)	Benzalkonium chloride 0.024-0.029%, CAS 68424-85-1 and
	CE 270-325-2, Methylthionibium chloride 0.00024%, CAS
	61-73-4 and 200-515-2.
Concentration ordered for the assay	80
B) TEST METHOD	
Performed in accredited subcontracted partner laboratory: Scope	EN 14476: 2013 + A2: 2019 Standard. Chemical
of Accreditation Nr. 648/LE1286	disinfectants and antiseptics. Quantitative suspension test for
Report D/23/V0259. Quantitative suspension test for the	the evaluation of virucidal activity in the medical area. Test
evaluation of virucidal activity in the medical area (phase 2, step	method and requirements (phase 2/step1).
1), against Poliovirus type 1, Adenovirus type 5 and Murine	
Norovirus with the product "Dezinfectant Universal "Bio-Dez"	
(EN 14476: 2013 + A2: 2019 Standard)	
Testing method	Procedure DESIN-1078 (EN 14476: 2013 + A2: 2019
	Standard).
C) INFORMATION ABOUT SAMPLE RECEPTION	
Date of reception of the sample	2023/08/30
Date of reception of order with test conditions	2023/09/04.
Aspect of the received product	Blue transparent liquid in plastic container with identification
•	label.
D) EXPERIMENTAL CONDITIONS	
Assay period	2023/09/06 to 2023/09/21.
Assay temperature	$37^{\circ}\text{C} \pm 1^{\circ}\text{C}$
Titration method	TCID50
	(Tissue Culture Infective Dose 50%).
Product concentrations for the assay	80%, 50% and 0.1%
Contact time	60 seconds
Contact temperature	$20^{\circ}\text{C} \pm 1^{\circ}\text{C}$
Procedure to stop product cytotoxicity	Molecular sieving (< 4 columns).
Procedure to stop product activity	Cooling with ice
Solvent of the product used in the assay	Sterile distilled water
Aspect of the dilutions of the product	Transparent
Stability of the mixture (interfering substance and product	
diluted in sterile hard water/distilled water)	Stable
Interfering substance	Dirty conditions in the presence of bovine serum albumin 3
	g/L and erythrocytes 3 mL/L.
Identification of the origin of viral stains and number of passes	Poliovirus type 1 (ATCC VR-192)
	aliquot: 2023/03/23 passage 2.
	Adenovirus type 5 (ATCC VR-5)
	aliquot: 2022/06/10 passage 2.
	Murine Norovirus (strain S99 Berlin)
	aliquot: 2022/06/22 passage 2.
Cell lines (name, origin, number of passes)	Vero, ref: FTVE, working aliquot 4, passages 18 21, 22 and
· · · · · · · · · · · · · · · · · · ·	25.
	Raw 264.7, Public Health England, working aliquot 4,
	passages 18, 21 and 25

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore. *Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page 1 of 13

Date: 27.10.2023

Authorized by: Mariana Ilinca, Manager of Microbiological laboratory

Aprobat de: Mihai Alina-Roxana, General manager (Approved with qualified electronic signature)



Validation of assay results

Poliovirus type 1 (ATCC VR-192)

Titre of the viral suspension for the virus control (at the requested test time)	
- Dirty conditions	log 10 ^{-7,50}
Cytotoxicity level (80%)	log 10 ^{-0.50}
Maximum level of virus inactivation detectable (difference between the tits suspension and the cytotoxicity level):	re of the viral
Dirty conditions	log 10 ^{-7.00}
Adenovirus type 5 (ATCC VR-5)	
Titre of the viral suspension for the virus control (at the requested test time)	
Dirty conditions	log 10 ^{-6.82}
Cytotoxicity level (80%)	
Maximum level of virus inactivation detectable (difference between the tits suspension and the cytotoxicity level):	
- Dirty conditions	log 10 ^{-6.32}
Murine Norovirus (strain S99 Berlin)	
Titre of the viral suspension for the virus control (at the requested test time)	
Dirty conditions	log 10 ^{-8.32}
Cytotoxicity level (80%)	log 10 ^{-0.50}
Maximum level of virus inactivation detectable (difference between the tits suspension and the cytotoxicity level):	re of the viral
- Dirty conditions	log 10 ^{-7.82}
Reference test (formaldehyde 1.4%)	
Cytotoxicity level of formaldehyde 0.7%	log 10 ^{-0.50}
Viral quantification in the reference test (formaldehyde) after 60 minutes and	with
Poliovirus type 1	log 10 ^{-3.08}
Viral quantification in the reference test (formaldehyde) after 60 minutes and Adenovirus type 5	with
Viral quantification in the reference test (formaldehyde) after 60 minutes and	with
Murine Norovirus	log 10 ^{-4,99}

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore. *Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



ENCLOSORE NO. 1 SUBCONTRACTED TESTS TO REPORT OF ANALYSIS NO 60362/23/ROBCH Confidence interval

Titre of virus with 95% confidence interval with Poliovirus type 1 (at the requested test time)
- Dirty conditions log 10 ^{-7.50 ± 0.37}
Titre of virus with 95% confidence interval with Adenovirus type 5 (at the requested test time)
- Dirty conditions log 10 ^{-6.82 ± 0.41}
Titre of virus with 95% confidence interval with Murine Norovirus (at the requested test time)
- Dirty conditions
Reduction with the confidence interval of 95%
Sensitivity of cells to virus
 Viral quantification of Poliovirus type 1 with cells not treated by the test solution with the test sample
Viral quantification of Poliovirus type 1 with cells treated by the test solution with the test sample
 Viral quantification of Adenovirus type 5 with cells not treated by the test solution with the test sample
Viral quantification of Adenovirus type 5 with cells treated by the test solution with the test sample
Viral quantification of Murine Norovirus with cells not treated by the test solution with the test sample
Viral quantification of Murine Norovirus with cells treated by the test solution with the test sample
Note: only can be used to determine the infectivity of cells, those dilutions which: a) show a low degree of cellular destruction ($< 25\%$ of cell monolayer) and b) produce a reduction of the title of the virus $< 1 \log_{10}$.
Control of the effectivity of the disinfectant suppression activity
 Viral quantification of Poliovirus type 1 after 30 minutes on bath ice without exposing the virus to the test sample
Viral quantification of Poliovirus type 1 exposing the virus to the test sample and incubated 30 minutes on ice bath
 Viral quantification of Adenovirus type 5 after 30 minutes on bath ice without exposing the virus to the test sample
 Viral quantification of Adenovirus type 5 exposing the virus to the test sample and

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



- Viral quantification of Murine Norovirus after 30 minutes on bath ice without exposing the virus to the test sample log 10^{-8.25}
- Viral quantification of Murine Norovirus exposing the virus to the test sample and

Note: The difference between decimal logarithm of titre without exposing the virus to the sample and of the test suspension should be ≤ 0.5 .

Special remarks

- All controls and validation were between the basic limits.
- To be accepted the assay, at least one concentration of the product must show a log reduction equal or higher than 4 log, and at least one concentration must show a log reduction lower than 4 log.

9. Assay results

9.1 Description of the results under the requested test conditions

Virus of assay	Test concentrations, reduction obtained with the confidence interval of 95 % and virucidal activity							
	80%	50%	0.1%					
Poliovirus	≥ 7.00 ± 0.37 TCID ₅₀	2.84 ± 0.56 TCID ₅₀	0.01 ± 0.49 TCID ₅₀					
type 1	Shows	Does not show	Does not show					
Adenovirus type 5	≥ 6.32 ± 0.41 TCID ₅₀	5.07 ± 0.48 TCID ₅₀	0.07 ± 0.48 TCID ₅₀					
	Shows	Shows	Does not show					
Murine Norovirus	≥ 7.82 ± 0.42 TCID ₅₀	5.58 ± 0.56 TCID ₅₀	0.08 ± 0.54 TCID ₅₀					
	Shows	Shows	Does not show					

Virucidal activity exists when the titre of virus shows a reduction $\geq 4 \log$. TCID50: Tissue Culture Infectious Dose 50%.

9.2 Tables of results and graphics

See tables 1 to 6 and figures 1 to 3.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



The product "Dezinfectant Universal "Bio-Dez", batch 60362/23/ROBCH, at 80% concentration, under dirty conditions (bovine serum albumin 3 g/L and erythrocytes 3 mL/L), requested by the client and during 60 seconds of contact time and 20°C of temperature, shows activity against Poliovirus type 1, Adenovirus type 5 and Murine Norovirus, when the activity is assayed according with the EN 14476: 2013 + A2: 2019 Standard.

Therefore, the disinfectant tested <u>shows</u> general virucidal activity at 80% concentration, when the activity is assayed according with the EN 14476: 2013 + A2: 2019 Standard.

Note 1: The results obtained correspond to the sample received in this laboratory.

Note 2: The information that depend on the information received from the client and are not facilitated by the same one, shown as "not indicated".

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page 5 of 13



Table 1. Results of activity of the test sample with Poliovirus type 1 (ATCC VR-192) under test conditions requested by the client.

Assay	Concen- tration	Interfering substance	Cytoto- xicity level	log ₁₀ TCID ₅₀ after				Reduction with the confidence interval of
				0 min	60 sec	30 min	60 min	95 %
	80%	- 3 g/L BSA + 3 mL/L	0.50		0.50			\geq 7.00 \pm 0.37
Test sample	50%		0.50	29	4.66	243	241	2.84 ± 0.56
	0.1%	- erythrocytes	0.50		7.49			0.01 ± 0.49
Virus control	NA	3 g/L BSA + 3 mL/L erythrocytes	NA	7.58	7.50		141	NA
Formaldehyde	0.7% (w:v)	NA	0.50	NR	NR	4.99	3.08	NA
Virus control formaldehyde	0.7% (w:v)	NA	NA	7.58	NR	NR	7.32	NA

NA: not applicable; NR: not realized.

Times recommended by Standard for surfaces: maximum 5 or 60 minutes. Times recommended by Standard for instruments: maximum 60 minutes.

Times recommended by Standard for Hygienic treatment of hands by friction and hygienic

handwashing: between 30 or 120 seconds.

PBS: phosphate buffered saline; BSA: bovine serum albumin.

Virucidal activity exists when the titre of virus shows a reduction ≥ 4 log.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. \emptyset Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

Page 6 of 13

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Date: 27.10.2023

Authorized by: Mariana Ilinca, Manager of Microbiological laboratory

Aprobat de: Mihai Alina-Roxana, General manager (Approved with qualified electronic signature)



Table 2. Results of the activity of the test sample, with Poliovirus type 1 (ATCC VR-192) (Assay of titration with 12 wells), under test conditions requested by the client.

Assay	Concen-	Interfering	Time of				Dih	itions (log10)*	b			
1234)	tration	substance	(sec/min)	1	2	3	4	5	6	7	8	9	10
ĺ	80%	NO BERNEY	60 sec	0000 0000	0000 0000 0000	0000 0000	0000 0000	0000 0000 0000	0000 0000	0000 0000 0000	NR	NR	NR
Test sample	50%	3 g/L BSA + 3 mL/L erythrocytes	60 sec	4444 4444 4444	4444 4444 4444	4444 4444 4444	3240 0403 4432	0002 3010 0020	0200 0000 0000	0000 0000 0000	NR	NR	NR
	0.1%	- u,	60 sec	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	3241 0344 3032	0000 0200 0001	0000 0000	NR.
Cytotoxicity	80%	3 g/L BSA + 3 mL/L erythrocytes	NA	0000 0000	0000 0000	0000 0000 0000	0000 0000 0000	0000 0000 0000	0000 0000	0000 0000 0000	NR	NR	NR
Virus control	NA	3 g/L BSA + 3 mL/L	0	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	3244 3021 3044	0000 0220 0003	0000 0000	NR
virus condroi		erythrocytes	60 sec	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	3204 4310 0233	0010 0000 2020	0000 0000	NR
Formal-	0.7%	NA	30 min	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	0030 2004 4030	0000 0020 0000	0000 0000 0000	NR	NR	NR
dehyde	(w:v)	NA	60 min	4444 4444 4444	4444 4444 4444	0302 2304 0002	0000 0000 0100	0000	0000 0000	0000 0000 0000	NR	NR	NR
Control of formaldehyde cytotoxicity	0.7% (w:v)	3 g/L BSA + 3 mL/L erythrocytes	NA	0000 0000	0000 0000	0000 0000	0000 0000 0000	0000	0000 0000 0000	0000 0000 0000	NR	NR	NR
Virus control	0.7%		0	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	0321 0044 4342	1000 2000 3020	0000 0000	0000 0000
dehyde	(w:v)	NA	60 min	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	0321 0404 4303	0000 2000 0020	0000 0000	0000 0000
Sensitivity control of	NA	NA	Cells not treated	0000 0000	CCCC CCCC CCCC	0000 0000 0000	0000 0000	0000 0000 0000	0000	CCCC CCCC	0000 0000	0000 0000	NR
cells to virus	*****	110	Cells treated	0000 0000	CCCC	0000 0000	0000	0000	0000	0000 0000	C0CC 0C00	0000 0000 C000	NR
Effectiveness control of the	274	3 g/L BSA	Without sample	0000 0000	0000 0000	0000 0000	0000	0000 0000	0000 0000	0000 0000	000C 0000 00C0	0000 0000	NR
disinfectant suppression activity	ctant NA + 3 mL/ ssion erythrocy	+ 3 mL/L erythrocytes	With sample	CCCC	0000 0000	0000 0000	0000	0000	CCCC CCCC	0000 0000	0000 C000 0000	0000 0000	NR

a): 1 to 4, virus present and grade of cytopathic effect in 12 units of cellular culture, or grade of cellular lesions in the cytotoxicity assay.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L. 8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

C = cytopathic effect with presence of virus (in this case and according to Standard does not take into account the degree of cytopathic effect only, the presence or absence of the same).

^{0 =} no virus present or absence of cellular lesions in the cytotoxicity assay; NA: not applicable; NR: not realized; BSA: Bovine serum albumin; PBS: phosphate buffered saline, sec: seconds; min: minutes;

^{*}Test method accredited # Test performed by subcontractor. \emptyset Non accredited methods.



Table 3. Results of activity of the test sample with Adenovirus type 5 (ATCC VR-5), under test conditions requested by the client.

Assay	Concen- tration	Interfering substance	Cytoto- xicity			TCID ₅₀		Reduction with the confidence interval of
			level	0 min	60 sec	30 min	60 Min	95 %
	80%	3 g/L BSA + - 3 mL/L	0.50	·	0.50	8		≥ 6.32 ± 0.41
Test sample	50%		0.50	8E	1.75	20	32	5.07 ± 0.48
	0.1%	erythrocytes	0.50	·	6.75	2	15	0.07 ± 0.48
Virus control	NA	3 g/L BSA + 3 mL/L erythrocytes	NA	6.91	6.82	21	2	NA
Formaldehyde	0.7% (w:v)	NA	0.50	NR	NR	3.49	2.75	NA
Virus control formaldehyde	0.7% (w:v)	NA	NA	7.16	NR	NR	6.98	NA

NA: not applicable; NR: not realized.

Times recommended by Standard for surfaces: maximum 5 or 60 minutes.

Times recommended by Standard for instruments: maximum 60 minutes.

Times recommended by Standard for Hygienic treatment of hands by friction and hygienic

handwashing: between 30 or 120 seconds.

PBS: phosphate buffered saline; BSA: bovine serum albumin.

Virucidal activity exists when the titre of virus shows a reduction $\geq 4 \log$.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0 Page 8 of 13

Date: 27.10.2023

Authorized by: Mariana Ilinca, Manager of Microbiological laboratory

Aprobat de: Mihai Alina-Roxana, General manager (Approved with qualified electronic signature)



Table 4. Results of the activity of the test sample, with Adenovirus type 5 (ATCC VR-5)

(Assay of titration with 12 wells), under test conditions requested by the client.

Assav	Concen-	Interfering	Time of contact	Š.			Dilt	ations (log10)a	b			
	tration	substance	(sec/min)	1	2	3	-4	5	6	7	8	9	10
	80%		60 sec	0000 0000 0000	0000 0000 0000	0000 0000	0000 0000	0000 0000	0000 0000	0000 0000 0000	NR	NR	NR
Test sample	50%	3 g/L BSA + 3 mL/L erythrocytes	60 sec	4433 2113 4443	0010 3002 0000	0000 0000	0000 0000	0000 0000 0000	0000 0000	0000 0000	NR	NR	NR
	0.1%		60 sec	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4433 1234 4433	0003 1000 2000	0000 0000	NR	NR
Cytotoxicity	80%	3 g/L BSA + 3 mL/L erythrocytes	NA	0000 0000	0000 0000	0000 0000 0000	0000 0000	0000 0000 0000	0000 0000 0000	0000 0000 0000	NR	NR.	NR
Virus control	NA	3 g/L BSA + 3 mL/L	0	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	3244 4302 3042	2004 0423 0001	0100 0000 0000	NR	NR
VIIIIS COMITOE	AMERICAN CONTRACT DESCRIPTION	erythrocytes	60 sec	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	3201 4443 3440	0023 0102 0200	0000 0000 0001	NR	NR
Formal-	0.7%	NA	30 min	4444 4444 4444	4444 4444 4444	3402 0303 2033	0001 2000 1000	0000 0000	0000 0000	0000 0000	NR	NR.	NR
dehyde	(w:v)	3.53	60 min	4444 4444 4444	3334 2444 3442	0202 0010 0000	0000 0000	0000	0000 0000	0000 0000	NR	NR.	NR
Control of formal- dehyde cytotoxicity	0.7% (w:v)	3 g/L BSA + 3 mL/L erythrocytes	NA	0000 0000 0000	0000 0000 0000	0000 0000	0000 0000 0000	0000 0000 0000	0000 0000 0000	0000 0000 0000	NR	NR.	NR
Virus control	0.7%		0	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	0402 3030 4040	0000 0010 0020	0000 0000	000
dehyde	(w:v)	NA	60 min	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4344 4340 2433	4020 0200 3200	0000 0010 0010	0000 0000	0000
Sensitivity control of	NA	NA	Cells not treated	CCCC CCCC	0000 0000	CCCC CCCC	0000 0000	CCCC CCCC	0000	0000 0000	0000 0C00 000C	NR	NR
control of cells to virus			Cells treated	0000	0000 0000	CCCC	0000	CCCC	0000 0000	0C00 0C00	0000 000C 0000	NR.	NR
Effectiveness control of the disinfectant l suppression activity	NIA	3 g/L BSA	Without sample	CCCC CCCC	0000 0000	0000	0000	0000 0000	CCCC CCCC	C0C0 00C0	000C C000 0C00	NR	NR
	NA	NA +3 mL/L erythrocytes	With sample	CCCC	0000	CCCC	0000	0000 0000	CCCC CCCC	00CC 0C00 00C0	0000 0000	NR	NR

a): 1 to 4, virus present and grade of cytopathic effect in 12 units of cellular culture, or grade of cellular lesions in the cytotoxicity assay.

C = cytopathic effect with presence of virus (in this case and according to Standard does not take into account the degree of cytopathic effect only, the presence or absence of the same).

0 = no virus present or absence of cellular lesions in the cytotoxicity assay; NA: not applicable; NR: not realized; BSA: Bovine serum albumin; PBS: phosphate buffered saline. sec: seconds; min: minutes.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods. JS. HAMILTON ROMANIA S.R.L.



Table 5. Results of activity of the test sample, with Murine Norovirus, strain S99 Berlin, under test conditions requested by the client.

Assay	Concen- tration	Interfering substance	Cytoto- xicity			TCID50 ter		Reduction with the confidence interval of
			level	0 min	60 sec	30 min	60 min	95 %
	80%		0.50	` = "	0.50		8	≥ 7.82 ± 0.42
Test sample	50%	3 g/L BSA + 3 mL/L	0.50		2.74			5.58 ± 0.56
	0.1%	erythrocytes	0.50		8.24	3	8	0.08 ± 0.54
Virus control	NA	3 g/L BSA + 3 mL/L erythrocytes	NA	8.41	8.32	9	¥	NA
Formaldehyde	0.7% (w.v)	NA	0.50	NR	NR	5.74	4.99	NA
Virus control formaldehyde	0.7% (w:v)	NA	NA	8.50	NR	NR	8.32	NA

Control of the effectiveness of the disinfectant suppression activity (difference between decimal logarithm of titre without exposing the virus to the sample and of the test suspension)................................log10^{-0.43}

NA: not applicable; NR: not realized.

Times recommended by Standard for surfaces: maximum 5 or 60 minutes. Times recommended by Standard for instruments: maximum 60 minutes.

Times recommended by Standard for Hygienic treatment of hands by friction and hygienic

handwashing: between 30 or 120 seconds.

PBS: phosphate buffered saline; BSA: bovine serum albumin.

Virucidal activity exists when the titre of virus shows a reduction $\geq 4 \log$.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

Page 10 of 13

PGL 09 F 04 Ed. 1 Rev. 0

Date: 27.10.2023

Authorized by: Mariana Ilinca, Manager of Microbiological laboratory

Aprobat de: Mihai Alina-Roxana, General manager (Approved with qualified electronic signature)



Table 6. Results of the activity of the test sample, with Murine Norovirus strain S99 Berlin (Assay of titration with 12 wells), under test conditions requested by the client.

Assav	Concen-	Interfering	Time of	ê			Dilu	tions (log10)°	b			
Assay	tration	substance	(sec/min)	1	2	3	4	5	6	7	8	9	10
	80%		60 sec	0000 0000 0000	NR	NR	NR						
Test sample	50%	3 g/L BSA +3 mL/L erythrocytes	60 sec	4444 4444 4444	3244 3020 2244	0020 0122 0030	0000 0000	0000	0000 0000	0000	NR	NR	NR
	0.1%		60 sec	4444 4444 4444	0302 2010 3212	0000 0000 0002	NR						
Cytotoxicity	80%	3 g/L BSA + 3 mL/L erythrocytes	NA	0000 0000 0000	0000 0000	0000 0000 0000	0000 0000 0000	0000 0000	0000 0000	0000 0000	NR	NR.	NR
Virus control	NA	3 g/L BSA +3 mL/L	0	4444 4444 4444	0323 0404 3302	0020 0000 0210	NR						
virus connoi		erythrocytes	60 sec	4444 4444 4444	4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	3244 3321 2013	3213 0030 2203	0002 0200 0010	NR
Formal-	0.7%	NA	30 min	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	3344 0334 4444	0200 0202 0100	0000 0000	NR	NR.	NR
dehyde	(w:v)		60 min	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	0030 4020 2200	0000 0100 0000	0000	NR	NR.	NR
Control of formal- dehyde cytotoxicity	0.7% (w:v)	3 g/L BSA + 3 mL/L erythrocytes	NA	0000 0000 0000	NR	NR	NE						
Virus control formal-	0.7%		0	4444 4444 4444	3042 4040 4433	0000 1000 0102	000 000						
dehyde	(w:v)	NA	60 min	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4444 4444	4444 4244 3330	2002 0302 2434	0000 0120 0100	000 000
Sensitivity control of	NA	NA	Cells not treated	0000	0000 0000	0000	0000 0000	0000 0000	0000 0000	0000	0000 0000	000C 00C0	NR
cells to virus	577		Cells treated	CCCC	CCCC CCCC	CCCC	0000 0000	0000 0000	CCCC	CCCC CCCC CCCC	00CC 00CC	0000 0C00 0C00	NR
Effectiveness control of the	l of the 3 g/L BSA Sectant NA +3 mL/L ession erythrocyte		Without sample	CCCC CCCC	0000 0000 0000	CCCC	0000 0000	CCCC	0000	0000	0000 0000	00C0 C000	NR
disinfectant suppression activity			With sample	CCCC CCCC	0000 0000	CCCC	0000 0000	0000 0000	CCCC	0000 0000	0000 CC00 C0C0	0000 0000	NR

a): 1 to 4, virus present and grade of cytopathic effect in 12 units of cellular culture, or grade of cellular lesions in the cytotoxicity assay.

Sec: seconds; min: minutes.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page 11 of 13

Date: 27.10.2023

C = cytopathic effect with presence of virus (in this case and according to Standard does not take into account the degree of cytopathic effect only, the presence or absence of the same).

^{0 =} no virus present or absence of cellular lesions in the cytotoxicity assay; NA: not applicable; NR: not realized; BSA: Bovine serum albumin; PBS: phosphate buffered saline.

^{*}Test method accredited # Test performed by subcontractor. \emptyset Non accredited methods.



Figure 1. Results of the activity of the test sample under test conditions requested by the client with Poliovirus type 1 (ATCC VR-192).





Figure 2. Results of the activity of the test sample under test conditions requested by the client with Adenovirus type 5 (ATCC VR-5).



Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.


8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



Figure 3. Results of the activity of the test sample under test conditions requested by the client with Murine Norovirus strain S99 Berlin.



Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page 13 of 13



REPORT OF ANALYSIS No. 16417/22/ROBCH

Client		Sample number:				
ECOCHIM-GRUP SRL		16417/22/ROBCH				
OR. OTACI, STR. VOITOVIO	II 21	Sample description (according to declaration of Client)				
2059 CHIŞINĂU		Dezinfectant Universal "Bio-Dez"				
		Lot: FABR.08.2020				
		Data fabricatie: -				
		Data expirarii: 18.02.2025				
		Data prelevarii:18.02.2022				
		Cantitate prelevata: 3 x 500 ml				
		Responsabil prelevare: Crestinov Alexandr				
		Ora receptiei probei: -				
Tarry 10 10 10	Francis of the Contraction	Temperatura receptie proba: 15°C				
Sample received:	01.03.2022	Sample condition with no objections				
Tests performed:	01.03.2022	1975				
Tests completed:	13.04.2022	Order of 01.03.2022				
Report dated:	13.04.2022	Sampling and delivery were carried out by client.				

Test	Method	Unit	Result
# * Chemical disinfectants and antiseptics. Quantitative carrier test for the evaluation of bactericidal activity for instruments used in the medical area. Test method and requirements (phase 2, step 2)	UNE-EN 14561:2007	<u>u</u>	Test method performed by the subcontractor; the results are taken in full from the test report No D/22/B0135, issued by the subcontractor. The results of the analysis are listed starting with enclosure No1 to report of analysis.

Elaborated by: Mariana Ilinca, Manager of Microbiological Laboratory Authorized by: Mariana Ilinca, Manager of Microbiological Laboratory

Approved by: Alina-Roxana Mihai, General Manager (Approved with qualified electronic signature)

Laboratory: Bucuresti 041914, sos. Berceni nr.8

Responsa bilitatea esantionarii/ prelevarii probelor apartine solicitantului. Rezultatele se refera numai la obiectul supus incercarii. Daca nu se specifica altfel, incertitudinea de masurare a fost estimata pentru coeficientul K= 2 si nivel de incredere 95%. Fara aprobarea scrisa a laboratorului acest raport de incercare nu poate fi reprodus decat integral. Responsabilitatea S.C. J.S. HAMILTON ROMANIA S.R.L. se refera exclusiv la rezultatele si declaratiile prezentate in raportul original. Opiniile si interpretarile continute in prezentul raport de incercare nu sunt acoperite de acreditarea RENAR. Pentru detalii suplimentare va rugam sa solicitati Certificatul de Acreditare la adresa de email bucharest@hamilton.com.pl

* Test method accredited # Test performed by external provider

ø Non accredited methods Page 1 / 1 PGL 09 F 01 Ed. 1 Rev. 2





A) IDENTYFICATION OF THE SAMPLE	
Name of the product/Details about the product	Dezinfectant Universal "Bio-Dez"
	Expiration date: 18.02.2025
	Manufacturer(supplier): Ecochim-Grup S.R.L.
	Store condition: Dry, without sun, 5-25°C.
	Condition of use: Chemical disinfection of certain instrument
	surfaces in the medical area.
Active(s) Substance(s) and its concentration(s)	Ethyl alcool 72-76%, CAS 64-17-5 and CE 200-578-6
	Benzalkonium chloride 0.024- 0.029%, CAS 68424-85-1 and
	CE 270-325-2 Methylthionibium chloride 0.00024%, CAS
	61-73-4 and 200-515-2.
Concentration ordered for the assay	Pure (100%)
B) TEST METHOD	
Performed in accredited subcontracted partner laboratory: Scope	UNE-EN 14561 : 2007. Chemical disinfectants and
of Accreditation Nr. 648/LE1286	antiseptics. Quantitative carrier test for the evaluation of
Report D/22/B0135 Quantitative carrier test for the evaluation of	bactericidal activity for instruments used in the medical area.
bactericidal activity for instruments used in the medical area	Test method and requirements (phase 2, step2). AENOR.
(phase 2, step 2), with the product Dezinfectant Universal	
"Bio-Dez". (UNE-EN 14561: 2007 Standard)	
Testing method	DESIN-1032-b //EN 14561: 2007
Methods of assay and its validation UNE-EN 14561: 2007 Sta	
Method	Dilution-neutralization.
Neutralizer	Tryptone 5 g/L, yeast extract, 2.5 g/L, dextrose 10 g/L,
	sodium thioglycolate 1 g/L, sodium thiosulfate 1 g/L, sodium
	bisulphite 2.5 g/L, soya lecithin 7 g/L, polysorbate-80 5 g/L,
	glycine 1 g/L, l-histidine 1 g/L and saponin 30 g/L.
C) INFORMATION ABOUT SAMPLE RECEPTION	2000/02/04
Date of reception of the sample	2022/03/04
Date of reception of order with test conditions	2022/03/01.
Aspect of the received product	Blue transparent liquid in plastic package.
D) EXPERIMENTAL CONDITIONS	T
Assay period	2022/03/23 to 2022/03/28
Solvent of the product used in the assay	Sterile distilled water
Product concentrations for the assay	Pure (100%), 50% and 0.1%.
Aspect of the dilutions of the product	Pure 100% and 50% blue liquid,
	0.1% transparent liquid.
Contact time	60 seconds
Assay temperature	$20^{\circ}\text{C} \pm 1^{\circ}\text{C}$
Interfering substance	Bovine serum albumin 3 g/L plus erythrocytes 3 mL/L.
Stability of the mixture (interfering substance and product	Stable
diluted in sterile hard water/distilled water)	
Incubation temperature	+36°C ± 1°C
Identification of the strains used:	- Pseudomonas aeruginosa (CECT 116 = ATCC 15442).
	- Staphylococcus aureus (CECT 239 = ATCC 6538).
	- Enterococcus hirae (CECT 4081 = ATCC 10541).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore. *Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay

Evaluation of bactericidal activity See tables 4, 8 and 12.

Number of replicates per assay organism ... 1

Special remarks

- All controls and validation were between the basic limits.
- At least one concentration of the sample showed a log reduction lower than 5 log.
- At least one concentration of the sample showed a log reduction higher than 5 log.
- There was not any precipitation during the assay procedure (the assay mixtures were homogeneous).

Conclusion

The product Dezinfectant Universal "Bio-Dez", batch not indicated, when is pure (100%), shows bactericidal activity after 60 seconds at 20°C ±1°C, under dirty conditions (bovine serum albumin 3 g/L plus erythrocytes 3 mL/L), for *Pseudomonas aeruginosa* (CECT 116 = ATCC 15442), *Staphylococcus aureus* (CECT 239 = ATCC 6538) and *Enterococcus hirae* (CECT 4081 = ATCC 10541), when tested as required by UNE-EN 14561: 2007 Standard.

Note: The results obtained correspond to the sample received in the laboratory.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay with Pseudomonas aeruginosa (CECT 116 = ATCC 15442).

Seeding: Pour plates. No. of plates: 1/mL. Drying time of the slide: 15 minutes.

Table 1.-Validation and controls.

	Suspen alidatio				ol of e conditi			neutralizer (B)			metho ple cor	tion of the hod (C) oncentration:			
	ts per ate	Vc ₁	Vc2	14-20-03-03	ts per ate	Vc1	Vc2	Coun	ts per ate	Vc1	Vc2	400000000000000000000000000000000000000	its per ate	Vc1	Vc2
42	40	42	40	30	31	30	31	35	37	35	37	31	34	31	34
$30 \le 3$ $X = 4$	X of N	v ₀ ≤ 16	50?	7-7-7	$4 \text{ is } \ge X = 30$	77-3	Yof	$X \text{ of } B \text{ is } \ge 0.5 \text{ x } X \text{ of}$ Nv_0 ? $X = 36$			$X \text{ of } C \text{ is } \ge 0.5 \text{ x } X \text{ of } Nv_0? X = 32.5$			of	
	Y	es			Y	es.		Yes Yes			es				

Table 2.-Suspension of the assay.

Suspension of assay (N)	N	Counts	per plate	Vc_1	Vc_2	$Xwm = 1.56 \times 10^9$
	10-7	158 153		158	153	lg N = 9.19 $9.17 \le lg N \le 9.7?$
	10-8	15	16	15	16	Yes

Table 3.-Water control.

	Nw	Counts	per plate	Vc_1	Vc_2	$Xwm \times 10 = 1.55 \times 10^7$
Water control (Nw)	10-5	16	15	16	15	lg Nw = 7.19 7.15 \le $lg Nw \le (lg N-1.3)$? Yes

Table 4.-Results of the activity assays with the sample.

Sample concentration (%)	Dilution	Counts per plate		Vc ₁	Vc2	Lg Na = lg (X o Xwm)+1	Lg R (lgNw = 7.19)	Time of contact (sec)	
	10 ⁰	0	0	<14	<14				
Pure 100%	10 ⁻¹	0	0	<14	<14	C2 15	>5.04	60	
Pule 100%	10 ⁻²	0	0	<14	<14	<2.15	>5.04	00	
	10 ⁻³	0	0	<14	<14				
	10 ⁰	>330	>330	>330	>330				
50%	10 ⁻¹	30	32	30	32	3.49	3.70	60	
30%	10 ⁻²	3	3	<14	<14	3.43	3.70	00	
	10 ⁻³	0	0	<14	<14				
	10 ⁰	>330	>330	>330	>330				
0.1%	10 ⁻¹	>330	>330	>330	>330	> 6.52	<0.67	60	
0.1%	10-2	>330	>330	>330	>330	0.32	~0.07	00	
	10 ⁻³	>330	>330	>330	>330				

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. \varnothing Non accredited methods.



Results of the assay with Staphylocccus aureus (CECT 239 = ATCC 6538).

Seeding: Pour plates. No. of plates: 1/mL; Drying time of the slide: 18 minutes.

Table 5.-Validation and controls.

Suspension of validation (Niv)				Control of experimental conditions (A)				Control of the neutralizer (B)				Validation of the method (C) Sample concentration: Pure			
	its per ate	Vc ₁	Vc2	Coun	ts per ate	Vc ₁	Vc ₂	100000000000000000000000000000000000000	ts per ate	Vc1	Vc2	Counts per plate		Vc1	Vc2
48	51	48	51	39	40	39	40	28	28	28	28	30	28	30	28
$30 \le X \text{ of } Nw \le 160?$ X = 49.5			$X \text{ of } A \text{ is } \ge 0.5 \text{ x } X \text{ of } N_{\text{No}}? X = 39.5$			X of B is $\ge 0.5 \times X$ of Nv_0 ? $X = 28$				$X \text{ of } C \text{ is } \ge 0.5 \text{ x } X \text{ of } Nv_0? X = 29$					
Yes			Yes			Yes				Yes					

Table 6.-Suspension of the assay.

	N	Counts	per plate	Vc1	Vc2	$Xwm = 2.00 \times 10^9$
Suspension of assay (N)	10-7	202	199	202	199	lg N= 9.30 $9.17 \le lg N \le 9.7?$
assay (2.)	10-8	19	19	19	19	Yes

Table 7.-Water control.

	Nw	Counts	per plate	Vc_1	Vc_2	$Xwm \times 10 = 3.35 \times 10^7$			
Water control (Nw)	10-5	32	35	32	35	lg Nw = 7.53 7.15 \le $lg Nw \le (lg N-1.3)$? Yes			

Table 8.-Results of the activity assays with the sample.

Sample concentration (%)	Dilution	Counts p	er plate	Vc ₁	Vc2	Lg Na = 1g (X o Xwm)+1	Lg R (lgNw = 7.53)	Time of contact (sec)
	10 ⁰	0	0	<14	<14			60
Pure 100%	10 ⁻¹	0	0	<14	<14	<2.15	>5.38	
Puie 100%	10 ⁻²	0	0	<14	<14	~2.13		
	10 ⁻³	0	0	<14	<14			
	10 ⁰	>330	>330	>330	>330			60
50%	10 ⁻¹	210	215	210	215	122	3.20	
30%	10 ⁻²	20	22	20	22	4.33		60
	10 ⁻³	2	1	<14	<14			
	10 ⁰	>330	>330	>330	>330			
0.19/	10 ⁻¹	>330	>330	>330	>330	> 6.52	<1.01	60
0.1%	10 ⁻²	>330	>330	>330	>330	- 0.32	~1.01	00
	10 ⁻³	>330	>330	>330	>330			

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. \varnothing Non accredited methods.



Results of the assay with Enterococcus hirae (CECT 4081 = ATCC 10541).

Seeding: Pour plates. No. of plates: 1/mL; Drying time of the slide: 16 minutes.

Table 9.-Validation and controls.

Suspension of validation (Nv ₀)			Control of experimental conditions (A)				Control of the neutralizer (B)				Validation of the method (C) Sample concentration: Pure				
	ts per ate	Vc1	Vc2	1 20	ts per ate	Vc1	Vc2	Counts per Vc1 Vc2 plate			its per ate	Vc1	Vc2		
46	47	46	47	29	28	29	28	31	30	31	30	27	28	27	28
$30 \le X \text{ of } N_{10} \le 160?$ X = 46.5			X of A is $\ge 0.5 \times X$ of No ? $X = 28.5$			X of B is $\ge 0.5 \times X$ of Nwo? $X = 30.5$				$X \text{ of } C \text{ is } \ge 0.5 \text{ x } X \text{ of}$ N_{10} ? $X = 27.5$					
	Y	Yes			Y	es		Yes				Yes			

Table 10.-Suspension of the assay.

	N	Counts	per plate	Vc_1	Vc_2	$Xwm = 1.86 \times 10^9$
Suspension of assay (N)	10-7	189	185	189	185	lg N= 9.27 $9.17 \le lg N \le 9.7?$
	10-8	17	18	17	18	Yes

Table 11.-Water control.

	Nw	Counts	per plate	Vc1	Vc2	$Xwm \times 10 = 1.85 \times 10^7$
Water control (Nw)	10-5	18	19	18	19	lg Nw = 7.27 7.15 \le $lg Nw \le (lg N-1.3)$? Yes

Table 12.-Results of the activity assays with the sample.

Sample concentration (%)	Dilution	Counts p	er plate	Vc ₁	Vc ₂	Lg Na = 1g (X o Xwm)+1	Lg R (lg/Vw = 7.27)	Time of contact (sec)	
	10 ⁰	0	0	<14	<14				
Pure 100%	10 ⁻¹	0	0	<14	<14	<2.15	>5.12	60	
Puie 100%	10 ⁻²	0	0	<14	<14	~2.13		60	
	10 ⁻³	0	0	<14	<14				
	10 ⁰	>330	>330	>330	>330		2.50		
50%	10 ⁻¹	>330	>330	>330	>330	4.77		60	
3076	10 ⁻²	57	60	57	60	4.77		00	
	10 ⁻³	5	6	<14	<14				
	10 ⁰	>330	>330	>330	>330				
0.1%	10 ⁻¹	>330	>330	>330	>330	> 6.52	<0.75	60	
0.1%	10-2	>330	>330	>330	>330	0.52	~0.73		
	10 ⁻³	>330	>330	>330	>330				

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. \varnothing Non accredited methods.



Explanations:

Vc = Count per mL (one or more plates).

X= mean of Vc_1 and Vc_2 .

Xwm = ponderated mean of X;

R (reduction) = ($\lg R = \log Nw - \log Na$).

If $Na \le 140$, $\log R = > [\log Nw - 2.15]$

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page $\mathbf{6}$ of $\mathbf{6}$

Date: 05.04.2022

Authorized by: Mariana Ilinca, Manager of Microbiological laboratory

Aprobat de: Mihai Alina-Roxana, General manager (Approved with qualified electronic signature)



REPORT OF ANALYSIS No. 92190/22/ROBCH

Client		Sample number:					
ECOCHIM-GRUP SRL		92190/22/ROBCH					
OR. OTACI, STR. VOITOVIC	I 21	Sample description (according to declaration of Client)					
2059 CHIŞINĂU		Dezinfectant Universal "Bio-Dez"					
		Lot/Batch: -					
		Production date: 21.09.2022					
		Expiration date: 21.09.2025					
		Sampling date: 29.09.2022					
		Sampling quantity: 1x 500ml					
		Sample temperature: 17°C					
		Reception hour: 12:30					
Table 18 18 18	Taxa era era era	Responsible for sampling: Crestinov Alexandr					
Sample received:	18.10.2022	Sample condition with no objections					
Tests performed: 19.10.2022							
Tests completed:	09.12.2022	Order of 18.10.2022					
Report dated:	09.12.2022	Sampling and delivery were carried out by client.	-				

Test	Method	Unit	Result
# * Chemical disinfectants and antiseptics. Quantitative carrier test for the evaluation of bactericidal activity for instruments used in the medical area. Test method and requirements (phase 2, step 2)	EN 14562:2007	<u>u</u>	Test method performed by the subcontractor; the results are taken in full from the test report No D/22/B0669, issued by the subcontractor. The results of the analysis are listed starting with enclosure No1 to report of analysis.

Elaborated by: Mariana Ilinca, Manager of Microbiological Laboratory Authorized by: Mariana Ilinca, Manager of Microbiological Laboratory

Approved by: Alina-Roxana Mihai, General Manager (Approved with qualified electronic signature)

Laboratory: Bucuresti 041914, sos. Berceni nr.8

Responsa bilitatea esantionarii/ prelevarii probelor apartine solicitantului. Rezultatele se refera numai la obiectul supus incercarii. Daca nu se specifica altfel, incertitudinea de masurare a fost estimata pentru coeficientul K = 2 si nivel de incredere 95%. Fara aprobarea scrisa a laboratorului acest raport de incercare nu poate fi reprodus decat integral. Responsabilitatea S.C. J.S. HAMILTON ROMANIA S.R.L. se refera exclusiv la rezultatele si declaratiile prezentate in raportul original. Opiniile si interpretarile continute in prezentul raport de incercare nu sunt acoperite de acreditarea RENAR. Pentru detalii suplimentare va rugam sa solicitati Certificatul de Acreditare la adresa de email bucharest@hamilton.com.pl

* Test method accredited # Test performed by external provider

ø Non accredited methods Page 1 / 1 PGL 09 F 01 Ed. 1 Rev. 2





A) IDENTYFICATION OF THE SAMPLE Name of the product/Details about the product	Dezinfectant Universal "Bio-Dez".
Name of the product Details about the product	Manufacturer(supplier): Ecochim-Grup.
	Store condition: Dry, without sun, 5-25 Celsius degree.
	Condition of use: PT2 product in the medical area.
	Solvent of the product recommended by the manufacturer
	Undiluted.
Active(s) Substance(s) and its concentration(s)	Ethyl alcool 72-76%, CAS 64-17-5 and CE 200-578-6
Active(s) substance(s) and its concentration(s)	Benzalkonium chloride 0.024-0.029%, CAS 68424-85-1 and
	CE 270-325-2; Methylthionibium chloride 0.00024%, CAS
	61-73-4 and 200-515-2.
Concentration ordered for the assay	Ready to use (100%).
B) TEST METHOD	reday to use (10070).
Performed in accredited subcontracted partner laboratory: Scope	EN 14562: 2007. Chemical disinfectants and antiseptics -
of Accreditation Nr. 648/LE1286	Quantitative carrier test for the evaluation of the antifungal o
Report D/22/B0669 Quantitative carrier test for evaluation of the	yeasticidal activity of chemical disinfectants for instrument
fungicidal activity of chemical disinfectants for instruments used	used in the medical area. Test methods and requirement
in the medical area (phase 2, step 2), with the product	(phase 2/step 2).
"Dezinfectant Universal "Bio-Dez". (EN 14562: 2007 Standard)	(F
Testing method	DESIN-1059-b // EN 14562: 2007
Methods of assay and its validation EN 14562: 2007 Standard	
Method	Dilution-neutralization.
Neutralizer	Tryptone 5 g/L, yeast extract, 2.5 g/L, dextrose 10 g/L
	sodium thioglycolate 1 g/L, sodium thiosulfate 1 g/L, sodium
	bisulphite 2.5 g/L, soya lecithin 7 g/L, polysorbate-80 5 g/L
	glycine 1 g/L, 1-histidine 1 g/L and saponin 30 g/L.
C) INFORMATION ABOUT SAMPLE RECEPTION	
Date of reception of the sample	2022/10/19
Date of reception of order with test conditions	2022/10/24.
Aspect of the received product	Blue liquid in a plastic package.
D) EXPERIMENTAL CONDITIONS	
Assay period	2022/11/15 to 2022/11/25.
Solvent of the product used in the assay	Sterile distilled water
Product concentrations for the assay	100%, 50% and 0.1%.
Aspect of the dilutions of the product	100% and 50%: Blue liquid;
	0.1%: Transparent liquid
Contact time	90 seconds
Assay temperature	$20^{\circ}\text{C} \pm 1^{\circ}\text{C}$
Interfering substance	Bovine serum albumin 3 g/L + 3 ml/L erythrocytes
Stability of the mixture (interfering substance and product	Stable
diluted in sterile hard water/distilled water)	
Incubation temperature	+30°C □ 1°C
Drying time of the slides	C.albicans: 35 minutes.
	A.brasiliensis: 37 minutes
Identification of the strains used:	-Aspergillus brasiliensis (CECT 2574 = ATCC 16404).
	-Candida albicans (CECT 1394 = ATCC 10231).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore. *Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



ENCLOSORE NO. 1 SUBCONTRACTED TESTS TO REPORT OF ANALYSIS NO 92190/22/ROBCH Results of the assay

Number of replicates per assay organism 1.

Special remarks

- All controls and validation were between the basic limits.
- At least one concentration of the sample showed a log reduction lower than 4 log.
- At least one concentration of the sample showed a log reduction higher than 4 log.
- There was not any precipitation during the assay procedure (the assay mixtures were homogeneous).
- The test meets the criteria of the BPR Guidance for PT2 products in the medical area

Conclusion

The product "Dezinfectant Universal "Bio-Dez"", batch 92190/22/robch, when it is pure (100%), concentration requested by the client, shows fungicidal activity after 90 seconds at 20°C ±1°C, under dirty conditions (bovine serum albumin 3 g/L + 3 ml/L erythrocytes), for the reference strains Aspergillus brasiliensis (CECT 2574 = ATCC 16404) and Candida albicans (CECT 1394 = ATCC 10231), when tested as required by EN 14562: 2007 Standard.

Note: The results obtained correspond to the sample received in the laboratory.

Use of the ENAC mark: The ENAC "mark" can only be used by the holder of the accreditation. Its use in packaging, installations, shop windows, advertising or other documentation format other than that issued by the accredited entity (IVAMI) is not allowed.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay with Aspergillus brasiliensis (CECT 2574 = ATCC 16404)

Drying time of the slide: 37 minutes (no longer than 60 minutes).

Seeding: Pour plates: No. of plates: 4/mL

Table 1.-Validation and controls

	S <mark>uspens</mark> alidation				experim	control of the neutralizer (B) tions (A)					Validation of the method (C) Sample concentration 100%				
	its per ate	Vc ₁	Vc ₂	1 - 3 -	its per ate	Vc ₁	Vc ₂	Counts per Vc1 Vc2 plate		1.5	ts per ate	Vc1	Vc ₂		
12+10+ 12+11	11+11+ 10+10	45	42	9+12+ 10+10	9+9 +11+10	41	39	10+10+ 9+9	11+10+ 9+9	38	39	8+7 +8+8	8+9 +8+8	31	33
30 ≤ X	$X ext{ of } Nv_0$ X = 4)?		$A \text{ is } \ge 0$ Nv_0 ? X		X of	100	$B \text{ is } \ge 0$			$X \text{ of } C \text{ is } \ge 0.5 \text{ x.}$ Nv_0 ? $X = 32$			Cof
	Yes	S			Yes	3			Yes	S			Yes		

Table 2.-Suspension of the assay

Suspension of assay (N)	N	Counts	per plate	Vc1	Vc_2	$Xwm = 2.52 \times 10^8$	
	10-6	66+52+53 +76	60+59+66+ 73	247	258	lg N = 8.40 $ig 8.17 \le lg N \le 8.7?$	
	10-7	6+6+6+6	6+7+6+7	24	26	Yes	

Table 3.-Water control

2007 (2007) (2007) (2007) (2007) (2007)	Nw	Counts	per plate	Vc1	Vc_2	$Xwm \times 10 = 6.80 \times 10^6$
(Nw)	10-4	18+17+17 +16	18+16+18+ 16	68	68	lg Nw = 6.83 6,15 \le $lg Nw \le (lgN-1.3)$? Yes

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. \emptyset Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



ENCLOSORE NO. 1 SUBCONTRACTED TESTS TO REPORT OF ANALYSIS NO 92190/22/ROBCH Table 4.-Results of the activity assays with the sample

Sample concentration (%)	Dilution Counts per plate			Vc1	Vc2	Lg Na = lg (X o Xwm) +1	Lg R (lg/Vw = 6.83)	Time of contact (seconds)	
8 8 1	10°	0+0+0+0	0+0+0+0	<14	<14		E 15.00	90	
1000/	10-1	0+0+0+0	0+0+0+0	<14	<14	20.15	~ 4.60		
100%	10-2	0+0+0+0	0+0+0+0	<14	<14	<2.15	>4.68		
÷	10-3	0+0+0+0	0+0+0+0	<14	<14	1			
	10°	>165+>165+ >165+>165	>165+>165+ >165+>165	>660	>660		1.41	90	
50%	10-1	>165+>165+ >165+>165	>165+>165+ >165+>165	>660	>660	5.42			
3076	10-2	65+70 +69+65	71+65 +61+66	269	263	3.42			
Ē	10 ⁻³	6+5+6+6	7+6+5+6	23	24	Ti .			
	100	>165+>165+ >165+>165	>165+>165+ >165+>165	>660	>660		S. 3.		
0.19/	10-1	>165+>165+ >165+>165	>165+>165+ >165+>165	>660	>660	>6.82	<0.01	00	
0.1%	10-2	>165+>165+ >165+>165	>165+>165+ >165+>165	>660	>660		<0.01	90	
	10-3	>165+>165+ >165+>165	>165+>165+ >165+>165	>660	>660				

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore. *Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay with Candida albicans (CECT 1394 = ATCC 10231)

Drying time of the slide: 35 minutes (no longer than 60 minutes).

Seeding: Pour plates; No. of plates: 1/mL

Table 5.-Validation and controls

		nsion (N		Control of experimental conditions (A) Control of the neutralizer (B)						100		Validation of the method (C) Sample concentration 100%				
Coun		Vc1	Vc2	Cour per p		Vc1	Vc2	Coun		Vc1	Vc_2	Cour per p		Vc1	Vc_2	
40	37	40	37	35	33	35	33	30	33	30	33	29	31	29	31	
$30 \le 3$		$v_0 \leq 1$	60?	1,5000000000	X of A is $\geq 0.5 \times X$ of Nv_0 ? $X = 34$			$X \text{ of } B \text{ is } \ge 0.5 \text{ x } X \text{ of}$ Nv_0 ? $X = 31.5$				$X \text{ of } C \text{ is } \ge 0.5 \text{ x } X \text{ of}$ Nv_0 ? $X = 30$				
	Y	es		Yes					Yes				Yes			

Table 6.-Suspension of the assay

Suspension of assay (N)	N	Counts	per plate	Vc1	Vc2	$Xwm = 1.61 \times 10^8$ $\lg N = 8.21$
	10-6	168	156	168	156	$8.17 \le \lg N \le 8.7?$
	10-7	16	15	16	15	Yes

Table 7.-Water control

Water control (Nw)	Nw	Counts	per plate	Vc ₁	Vc2	$Xwm \times 10 = 5.25 \times 10^6$
	10-4	53	52	53	52	lg Nw= 6.72 6.15 ≤ lg N-1.3? Yes

Table 8.-Results of the activity assays with the sample

Sample concentration (%)	Dilution	Counts p	er plate	Vc ₁	Vc ₂	Lg Na = lg (X o Xwm) +1	Lg R (lgNw = 6.72)	Time of contact (seconds)
	10 ⁰	0	0	<14	<14		>4.57	
100%	10 ⁻¹	0	0	<14	<14	<2.15		90
100%	10 ⁻²	0	0	<14	<14	~2.13	~ 4 .37	90
	10 ⁻³	0	0	<14	<14			
	10 ⁰	0	0	<14	<14		>4.57	00
50%	10 ⁻¹	0	0	<14	<14	<2.15		
30%	10 ⁻²	0	0	<14	<14	~2.13	>4.57	90
	10 ⁻³	0	0	<14	<14			
	10 ⁰	>330	>330	>330	>330			
0.1%	10 ⁻¹	>330	>330	>330	>330	5.93	0.79	90
0.1%	10 ⁻²	>330	>330	>330	>330	3.93	0.79	90
	10 ⁻³	86	84	86	84			

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



Explanations:

Vc = Count per mL (one or more plates).

X= mean of Vc_1 and Vc_2 .

Xwm = Weighted mean of X; R (reduction) = ($\lg R = \log Nw - \log Na$).

If Na < 140, $\log R = > [\log Nw - 2.15]$

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page **6** of **6**

Date: 08.12.2022

Authorized by: Mariana Ilinca, Manager of Microbiological laboratory

Aprobat de: Mihai Alina-Roxana, General manager (Approved with qualified electronic signature)



REPORT OF ANALYSIS No. 16418/22/ROBCH

Client		Sample number:	
ECOCHIM-GRUP SRL		16418/22/ROBCH	
OR. OTACI, STR. VOITOVIC	1 21	Sample description (according to declaration of Client)	
2059 CHIŞINĂU		Dezinfectant Universal "Bio-Dez"	
		Lot: FABR.08.2020	
		Data fabricatie: -	
		Data expirarii: 18.02.2025	
		Data prelevarii:18.02.2022	
		Cantitate prelevata: 3 x 500 ml	
		Responsabil prelevare: Crestinov Alexandr	
		Ora receptiei probei: -	
1 1 1000 10 10 10	Property appropriate accept	Temperatura receptie proba: 15°C	
Sample received:	01.03.2022	Sample condition with no objections	
Tests performed:	01.03.2022		
Tests completed:	16.06.2022	Order of 01.03.2022	
Report dated:	16.06.2022	Sampling and delivery were carried out by client.	

Test	Method	Unit	Result
# * Quantitative carrier test for the evaluation of mycobactericidal or tuberculocidal activity of chemical disinfectants and antiseptics used in the medical area	UNE-EN 14563:2009	ш	Test method performed by the subcontractor; the results are taken in full from the test report No D/22/B0134, issued by the subcontractor. The results of the analysis are listed starting with enclosure No1 to report of analysis.

Elaborated by: Mariana Ilinca, Manager of Microbiological Laboratory Authorized by: Mariana Ilinca, Manager of Microbiological Laboratory

Approved by: Alina-Roxana Mihai, General Manager (Approved with qualified electronic signature)

Laboratory: Bucuresti 041914, sos. Berceni nr.8

Responsa bilitatea esantionarii/ prelevarii probelor apartine solicitantului. Rezultatele se refera numai la obiectul supus incercarii. Daca nu se specifica altfel, incertitudinea de masurare a fost estimata pentru coeficientul K= 2 si nivel de incredere 95%. Fara aprobarea scrisa a laboratorului acest raport de incercare nu poate fi reprodus decat integral. Responsabilitatea S.C. J.S. HAMILTON ROMANIA S.R.L. se refera exclusiv la rezultatele si declaratiile prezentate in raportul original. Opiniile si interpretarile continute in prezentul raport de incercare nu sunt acoperite de acreditarea RENAR. Pentru detalii suplimentare va rugam sa solicitati Certificatul de Acreditare la adresa de email bucharest@hamilton.com.pl

* Test method accredited # Test performed by external provider

ø Non accredited methods Page 1 / 1 PGL 09 F 01 Ed. 1 Rev. 2





A) IDENTYFICATION OF THE SAMPLE Name of the product/Details about the product	Dezinfectant Universal "Bio-Dez"
Name of the product/Details about the product	
	Expiration date: 18.02.2025
	Manufacturer(supplier): Ecochim-Grup S.R.L.
	Store condition: Dry, without sun, 5-25°C.
	Condition of use: Chemical disinfection of certain instrumen
	surfaces in the medical area.
Active(s) Substance(s) and its concentration(s)	Ethyl alcool 72-76%, CAS 64-17-5 and CE 200-578-6 Benzalkonium chloride 0.024- 0.029%, CAS 68424-85-1 and CE 270-325-2 Methylthionibium chloride 0.00024%, CAS 61-73-4 and 200-515-2.
Concentration ordered for the assay	Pure (100%)
B) TEST METHOD	. ,
Performed in accredited subcontracted partner laboratory: Scope	UNE-EN 14563: 2009. Chemical disinfectants and
of Accreditation Nr. 648/LE1286	antiseptics. Quantitative carrier test for the evaluation of
Report D/22/B0134 Quantitative carrier test for the evaluation of	mycobactericidal or tuberculocidal activity of chemical
mycobactericidal and tuberculocidal activity of chemical	disinfectants used for instruments in the medical area. Tes
disinfectants used for instruments in the medical area (phase 2,	method and requirements (phase 2, step 2).
step 2), with the product Dezinfectant Universal "Bio-Dez" .	method and requirements (phase 2, step 2).
(UNE-EN 14563 : 2009 Standard)	
Testing method	DESIN-1054-b //EN 14563: 2009
Methods of assay and its validation UNE-EN 14561: 2007 Star	
Method	Dilution-neutralization.
Neutralizer	
	Tryptone 5 g/L, yeast extract, 2.5 g/L, dextrose 10 g/L sodium thioglycolate 1 g/L, sodium thiosulfate 1 g/L, sodium bisulphite 2.5 g/L, soya lecithin 7 g/L, polysorbate-80 5 g/L glycine 1 g/L, l-histidine 1 g/L and saponin 30 g/L.
C) INFORMATION ABOUT SAMPLE RECEPTION	
Date of reception of the sample	2022/03/04
Date of reception of order with test conditions	2022/03/01.
Aspect of the received product	Blue transparent liquid in plastic package.
D) EXPERIMENTAL CONDITIONS	
Assay period	2022/03/02 to 2022/04/13 (Including prior preparation of the
The state of the s	strains).
Solvent of the product used in the assay	Sterile distilled water
Product concentrations for the assay	Pure (100%), 50% and 0.1%.
Aspect of the dilutions of the product	Pure (100%) and 50% blue transparent liquid; 0.1%
Aspect of the dilutions of the product	transparent liquid.
Contact time	60 seconds
	$20^{\circ}\text{C} \pm 1^{\circ}\text{C}$
Assay temperature	
Interfering substance	Bovine serum albumin 3 g/L plus erythrocytes 3 mL/L.
Stability of the mixture (interfering substance and product diluted in sterile hard water/distilled water)	Stable
Incubation temperature	$+36^{\circ}\text{C} \pm 1^{\circ}\text{C}$
	1.6 1
Identification of the strains used:	- Mycobacterium avium (ATCC 15769).- Mycobacterium terrae (CECT 3028 = ATCC 15755).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore. *Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay

Evaluation of mycobactericidal activity..... See table 4 and 8

Number of replicates per assay organism .. 1.

Special remarks

- All controls and validation were between the basic limits.
- One concentration of the sample at least showed a log reduction less than 4 log.
- One concentration of the sample at least showed a log reduction higher than 4 log.

Conclusion

The product Dezinfectant Universal "Bio-Dez", batch not indicated, when is pure (100%), shows mycobactericidal activity after 60 seconds at 20°C under dirty conditions (bovine serum albumin 3 g/L and erythrocytes 3 mL/L), against the reference strains Mycobacterium avium (ATCC 15769) and Mycobacterium terrae (CECT 3028 = ATCC 15755), when tested as required by UNE-EN 14563: 2009 Standard.

Note: The results obtained correspond to the sample received in the laboratory.

Quality Assurance Review:

The assay development and the results obtained have been supervised by the Director of the study.

The Quality Assurance Director has inspected the development of the assay, proving that has been realized following the proper procedure and using the adequate media, materials and reagents, following the Good Laboratory Practices (GLPs) as well and the final report contains the primary data obtained.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Page 2 of 5

Enclosore no. 1 subcontracted tests



Results of the assay with Mycobacterium avium (ATCC 15769).

Time of dryness of carriers: 32 minutes (no longer than 60 minutes).

Seeding: Spread plate; No. of plates: 2/mL

Table 1.-Validation and controls

	Suspension of validation (Nv ₀) Control of experimental conditions (A)				Control of the neutralizer (B)			Validation of the method (C) Sample concentration: Pure							
Coun plate	ts per	Vc1	Vc2	Coun	its per	Vc1	Vc2	Coun	ts per	Vc1	Vc2	Coun	ts per	Vc1	Vc2
47 + 52	56 + 49	99	105	45 + 48	46 + 51	93	97	42 + 47	49 + 44	89	93	44 + 46	43 + 41	90	84
	$30 \le X \text{ of } Nv_0 \le 160?$ $X \text{ of } A \text{ is } \ge 0.5 \text{ x } X \text{ de}$ $X = 102$ $Nv_0? X = 95$				$X \text{ of } B \text{ is } \ge 0.5 \text{ x } X \text{ of } Nv_0? X = 91$			$X \text{ of } C \text{ is } \ge 0.5 \text{ x } X \text{ of } N_{0}? X = 87$							
	Ye	es		Yes			Yes			Yes					

Table 2.-Suspension of the assay

	N	N Counts per plate			Vc2	$X_{wm} 4.45 \times 10^9$
Suspension of assay (N)	10-7	223 + 214	230 + 222	437	452	lg N = 9.65 $9.17 \le lg N \le$
	10-8	21 + 23	24 + 23	44	47	9.7? Yes

Table 3.-Water control

	Nw	Counts	per plate	Vc_1	Vc2	Xwm 8.2 x 107
Water control (Nw)	10-4	>330 + >330 + >330 >330		>660	>660	lg Nw = 7.91 6.15 $\leq lg Nw$
	10-5	37 + 43	45 + 39	80	84	≤lg N –1.3? Yes

Table 4.-Results of the activity assays with the sample

Sample concentration (%)	Dilution	Counts	Counts per plate Vc1 Vc2		Lg Na = lg (X o Xwm)+1	Lg R (lgNw = 7.91)	Time of contact (sec)	
et contra	10 ⁰	0+0	0+0	< 14	< 14	10		
Des (1009/)	10-1	0+0	0+0	< 14	< 14	< 2.15	>5.76	60
Pure (100%)	10-2	0+0	0+0	< 14	< 14	< 2.15		
	10-3	0+0	0+0	< 14	< 14			
	10 ⁰	0+0	0+0	< 14	< 14		>5.76	60
500/	10-1	0+0	0+0	< 14	< 14	< 2.15		
50%	10-2	0+0	0+0	< 14	< 14	< 2.15		
	10-3	0+0	0+0	< 14	< 14			
	10 ⁰	>330+>330	>330+>330	>660	>660			
0.1%	10-1	>330+>330	>330+>330	>660	>660	>6.02	<1.00	60
	10-2	>330+>330	>330+>330	>660	>660	>6.82	<1.09	60
	10-3	>330+>330	>330+>330	>660	>660			

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Page 3 of 5

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. \emptyset Non accredited methods.



Results of the assay with Mycobacterium terrae (CECT 3028 = ATCC 15755).

Time of dryness of carriers: 29 minutes (no longer than 60 minutes).

Seeding: Spread plate; No. of plates: 2/mL

Table 5.-Validation and controls

	Suspension of validation (Nv ₀) Control of experimental conditions (A)				Control of the neutralizer (B)			Validation of the method (C) Sample concentration: Pure							
Coun plate	its per	Vc1	Vc2	Coun plate	ts per	Vc1	Vc2	Coun	ts per	Vc1	Vc2	Counts per plate		Vc1	Vc2
49 + 54	50 + 48	103	98	41 + 44	44 + 48	85	92	43 + 37	45 + 41	80	86	39 + 43	38 + 39	82	77
$30 \le X \text{ of } Nv_0 \le 160$? $X \text{ of } A \text{ is } \ge 0.5 \text{ x } X \text{ de}$ $X = 100.5$ Nv_0 ? $X = 88.5$				$X \text{ of } B \text{ is } \ge 0.5 \text{ x } X \text{ of}$ Nv_0 ? $X = 83$			Yof	$X \text{ of } C \text{ is } \ge 0.5 \text{ x } X \text{ of } N_{V0}? X = 79.5$							
	Ye	s		Yes			Yes			Yes					

Table 6.-Suspension of the assay

	N	Counts	Vc1	Vc2	Xwm 3.91 x 109	
Suspension of assay (N)	10-7	207 + 193	187 + 199	400	386	$\lg N = 9.59$ $9.17 \le \lg N \le$
	10-8	21 + 18	17 + 19	39	36	9.7? Yes

Table 7.-Water control

	Nw	Counts	per plate	Vc1	Vc_2	Xwm 6.25 x 107
Water control (Nw)	10-4	>330 + >330	>330 + >330	>660	>660	$\lg N_W = 7.80$ 6.15 $\leq \lg N_W$
	10-5	30 + 31	33 + 31	61	64	≤lg N-1.3? Yes

Table 8.-Results of the activity assays with the sample

Sample concentration (%)	Dilution	Counts 1	ounts per plate Vc1 Vc2		Lg Na = lg (X o Xwm)+1	Lg R (lgNw = 7.80)	Time of contact (sec)	
	10 ⁰	0+0	0+0	< 14	< 14			60
D (1000/)	10-1	0+0	0+0	< 14	< 14	-015	>5.65	
Pure (100%)	10-2	0+0	0+0	< 14	< 14	< 2.15		
	10-3	0+0	0+0	< 14	< 14			
	10 ⁰	185 +172	190 + 179	357	369		3.24	60
50%	10 ⁻¹	15 + 17	18 + 16	32	34	456		
30%	10-2	1 + 2	2+0	< 14	< 14	4.56		
	10-3	0+0	0+0	< 14	< 14			
	10 ⁰	>330+>330	>330+>330	>660	>660			
0.1%	10-1	>330+>330	>330+>330	>660	>660	- 6.00	<0.00	60
	10-2	>330+>330	>330+>330	>660	>660	>6.82	<0.98	60
	10-3	>330+>330	>330+>330	>660	>660	1		

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page **4** of **5**

^{*}Test method accredited # Test performed by subcontractor. \varnothing Non accredited methods.



Explanations:

Vc = Count per mL (one or more plates). X= mean of Vc_1 and Vc_2 . Xwm = Weighted mean of X; R = reduction ($\lg R = \lg Nw - \lg Na$). If Na < 140, $\lg R = > [\lg Nw - 2.15]$

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. \varnothing Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

PGL 09 F 04 Ed. 1 Rev. 0

Page 5 of 5

Authorized by: Mariana Ilinca, Manager of Microbiological laboratory Aprobat de: Mihai Alina-Roxana, General manager (Approved with qualified electronic signature)



RAPORT DE INCERCARE NR. 34692/23/ROBCH

Client		Numărul eșantionului:
ECOCHIM-GRUP SRL		34692/23/ROBCH
STRADA PETRICANI 21/3		Descriere obiect de incercat (conform cu declaratia Clientului)
2059 CHIŞINĂU		Dezinfectant Universal "Bio-Dez"
		Lot: -
		Cantitate prelevata:500 ml
		Responsabil prelevare: Cristinov Alexandr
		Ora receptiei probei: 08:00
		Temperatura receptie proba: 15°C
Data primirii obiectului de incercat:	17.05.2023	Sample condition with no objections
Data inceperii incercarii:	26.05.2023	
Data finalizarii incercarii:	07.11.2023	Comanda din 17.05.2023
Data eliberarii raportului:	07.11.2023	Probele au fost prelevate si livrate de catre Client.

Parametrii de testare	Metoda de testare	Unitate de masura	Rezultat
			Test method performed by the
			subcontractor; the results are taken in
# * Quantitative suspension test for			full from the test report No D/23/
the evaluation of bactericidal activity	EN 13727:2012+A2:2015	-	B0419, issued by the subcontractor.
in medical area			The results of the analysis are listed
			starting with enclosure No1 to report
			of analysis.

Responsabil incercare: Mariana Ilinca, Sef Laborator Microbiologie Validat de: Mariana Ilinca, Sef Laborator Microbiologie

Autorizat de: Alina-Roxana Mihai, General Manager (Aprobat cu semnatura electronica)

Laborator: Bucuresti 041914, sos. Berceni nr.8

Responsabilitatea esantionarii/ prelevarii probelor apartine solicitantului. Rezultatele se refera numai la obiectul supus incercarii. Daca nu se specifica altfel, incertitudinea de masurare a fost estimata pentru coeficientul K= 2 si nivel de incredere 95%. Fara aprobarea scrisa a laboratorului acest raport de incercare nu poate fi reprodus decat integral. Responsabilitatea S.C. J.S. HAMILTON ROMANIA S.R.L. se refera exclusiv la rezultatele si declaratiile prezentate in raportul original. Opiniile si interpretarile continute in prezentul raport de incercare nu sunt acoperite de acreditarea RENAR. Pentru detalii suplimentare va rugam sa solicitati Certificatul de Acreditare la adresa de email bucharest@hamilton.com.pl

st Metoda de testare acreditata # Test efectuat de catre subcontractor

ø Incercari neacreditate Pagina 1/1 PGL 09 F 01 Ed. 1 Rev. 3





A) IDENTYFICATION OF THE SAMPLE	
Name of the product/Details about the product	Dezinfectant Universal "Bio-Dez".
	Manufacturer(supplier): Ecochim-Grup
	Condition of use: Instrument disinfection, surface
	disinfection, Hygienic handrub, surgical handrub.
Active(s) Substance(s) and its concentration(s)	Ethyl alcool 72-76%, CAS 64-17-5 and CE 200-578-6
(-)	Benzalkonium chloride 0.024-0.029%, CAS 68424-85-1 and
	CE 270-325-2 Methylthionibium chloride 0.00024%, CAS
	61-73-4 and 200-515-2.
Concentration ordered for the assay	97%, 80%.
B) TEST METHOD	
Performed in accredited subcontracted partner laboratory: Scope	EN 13727: 2012 + A2: 2015. Chemical disinfectants and
of Accreditation Nr. 648/LE1286	antiseptics. Quantitative suspension test for the evaluation of
Report No.: D/23/B0419– Quantitative evaluation assay of the	bactericidal activity of chemical disinfectants for instruments
bactericidal activity in the medical area (phase 2, step 1), with	used in Medicine. Test method and requirements (phase 2,
the product "Dezinfectant Universal "Bio-Dez"". (EN 13727:	step 1).
2012 + A2: 2015 Standard)	
Testing method	EN 13727: 2012 + A2: 2015 Standard
Methods of assay and its validation UNE-EN 13727: 2012 + A2	
Method	Dilution-neutralization.
Neutralizer	Tryptone 5 g/L, yeast extract 2.5 g/L, dextrose 10 g/L,
	sodium thioglycolate 1 g/L, sodium thiosulfate 1 g/L, sodium
	bisulphite 2.5 g/L, soya lecithin 7 g/L, polysorbate-80 5 g/L,
	glycine 1 g/L, l-histidine 1 g/L and saponin 30 g/L.
C) INFORMATION ABOUT SAMPLE RECEPTION	0000/07/10
Date of reception of the sample	2023/05/18.
Date of reception of order with test conditions	2023/08/30.
Aspect of the received product	Blue liquid in plastic container.
D) EXPERIMENTAL CONDITIONS	
Assay period	2023/10/11 to 2023/10/15.
Solvent of the product used in the assay	Sterile distilled water.
Product concentrations for the assay	97%, 80%, 50% and 0.1%.
Aspect of the dilutions of the product	97%, 80% and 50% blue liquid;
	0.1% transparent liquid
Contact time	60 seconds.
Assay temperature	20°C ± 1°C
Interfering substance	Bovine serum albumin 3 g/L + erythrocytes 3 mL/L.
Stability of the mixture (interfering substance and product	97% flocs formation;
diluted in sterile distilled water)	80%, 50% and 0.1% stable.
Incubation temperature	$+36^{\circ}\text{C} \pm 1^{\circ}\text{C}$
Identification of the strains used:	– Pseudomonas aeruginosa CECT-116 (ATCC-15442).
	- Staphylococcus aureus CECT-239 (ATCC-6538).
	- Enterococcus hirae CECT-4081 (ATCC-10541).
	- <i>Escherichia coli</i> K12 (CECT 433 = NCTC 10538).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore. *Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania $Tel. + 40\ 21\ 634\ 10\ 81\ bucharest@hamilton.com.pl,\ www.hamilton.com.pl$

Enclosore no. 1 subcontracted tests



Results of the assay

Special remarks

- All controls and validation were between the basic limits.
- For a valid test, at least one concentration must show a log reduction lower than 5 log, and at least one concentration must show a log reduction equal or higher than 5 log.
- Flocs formation is observed during the test procedure at 97%.
- The client requests the complete test including the concentration of 80% as the maximum concentration. It also requests the modified method (97%) additionally.

Conclusion

The product Dezinfectant Universal "Bio-Dez", batch 34692/23/ROBCH, when it is pure (97%) (modified method) and 80%, concentrations requested by the client, shows bactericidal activity after 60 seconds at 20°C ± 1°C, under dirty conditions (bovine serum albumin 3 g/L and erythrocytes 3 mL/L), for the reference strains *Pseudomonas aeruginosa* (CECT 116 = ATCC 15442), *Staphylococcus aureus* (CECT 239 = ATCC 6538), *Enterococcus hirae* (CECT 4081 = ATCC 10541) and *Escherichia coli* K12 (CECT 433 = NCTC 10538), when tested according to EN 13727: 2012 + A2: 2015 Standard.

Note: The results obtained correspond to the sample received in the laboratory.

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay (Bactericidal suspension) with *Pseudomonas aeruginosa* (CECT 116 = ATCC 15442).

Seeding: Pour plates. No. of plates: 1 /mL.

Table 1.-Validation and controls

	ispensio idation		ez	Control perime ndition	ntal	100,000	ontrol o ralizat	of the ion (B)	E	idation on nethod (e concen 80%	30071100
Vc1	44	X= 42	Vcı	36	X= 35	Vc1	38	X=	Vc1	32	X= 33
Vc2	40		Vc2	34		Vc2	37	37.5	Vc2	34	
30 ≤ <i>X</i>	of Nv ₀ :	≤ 160?	Xof	A is ≥ 0 Nv₀? Yes		Xof	B is ≥ (Nv ₀ ? Yes		Xof	C is ≥ 0. Nv ₀ ? Yes	5 X of
	sp <mark>en</mark> sio dation		Vc1	:40 V	c ₂ : 39		X = 39 c of Nv_1 160? Y	$_{\rm B}/1000 \le$			

Table 2.-Suspension of the assay

	N	Vc1	Vc2	$Xwm = 1.68 \times 10^8$, $\lg N = 8.22$
Suspension of assay (N and No)	10-6	164	171	$N_0 = N/10$; $\log N_0 = 7.22$
	10-7	18	16	$7.17 \le \lg N_0 \le 7.70$? Yes

Table 3.-Results of the activity assays with the sample

Concentrations of the sample (%)	Dilutions steps	Vc_1	Vc2	$Lg Na = lg$ $(X \times 10 \text{ o}$ $Xwm \times 10)$	Lg R (Lg N ₀ =7.22)	Time of contact (sec)
900/	Na^0	<14	<14	Ø 15	>5.07	60
80%	Na -1	<14	<14	<2.15	>5.07	60
500/	Na ⁰	<14	<14	~ 15	>5.07	60
50%	Na -1	<14	<14	<2.15	>5.07	60
0.1%	Na ⁰	>330	>330	>4.50	-0.70	60
0.1%	Na ⁻¹	>330	>330	>4.52	<2.70	60

Explanations:

Vc = number per mL (one or two plates); Xwm = weighted mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1 + 2);$

Logarithmic reduction R: ($\lg R = \lg N_0 - \lg N_a$).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



Results of the assay (Bactericidal suspension) with *Pseudomonas aeruginosa* (CECT 116 = ATCC 15442) following the modified method (97%).

Seeding: Pour plates. No. of plates: 1 /mL.

Table 4.-Validation and controls

	ispensio idation		ez	Control perime ndition	ntal		ontrol o ralizat	of the ion (B)	n	idation on nethod (e concen 97%	111
Vc1	42	X= 41	Vcı	37	X= 36	Vc1	31	X= 32	Vc1	30	X= 31
Vc2	40		Vc2	35	3 1	Vc2	33		Vc2	32	
30 ≤ <i>X</i>	of N ₀ :	≤ 160?	Xof	A is ≥ 0 Nv ₀ ? Yes		X of	B is ≥ 0 Nv ₀ ? Yes		Xof	C is ≥ 0. Nv ₀ ? Yes	5 <i>X</i> of
	ispensio idation		Vc1	: 43 V	°c2: 45	30 ≤ 2	X=4 x of Nv x 160? Y	B/1000 ≤			

Table 5.-Suspension of the assay

	N	Vc_1	Vc_2	$Xwm = 1.86 \times 10^9$, $\lg N = 9.27$
Suspension of assay (N and No)	10-7	189	183	$N_0 = N/100$; $\lg N_0 = 7.27$
	10-8	20	18	7.17 ≤ lg N ₀ ≤ 7.70? Yes

Table 6.-Results of the activity assays with the sample

Concentrations of the sample (%)	Dilutions steps	Vc ₁	Vc2	$Lg Na = lg$ $(X \times 10 \text{ o}$ $Xwm \times 10)$	Lg R (Lg N ₀ =7.27)	Time of contact (sec)
079/	Na ⁰	<14	<14	~215	>5.10	60
97%	Na-1	<14	<14	<2.15	>5.12	60

Explanations:

Vc = number per mL (one or two plates); Xwm = weighted mean of X.

 $X = \text{mean of } V_{C1} \text{ and } V_{C2} \text{ (duplicate of } 1 + 2);$

Logarithmic reduction R: ($\lg R = \lg N_0 - \lg N_a$).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay (Bactericidal suspension) with Staphylococcus aureus (CECT 239 = ATCC 6538).

Seeding: Pour plates. No. of plates: 1 /mL.

Table 7.-Validation and controls

	spensio idation		ez	Contro perime ndition	ental		ontrol o tralizat	of the ion (B)	1	idation on nethod (e concen 80%	0.00
Vc1	48	X= 49	Vc1	47	X= 46	Vc1	48	X= 46	Vc1	40	X= 42
V_{C2}	50		Vc2	45	i i	Vc2	44		Vc2	44	
30 ≤ <i>X</i>	of Nv ₀ :	≤ 160?	Xof	A is ≥ (Nv ₀ ? Yes).5 X of	Xof	$B \text{ is } \ge 0$ $N_{V0}?$ Yes		Xof	C is ≥ 0. Nv ₀ ? Yes	5 <i>X</i> of
	spensio dation		Vcı	: 52	°c2: 56		X = 5 x of Nv_1 160? Y	B/1000 ≤			

Table 8.-Suspension of the assay

,	N	Vc_1	Vc2	$Xwm = 1.84 \times 10^8$, $\lg N = 8.27$
Suspension of assay (N and No)	10-6	177	189	$N_0 = N/10$; $\log N_0 = 7.27$
	10-7	20	19	$7.17 \le \lg N_0 \le 7.70$? Yes

Table 9.-Results of the activity assays with the sample

Concentrations of the sample (%)	Dilutions steps	Vc ₁	Vc2	Lg Na = lg (X x 10 o Xwm x 10)	Lg R (Lg N ₀ =7.27)	Time of contact (sec)
000/	Na ⁰	<14	<14	-0.15	25.10	
80%	Na ⁻¹	<14	<14	<2.15	>5.12	60
500/	Na ⁰	<14	<14	200	>5.10	
50%	Na ⁻¹	<14	<14	<2.15	>5.12	60
0.10/	Na ⁰	>330	>330	~4.50	~2.75	60
0.1%	Na-1	>330	>330	>4.52	<2.75	60

Explanations:

Vc = number per mL (one or two plates); Xwm = weighted mean of X.

 $X = \text{mean of } V_{C1} \text{ and } V_{C2} \text{ (duplicate of } 1 + 2);$

Logarithmic reduction R: ($\lg R = \lg N_0 - \lg N_a$).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



Results of the assay (Bactericidal suspension) with Staphylococcus aureus (CECT 239 = ATCC 6538) following the modified method (97%).

Seeding: Pour plates. No. of plates: 1 /mL.

Table 10.-Validation and controls

	ispensio idation		ez	Control operime nditions	ntal		ontrol o ralizat	of the ion (B)	1	idation on nethod (e concen 97%	
Vc1	51	X= 52	Vc1	46	X= 48	Vc1	50	X= 52	Vc1	39	X= 40
V_{C2}	53		Vc2	50		Vc2	54		Vc2	41	
30 ≤ X	of N _{V0}	≤ 160?	X of	A is ≥ 0 Nvo? Yes	.5 X of	Xof	$B \text{ is } \ge 0$ $Nv_0?$ Yes		Xof	C is ≥ 0. Nvo? Yes	5 <i>X</i> of
	spensio dation		Vc1	:56 V	c ₂ : 58	111111111111111111111111111111111111111	X = 5 s of Nv_1 160? Y	$_{\rm B}/1000 \le$			

Table 11.-Suspension of the assay

	N	Vc1	Vc2	$Xwm = 1.97 \times 10^9$, $\lg N = 9.29$
Suspension of assay (N and N_0)	10-7	190	201	$N_0 = N/100$; $\log N_0 = 7.29$
	10-8	22	20	7.17 ≤ lg N ₀ ≤ 7.70? Yes

Table 12.-Results of the activity assays with the sample

Concentrations of the sample (%)	Dilutions steps	Vc1	Vc2	$Lg Na = lg$ $(X \times 10 \text{ o}$ $Xwm \times 10)$	Lg R (Lg N ₀ =7.29)	Time of contact (sec)
0.70/	Na^0	<14	<14	215	>5.14	60
97%	Na ⁻¹	<14	<14	<2.15	>5.14	60

Explanations:

Vc = number per mL (one or two plates); Xwm = weighted mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1 + 2);$

Logarithmic reduction R: ($\lg R = \lg N_0 - \lg N_a$).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay (Bactericidal suspension) with Enterococcus hirae (CECT 4081 = ATCC 10541).

Seeding: Pour plates. No. of plates: 1 /mL.

Table 13.-Validation and controls

	ispensio idation		ez	Control operime ndition	ntal	2.00	ontrol o	of the ion (B)	1	idation on nethod (e concen 80%	0
Vc1	47	X= 49	Vc1	40	X=	Vc1	47	X=	Vc1	45	X= 44
V_{C2}	51		Vc2	44	42	Vc2	42	44.5	Vc2	43	
30 ≤ X	of N ₁₀	≤ 160?	Xof	A is ≥ 0 Nv ₀ ? Yes	.5 X of	Xof	B is ≥ 0 Nv ₀ ? Yes	0.5 X of	Xof	C is ≥ 0. Nvo? Yes	5 X of
	ispensio idation		Vc1	: 50 V	c ₂ : 52		X = 5 $x ext{ of } Nv_1$ $x ext{ 160? } Y$	B/1000 ≤			

Table 14.-Suspension of the assay

	N	Vc_1	Vc2	$Xwm = 1.88 \times 10^8, \lg N = 8.2$
Suspension of assay (N and No)	10-6	181	192	$N_0 = N/10$; $\lg N_0 = 7.27$
	10 ⁻⁷	20	21	7.17 ≤ lg N₀ ≤ 7.70? Yes

Table 15.-Results of the activity assays with the sample

Concentrations of the sample (%)	Dilutions steps	Vc ₁	Vc2	Lg Na = 1g (X x 10 o Xwm x 10)	Lg R (Lg N ₀ =7.27)	Time of contact (sec)
000/	Na ⁰	<14	<14	e2.15	>5.10	60
80%	Na ⁻¹	<14	<14	<2.15	>5.12	00
5007	Na ⁰	<14	<14	~2.15	>510	
50%	Na-1	<14	<14	<2.15	>5.12	60
0.1%	Na ⁰	>330	>330	~ 4.50	-0.75	
0.1%	Na ⁻¹	>330	>330	>4.52	<2.75	60

Explanations:

Vc = number per mL (one or two plates); Xwm = weighted mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1 + 2);$

Logarithmic reduction R: ($\lg R = \lg N_0 - \lg N_a$).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



Results of the assay (Bactericidal suspension) with *Enterococcus hirae* (CECT 4081 = ATCC 10541), following the modified method (97%).

Seeding: Pour plates. No. of plates: 1 /mL.

Table 16.-Validation and controls

	ispensio idation		ez	Control sperime nditions	ntal		ontrol o tralizat	of the ion (B)	I	idation on nethod (e concen 97%	
Vc1	46	X= 47	Vc1	40	X= 42	Vc1	42	X= 44	Vc1	37	X= 36
Vc2	48		Vc2	44	- Vene 19401	Vc2	46		Vc2	35	9.5 0.0
30 ≤ X	of Nv ₀ : Yes	≤ 160?	Xof	$A ext{ is } \ge 0$ Nv_0 ? Yes		Xof	B is ≥ 0 N_{10} ? Yes		Xof	C is ≥ 0. Nv ₀ ? Yes	5 <i>X</i> of
	ispensio idation		Vc	ı: 51 <i>V</i>	c ₂ : 53		X = 5 x of Nv_1 160? Y	$_{\rm B}/1000 \le$			

Table 17.-Suspension of the assay

	N	Vc1	Vc2	$Xwm = 1.84 \times 10^9$, $\lg N = 9.27$
Suspension of assay (N and No)	10-7	179	188	$N_0 = N/100$; $\log N_0 = 7.27$
	10-8	20	18	$7.17 \le \lg N_0 \le 7.70$? Yes

Table 18.-Results of the activity assays with the sample

Concentrations of the sample (%)	Dilutions steps	Vc_1	Vc2	$Lg Na = lg$ $(X \times 10 \text{ o}$ $Xwm \times 10)$	Lg R (Lg N ₀ =7.27)	Time of contact (sec)
070/	Na ⁰	<14	<14	2.15	>5.10	60
97%	Na-1	<14	<14	<2.15	>5.12	60

Explanations:

Vc = number per mL (one or two plates); Xwm = weighted mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1 + 2);$

Logarithmic reduction R: ($\lg R = \lg N_0 - \lg N_a$).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

*Test method accredited # Test performed by subcontractor. Ø Non accredited methods.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests



Results of the assay (Bactericidal suspension) with Escherichia coli K12 (CECT 433 = NCTC 10538).

Seeding: Pour plates. No. of plates: 1 /mL.

Table 19.-Validation and controls

	ispensio idation		ez	Control perime ndition	ntal	1 7 7	ontrol o ralizat	of the ion (B)	11	idation on nethod (e concen 80%	()
Vc1	47	X= 46	Vc_1	40	X=	Vc1	39	X= 38	Vc1	41	X= 42
V_{C2}	45	10	Vc2	39	39.5	Vc2	37		Vc2	43	36
30 ≤ X	of N _{v0} Yes	≤ 160?	X of	A is ≥ 0 Nv ₀ ? Yes		Xof	B is ≥ 0 Nvo? Yes		X of	C is ≥ 0. Nvo? Yes	5 <i>X</i> of
	ispensio idation		Vc1	:45 V	c ₂ : 41		X=4 c of Nv 160? Y	8/1000 ≤			

Table 20.-Suspension of the assay

	N	Vc1	Vc2	$Xwm = 1.72 \times 10^8$, $\lg N = 8.24$
Suspension of assay (N and No)	10-6	168	175	$N_0 = N/10$; $\lg N_0 = 7.24$
8	10-7	19	17	7.17 ≤ lg N ₀ ≤ 7.70? Yes

Table 21.-Results of the activity assays with the sample

Concentrations of the sample (%)	Dilutions steps	Vc ₁	Vc2	Lg Na = 1g (X x 10 o Xwm x 10)	Lg R (Lg N ₀ =7.24)	Time of contact (sec)
000/	Na ⁰	<14	<14	-2.15	> 5 00	
80%	Na -1	<14	<14	<2.15	>5.09	60
500/	Na ⁰	<14	<14	-2.15	> 5.00	
50%	Na ⁻¹	<14	<14	<2.15	>5.09	60
0.10/	Na ⁰	>330	>330	>4.50	<2.72	60
0.1%	Na -1	>330	>330	>4.52	<2.72	60

Explanations:

Vc = number per mL (one or two plates); Xwm = weighted mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1 + 2);$

Logarithmic reduction R: ($\lg R = \lg N_0 - \lg N_a$).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



Results of the assay (Bactericidal suspension) with Escherichia coli K12 (CECT 433 = NCTC 10538), following the modified method (97%).

Seeding: Pour plates. No. of plates: 1 /mL.

Table 22.-Validation and controls

	ispensio idation		ez	Control perime ndition	ntal		ontrol o ralizat	of the ion (B)	n	idation on nethod (e concen 97%	
Vc1	42	X= 43	Vc1	36	X=	Vc1	33	X=	Vcı	37	X= 36
Vc2	44		Vc2	39	37.5	Vc2	36	34.5	Vc2	35	
30 ≤ <i>X</i>	of N ₀ :	≤ 160?	X of	A is ≥ 0 Nv ₀ ? Yes	0.5 X of	X of	B is ≥ 0 Nv ₀ ? Yes		Xof	C is ≥ 0. Nv ₀ ? Yes	5 <i>X</i> of
	ispensio idation		Vcı	: 40 V	ca: 39		X = 39 x of Nv_1 160? Y	B/1000 ≤			

Table 23.-Suspension of the assay

	N	Vc_1	Vc2	$Xwm = 1.74 \times 10^9$, $\lg N = 9.24$
Suspension of assay (N and No)	10-7	180	165	$N_0 = N/100$; $\log N_0 = 7.24$
	10-8	19	18	7.17 ≤ lg N ₀ ≤ 7.70? Yes

Table 24.-Results of the activity assays with the sample

Concentrations of the sample (%)	Dilutions steps	Vc1	Vc2	$Lg Na = lg$ $(X \times 10 \text{ o}$ $Xwm \times 10)$	Lg R (Lg N ₀ =7.24)	Time of contact (sec)
070/	Na ⁰	<14	<14	-2.15	>5.00	60
97%	Na-1	<14	<14	<2.15	>5.09	60

Explanations:

Vc = number per mL (one or two plates); Xwm = weighted mean of X.

 $X = \text{mean of } Vc_1 \text{ and } Vc_2 \text{ (duplicate of } 1 + 2);$

Logarithmic reduction R: ($\lg R = \lg N_0 - \lg Na$).

Laboratory: Bucharest 041914, 8 Berceni Street.

The results relate to the analyzed samples only. The enclosore cannot be reproduced partially without a prior written consent of J.S. Hamilton Romania S.R.L. Responsibility of J.S. Hamilton Romania is restricted exclusively to the results and statements presented in original copy of the enclosore.

JS. HAMILTON ROMANIA S.R.L.

8 Berceni Street, 041902 Bucharest, Romania

Tel.+40 21 634 10 81 bucharest@hamilton.com.pl, www.hamilton.com.pl

Enclosore no. 1 subcontracted tests

^{*}Test method accredited # Test performed by subcontractor. Ø Non accredited methods.



Client: "ECOCHIM-GRUP" S.R.L. str. Nationala, or. Ungheni, Republica Moldova		Description of the sample (as per Client's declaration) Dezinfectant Universal "Bio-Dez"
Sample reception date:	24.08.2023	Lot/Batch: - Production date: 05.08.2023 Expiration date: 05.08.2026
Test report date:	08.09.2023	Sampling date: 23.08.2023 Sampling quantity: 1x 200ml Sample temperature: 17°C Reception hour: 12:30 Responsible for sampling: Crestinov Alexandr Sample condition with no objections

Dermatological test - Open test (25 subjects with allergological history, 25 subjects, without allergological history)

Prepared by: Natalia Dawidowicz, Technician

Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk



THE STUDY IS COMPLIANT WITH:

Regulation of the European Parliament and of the Council (EC) No. 1223/2009 of 30 November 2009 on Cosmetic Products

Cosmetics Europe The Personal Care Association (previously COLIPA) Guidelines Product Test Guidelines for the Assessment of Human Skin Compatibility 1997

Cosmetics Europe The Personal Care Association (previously COLIPA) Guidelines for the Evaluation of the Efficacy of Cosmetic Products 2008

Prepared by: Natalia Dawidowicz, Technician

Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk



LIST OF CONTENTS

- 1. Basis of the study
- 2. Object of the study
- 3. Qualitative composition of the product
- 4. Aim of the study
- 5. Description of volunteers
- 6. Testing methodology
- 7. Date of the study
- 8. Evaluation parameters
- 9. Results
 - 9.1. Characteristics of study subjects
 - 9.2. Table of skin response
- 10. Calculated values
- 11. Interpretation
- 12. Conclusion
- 13. Signatures

Prepared by: Natalia Dawidowicz, Technician

Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk



1. BASIS OF THE STUDY

- Samples delivered by the Sponsor.
- The qualitative composition of the product delivered by the Sponsor.
- The results of microbiological purity of the product provided by the Sponsor (or declaration from the Sponsor about microbiological purity).

The Sponsor is responsible for conformity with the declared quality composition of the product as well as for the microbiological purity test of the delivered samples.

2. OBJECT OF THE STUDY

Parameter	Description
Appearance	Liquid
Colour	Blue
Fragrance	Characteristic for raw materials (or fragrance composition)
Packaging	Replacement packaging containing the name and sample number for testing

3. QUALITATIVE COMPOSITION OF THE PRODUCT

The qualitative composition was delivered to the Laboratory by the Sponsor before the start of the study.

4. PURPOSE OF THE STUDY

The purpose of the study was to assess irritating properties (skin tolerance) of the product on a healthy adult skin, with applied patch test.

Prepared by: Natalia Dawidowicz, Technician

Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk



5. DESCRIPTION OF STUDY SUBJECTS

The study subjects (25 people) were healthy, with negative history of allergy. General inclusion criteria for the selection of study subjects were the following: healthy men and women over 18 years old, phototype: I-IV on Fitzpatrick scale, Caucasians, skin without irritations and changes requiring pharmacological treatment. General exclusion criteria were the following: volunteers who at the time used any treatment on the skin area subject to the study, volunteers exhibiting or having a known history of acute or chronic dermatological, medical and/or physical conditions that could influence the outcome of the study, pregnant or breastfeeding women or women planning a pregnancy during the study. None of the study subjects reported documented oversensitivity or history of adverse reactions to individual ingredients of the product tested. All the study subjects fulfilled the requirements of inclusion for tests and signed the Informed Consent Form (ICF). Additionally, they were informed on the purpose, methodology of the study and possible adverse effects. The skin at the application area (arms or interscapular area) was healthy, without lesions. The study subjects were advised to exercise caution in handling the applied contact tests.

6. TESTING METHODOLOGY

The preparation in the appropriate concentration was applied onto to the skin on the forearm in the area of 3x3 cm. The reading of skin response was performed 15 minutes, 30 minutes, 1 hour, and 24 hours after the test application. Simultaneously, to assure the objectivity of the results of the study and in order to exclude possible reading errors connected with dermal irritations one sample control (control sample with water) was carried out. The results of the study are presented in section 10 of this report. If irritations appeared or persisted 24h after the application, an additional examination took place after 48 hours. Determining the response of the skin, the dermatologist assessed the irritating and sensitising effects of the tested product. The study results might have been influenced by factors such as lifestyle, stress, diet and environmental conditions, etc.

7. DATE OF THE STUDY

05.09.2023 - 08.09.2023

Prepared by: Natalia Dawidowicz, Technician

Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk



8. EVALUATION PARAMETERS

EVALUATION PARAMETERS OF SKIN REACTION				
Erythema	Classification point			
No erythema	0			
Light erythema	0.5			
Erythema and/or papules	1			
Erythema and/or papules and/or vesicles	2			
Erythema and/or papules and/or vesicles and/or blisters	3			
Erythema Bullous and/or ulcerative reaction and/or papules and/or vesicles and/or blisters	4			
Edema	Classification point			
No edema	0			
Very light edema (hardly visible)	1			
Light edema	2			
Moderate edema (about 1mm raised skin)	3			
Strong edema (extended swelling even beyond the application area)	4			

Prepared by: Natalia Dawidowicz, Technician Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk



9. RESULTS

CHARACTERISTICS OF VOLUNTEERS 9.1.

Table 1

No. of subject	Identification of subject	Begining of the study	Age	Sex	Phototype
1	CHY.AG	05.09.2023	26	F	II
2	DAW.NA	05.09.2023	24	F	II
3	BIE.IZ	05.09.2023	34	F	II
4	KOC.KR	05.09.2023	54	М	II
5	KRZ.EW	05.09.2023	37	F	II
6	ZAM.PA	05.09.2023	32	F	II
7	JAG.KR	05.09.2023	32	М	II
8	URB.BA	05.09.2023	65	F	II
9	TRE.MI	05.09.2023	57	F	II
10	BOC.AL	05.09.2023	44	F	II
11	FLI.AN	05.09.2023	35	F	II
12	PAC.NA	05.09.2023	24	F	II
13	KIE.MA	05.09.2023	26	F	II
14	ZAW.AG	05.09.2023	41	F	II
15	FUS.MO	05.09.2023	28	F	II
16	MAM.AG	05.09.2023	24	F	II
17	WEN.MO	05.09.2023	25	F	II
18	WOD.KA	05.09.2023	34	F	II
19	KOS.DO	05.09.2023	23	F	II
20	NOW.AR	05.09.2023	51	М	II
21	SEP.JA	05.09.2023	42	М	II
22	PIS.PI	05.09.2023	46	М	II
23	JER.DA	05.09.2023	56	F	II
24	MUS.NA	05.09.2023	37	F	II
25	BEC.EL	05.09.2023	58	F	II
		Min	23	No. F	phototype I
		Max	65	20	0
		Average	38	No. M	phototype II
				5	25
					phototype III

phototype IV 0

Table 1. Characteristics of volunteers with a negative history of allergy

Prepared by: Natalia Dawidowicz, Technician

Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk



Table 2

Table 2					
No. of subject	Identification of subject	Begining of the study	Age	Sex	Phototype
1	CIE.MA	05.09.2023	62	F	II
2	SZY.UR	05.09.2023	37	F	II
3	TRO.MA	05.09.2023	44	F	II
4	SKU.IW	05.09.2023	45	F	II
5	SZY.MA	05.09.2023	51	F	II
6	ARB.YU	05.09.2023	22	F	II
7	KOR.DO	05.09.2023	48	F	II
8	GAN.MA	05.09.2023	59	F	II
9	TAR.AG	05.09.2023	58	F	II
10	RAT.EM	05.09.2023	38	F	II
11	PIO.EL	05.09.2023	53	F	II
12	KWI.BO	05.09.2023	68	F	II
13	WYS.BE	05.09.2023	35	F	II
14	ARB.AL	05.09.2023	22	F	II
15	ARB.LU	05.09.2023	45	F	II
16	ZAL.IZ	05.09.2023	44	F	II
17	SLE.AG	05.09.2023	45	F	II
18	GOR.AG	05.09.2023	22	F	II
19	WAN.SY	05.09.2023	25	F	II
20	SZE.KA	05.09.2023	22	F	II
21	HIR.HA	05.09.2023	47	F	II
22	RAD.MA	05.09.2023	57	F	II
23	MAN.MA	05.09.2023	48	F	II
24	HAN.AN	05.09.2023	23	F	II
25	ROZ.AG	05.09.2023	41	F	II
		Min	22	No. F	phototype I
		Max	68	25	0
		Average	42	No. M	phototype II
				0	25
					phototype III
					phototype IV
					hilototype IV

Table 2. Characteristics of volunteers with a positive history of allergy

Prepared by: Natalia Dawidowicz, Technician

Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk



TABLE OF SKIN RESPONSE 9.2.

Table 3

No.	Evaluation after 15 minutes of product application		30 minu produ	20 minutes of		Evaluation after 1 hour of product application		after 24 product tion	Evaluation hours of p applica	roduct
	Erythema	Edema	Erythema	Edema	Erythema	Edema	Erythema	Edema	Erythema	Edema
1	0	0	0	0	0	0	0	0	Examination	skipped
2	0	0	0	0	0	0	0	0	Examination	skipped
3	0	0	0	0	0	0	0	0	Examination	skipped
4	0	0	0	0	0	0	0	0	Examination	skipped
5	0	0	0	0	0	0	0	0	Examination	skipped
6	0	0	0	0	0	0	0	0	Examination	skipped
7	0	0	0	0	0	0	0	0	Examination	skipped
8	0	0	0	0	0	0	0	0	Examination	skipped
9	0	0	0	0	0	0	0	0	Examination	skipped
10	0	0	0	0	0	0	0	0	Examination	skipped
11	0	0	0	0	0	0	0	0	Examination	skipped
12	0	0	0	0	0	0	0	0	Examination	skipped
13	0	0	0	0	0	0	0	0	Examination	skipped
14	0	0	0	0	0	0	0	0	Examination	skipped
15	0	0	0	0	0	0	0	0	Examination	skipped
16	0	0	0	0	0	0	0	0	Examination	skipped
17	0	0	0	0	0	0	0	0	Examination	skipped
18	0	0	0	0	0	0	0	0	Examination	skipped
19	0	0	0	0	0	0	0	0	Examination	skipped
20	0	0	0	0	0	0	0	0	Examination	skipped
21	0	0	0	0	0	0	0	0	Examination	skipped
22	0	0	0	0	0	0	0	0	Examination	skipped
23	0	0	0	0	0	0	0	0	Examination	skipped
24	0	0	0	0	0	0	0	0	Examination	skipped
25	0	0	0	0	0	0	0	0	Examination	skipped

Table 3. Results for volunteers with a negative history of allergy

Prepared by: Natalia Dawidowicz, Technician Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk



Table 4

No.	Evaluation after 15 minutes of product application		30 minu produ	Evaluation after 30 minutes of product application		Evaluation after 1 hour of product application		after 24 product tion	Evaluation hours of p applica	roduct
	Erythema	Edema	Erythema	Edema	Erythema	Edema	Erythema	Edema	Erythema	Edema
1	0	0	0	0	0	0	0	0	Examination	skipped
2	0	0	0	0	0	0	0	0	Examination	skipped
3	0	0	0	0	0	0	0	0	Examination	skipped
4	0	0	0	0	0	0	0	0	Examination	skipped
5	0	0	0	0	0	0	0	0	Examination	skipped
6	0	0	0	0	0	0	0	0	Examination	skipped
7	0	0	0	0	0	0	0	0	Examination	skipped
8	0	0	0	0	0	0	0	0	Examination	skipped
9	0	0	0	0	0	0	0	0	Examination	skipped
10	0	0	0	0	0	0	0	0	Examination	skipped
11	0	0	0	0	0	0	0	0	Examination	skipped
12	0	0	0	0	0	0	0	0	Examination	skipped
13	0	0	0	0	0	0	0	0	Examination	skipped
14	0	0	0	0	0	0	0	0	Examination	skipped
15	0	0	0	0	0	0	0	0	Examination	skipped
16	0	0	0	0	0	0	0	0	Examination	skipped
17	0	0	0	0	0	0	0	0	Examination	skipped
18	0	0	0	0	0	0	0	0	Examination	skipped
19	0	0	0	0	0	0	0	0	Examination	skipped
20	0	0	0	0	0	0	0	0	Examination	skipped
21	0	0	0	0	0	0	0	0	Examination	skipped
22	0	0	0	0	0	0	0	0	Examination	skipped
23	0	0	0	0	0	0	0	0	Examination	skipped
24	0	0	0	0	0	0	0	0	Examination	skipped
25	0	0	0	0	0	0	0	0	Examination	skipped

Table 4. Results for volunteers with a positive history of allergy

Prepared by: Natalia Dawidowicz, Technician Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk



10. CALCULATED VALUES

The following calculated values present the sum of negative reaction (erythema and edema) defined as Average Irritation Index (Xav).

	Evaluation after 15 minutes of product application	Evaluation after 30 minutes of product application	Evaluation after 1 hour of product application	Evaluation after 24 hours of product application	Evaluation after 48 hours of product application
The sum of negative reaction (the sum of classification points)	0,00	0,00	0,00	0,00	Examination skipped
X _{av}			0,00		

11. INTERPRETATION

The average irritation index (Xav) was calculated. The product was then classified according to the following table:

Average irritation index (xav)	Class
X _{av} < 0.50	Not irritating
$0.50 \le X_{av} < 2.00$	Slightly irritating
$2.00 \le X_{av} < 5.00$	Moderately irritating
5.00 ≤ X _{av}	Highly irritating

Prepared by: Natalia Dawidowicz, Technician

Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk



12. CONCLUSION

The patch test study was performed under dermatological control on a group of 25 volunteers. The study allowed the investigators to conclude that product Dezinfectant Universal "Bio-Dez" used by volunteers that didn't report documented oversensitivity or a history of adverse reactions to individual ingredients of the tested product, was well tolerated by the skin. In the tested group of volunteers there were no irritations or allergic reactions. The product meets the requirements of compatibility test with the skin (Skin Compatibility Test) and can be classified as NOT IRRITATING.

Prepared by: Natalia Dawidowicz, Technician

Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk



13. SIGNATURES

Technician	Natalia Dawidowicz	
Dermatologist - venereologist	Karolina Osiecka (2487308)	
Project Manager	Paulina Maciszka	

^{*}The Sponsor is responsible for conformity with the declared quality composition as well as microbiological purity of the delivered samples.

Attention: The released opinion of dermatological compatibility does not apply to people who are allergic to any ingredient of the tested product.

Prepared by: Natalia Dawidowicz, Technician

Authorized by: Karolina Osiecka (2487308), Dermatologist - venereologist Paulina Maciszka, Project Manager (qualified electronic signature)

Laboratory: ul. Bajana 3D, 80-463 Gdańsk

Instituto Valenciano de Microbiología



Masía El Romeral Ctra. Bétera – San Antonio de Benagéber, Km 0,3 46117 Bétera (Valencia) Tel. 96 169 17 02 e-mail: <u>ivami@ivami.com</u> www.ivami.com



Test with the certificate of GLPs (Good Laboratory Practices) No. 2/21-C.VAL. General Directorate of Pharmacy and Medical Devices of the Health Department of the Valencian Region. Spain

Mycobactericidal activity of chemical disinfectants in the medical area including instrument disinfectants (phase 2, step 1), with the product "Dezinfectant Universal "Bio-Dez"".

(EN 14348: 2005 Standard)

Re	port
----	------

Registration No.: D/23/B0672.

1. Laboratory identificationInstituto Valenciano de Microbiología.2. Client identificationJ.S. HAMILTON ROMANIA SRL.
SOS BERCENI, NR 8, SECTOR 4
BUCURESTI, ROMANIA, 041914.

3. Sample identification (information provided by the client)

CIF B-96337217

Dezinfectant Universal "Bio-Dez". Product name 60363/23/ROBCH. Batch number 05.08.2026. • Expiration date Manufacturer/Supplier SRL "Ecochim-Grup". Not indicated. Keeping conditions Hygienic handrub, Instrument disinfection, Condition for use surface disinfection. Not indicated. Diluent recommended by the manufacturer ... Ethyl alcool 72-76%, CAS 64-17-5 and CE Active compound/s and its concentration/s ... 200-578-6 Benzalkonium chloride 0.024-0.029%, CAS 68424-85-1 and CE 270-325-2 Methylthionibium chloride 0.00024%, CAS 61-73-4 and 200-515-2. 80% Concentrations requested for the assay

IVAMI is not responsible for client-supplied information. This information **is not covered** by the ENAC accreditation.

DESIN-1052-b // EN 14348: 2005 Version 3 (2019-10-02) Page 1 of 6 Registration No.: D/23/B0672 Instituto Valenciano de Microbiología

4. Information about sample reception

• Date of reception of the sample 2023/08/31.

• Date of reception of order with test conditions

• Aspect of the received samples...... Purple transparent liquid in plastic package.

5. Method of assay and its validation (EN 14348: 2005 Standard)

• Method used Dilution-neutralization.

2023/08/25.

lecithin 7 g/L, polisorbate-80 5 g/L, glycine 1 g/L,

1-histidine 1 g/L and saponin 30 g/L.

6. Experimental conditions

• Solvent of the product used in the assay ... Sterile distilled water.

• Product concentrations for the assay 80%, 50% and 0.1%.

• Aspect of the dilutions of the product 80% purple transparent liquid;

50% blue transparent liquid; 0.1% transparent liquid.

• Interfering substance Bovine serum albumin 3 g/L and erythrocytes 3

mL/L.

• Stability of the mixture (interfering substance and product diluted in sterile distilled water)

• Identification of the strains used

- Mycobacterium avium (ATCC 15769).
- *Mycobacterium terrae* (CECT 3028 = ATCC 15755).

7. Results of the assay

Control and validation assays
Evaluation of mycobactericidal activity
See tables 1, 2, 4 and 5.
See tables 3 and 6.

Number of replicates for each assay microorganism

1.

DESIN-1052-b // EN 14348: 2005 Version 3 (2019-10-02) Page 2 of 6 Registration No.: D/23/B0672 Instituto Valenciano de Microbiología

8. Special remarks

- All controls and validation were between the basic limits.
- For a valid test, at least one concentration must show a reduction lower than 4 log and at least one concentration must show a reduction equal or higher than 4 log.
- The highest concentration that can be assayed in the test (80%) is due to the mixtures to perform the assay.

9. Conclusion

The product **Dezinfectant Universal "Bio-Dez"**, batch 60363/23/ROBCH, when it is pure (80%), concentration requested by the client, **shows mycobactericidal activity** after 60 seconds, at $20^{\circ}C \pm 1^{\circ}C$, under dirty conditions (bovine serum albumin 3 g/L and erythrocytes 3 mL/L), against the strains *Mycobacterium avium* (ATCC 15769) and *Mycobacterium terrae* (CECT 3028 = ATCC 15755), when tested as required by **EN 14348: 2005 Standard**.

Note: The results obtained correspond to the sample received in the laboratory.

Use of the ENAC mark: The ENAC "mark" can only be used by the holder of the accreditation. Its use in packaging, installations, shop windows, advertising or other documentation format other than that issued by the accredited entity (IVAMI) is not allowed.

Bétera (Valencia), November 9, 2023.

MIGUEL FRANCO, CLAUDIA (FIRMA)

Signed: Claudia Miguel. Responsible Technician

Quality Assurance Review:

The assay development and the results obtained have been supervised by the Director of the study.

The Quality Assurance Director has inspected the development of the assay, proving that has been realized following the proper procedure and using the adequate media, materials and reagents, following as well the Good Laboratory Practices (GLPs) and the final report contains the primary data obtained.



Signed. Elena Montoya. Responsible for the Laboratory Area (Study Director) ESTEBAN BERMUDEZ, ENCARNACION PILAR (FIRMA)

Signed. Encarnación Esteban. Technical Director (Quality Assurance Director)

Reference

• EN 14348: 2005. Chemical disinfectants and antiseptics. Quantitative suspension test for the evaluation of mycobactericidal activity of chemical disinfectants in the medical area including instrument disinfectants. Test methods and requirements (phase 2, step 1).

DESIN-1052-b // EN 14348: 2005 Version 3 (2019-10-02) Page 4 of 6 Registration No.: D/23/B0672 Instituto Valenciano de Microbiología

Table 1.-Assay with Mycobacterium avium (ATCC 15769): Validation and controls.

Suspension of validation (Nv ₀)			Control of experimental conditions (A)		Neutralizer (B)		Validation of the method (C) with sample concentration: 80%				
Vc ₁	97	X =	Vc ₁	98	X = 96	Vc ₁	92	X = 95	Vc ₁	93	X = 91
Vc_2	104	100.5	Vc_2	94		Vc_2	98		Vc_2	89	
$30 \le X \text{ of } Nv_0 \le 160$?		$X \text{ of } A \text{ is } \ge 0.5 \text{ x } X$		$X \text{ of } B \text{ is } \ge 0.5 \text{ x } X \text{ of }$		$X \text{ of } C \text{ is } \ge 0.5 \text{ x } X \text{ of }$					
Yes			of Nvo? Yes		Nv ₀ ? Yes		Nv ₀ ? Yes				

Table 2.- Assay with *Mycobacterium avium* (ATCC 15769): Suspension of the assay.

	N	Vc_1	Vc_2	
Suspension of the assay (N y	10-7	391	405	$Xwm = 4.00 \times 10^9 = 1g = 9.60$ $N_0 = N/10 = 1g = 8.60$
N_0)	10-8	44	41	$8.17 \le N_0 \le 8.70$? Yes

Table 3.- Assay with Mycobacterium avium (ATCC 15769).

Concentrations of the sample (%)	Dilutions	Vc ₁	Vc2	$Lg Na = lg$ $(X \times 10 \text{ o}$ $Xwm \times 10)$	$LgR (lgN_0 = 8.60)$	Time of contact (sec)
	10^{0}	<14	<14	< 2.15	> 6.45	60
80 %	10-1	<14	<14			
8U 70	10-2	<14	<14			
	10-3	<14	<14			
	10^{0}	<14	<14	< 2.15	> 6.45	60
50 %	10-1	<14	<14			
30 /0	10-2	<14	<14			
	10-3	<14	<14			
	10^{0}	>660	>660	>6.82	<1.78	60
0.1 %	10-1	>660	>660			
0.1 70	10-2	>660	>660			
	10-3	>660	>660			

Observations:

$$N$$
 10⁻⁷: 198 + 193; 202 + 203;
10⁻⁸: 20 + 24; 19 + 22;
 Na 80% 10⁰: 0 + 0; 0 + 0;
50% 10⁰: 0 + 0; 0 + 0;
0.1% 10⁻³: >330 +>330; >330 +>330;

DESIN-1052-b // EN 14348: 2005 Version 3 (2019-10-02) Page 5 of 6 Registration No.: D/23/B0672 Instituto Valenciano de Microbiología

Table 4.-Assay with *Mycobacterium terrae* (CECT 3028 = ATCC 15755): Validation and controls.

Suspension of validation (Nv ₀)	Control of experimental conditions (A)	Neutralizer (B)	Validation of the method (C) with sample concentration: 80%		
$ Vc_1 $ 79 $ X=$	$Vc_1 = 66$ $X = 68$	Vc_1 75 $X = 77$	$ Vc_1 $ 67 $X=$		
<i>Vc</i> ₂ 82 80.5	Vc_2 70 $A - 08$	Vc_2 79 $A - 77$	<i>Vc</i> ₂ 72 69.5		
$30 \le X \text{ of } Nv_0 \le 160?$	$X \text{ of } A \text{ is } \ge 0.5 \text{ x } X$	$X \text{ of } B \text{ is } \ge 0.5 \text{ x } X \text{ of }$	$X \text{ of } C \text{ is } \ge 0.5 \text{ x } X \text{ of }$		
Yes	of Nv ₀ ? Yes	Nv ₀ ? Yes	Nv ₀ ? Yes		

Table 5.- Assay with *Mycobacterium terrae* (CECT 3028 = ATCC 15755): Suspension of the assay.

Suspension of	N	Vc_1	Vc_2	
the assay (N y	10-7	295	275	$Xwm = 2.86 \times 10^9 = 1g = 9.46$
N_0)	10-8	32	29	$N_0 = N/10 = \lg = 8.46$ 8.17 \le N_0 \le 8.70? Yes

Table 6.- Assay with *Mycobacterium terrae* (CECT 3028 = ATCC 15755).

Concentrations of the sample (%)	Dilutions	Vc ₁	Vc2	$Lg Na = lg$ $(X \times 10 \text{ o}$ $Xwm \times 10)$	LgR (lgN0 = 8.46)	Time of contact (sec)
	10^{0}	<14	<14	<2.15	>6.31	60
80 %	10-1	<14	<14			
80 /0	10-2	<14	<14			
	10-3	<14	<14			
	10^{0}	<14	<14	<2.15	>6.31	60
50 %	10-1	<14	<14			
30 70	10-2	<14	<14			
	10-3	<14	<14			
	10^{0}	>660	>660	>6.82	<1.64	60
0.1%	10-1	>660	>660			
0.170	10-2	>660	>660			
	10-3	>660	>660			

Observations:

N

$$10^{-7}$$
: $150 + 145$; $130 + 145$;
 Nv₀: $40 + 39$; $40 + 42$;

 10^{-8} : $17 + 15$; $14 + 15$;
 A: $32 + 34$; $34 + 36$;

 Na
 80% 10^{0} : $0 + 0$; $0 + 0$;
 B: $39 + 36$; $40 + 39$;

 50%
 10^{0} : $0 + 0$; $0 + 0$;
 C: $36 + 31$; $35 + 37$;

 0.1%
 10^{-3} : $>330 + >330$; $>330 + >330$;

Explanations:

Vc: Counts per mL.

Xwm: weighted mean of X.

X: Values of Vc_1 and Vc_2 (1. + 2. duplicates); R: reduction (Lg $R = \lg N_0 - \lg Na$).

DESIN-1052-b // EN 14348: 2005 Version 3 (2019-10-02) Page 6 of 6 Registration No.: D/23/B0672 Instituto Valenciano de Microbiología