


1. Disassemble TCB version 1.
2. Assemble TCB version 2/3 in new position with enclosed screws and spacers.
3. Remove cable adapter A.
4. Connect flex cable D directly from touch to TCB version 2/3.

1. TCB Version 1 demontieren.
2. Mit beigefügten Schrauben/Abstandshaltern TCB Version 2/3 in neue Position montieren.
3. Kabeladapter A entfernen.
4. Flex-Kabel D vom Touch direkt an TCB Version 2/3 anschließen.



TCB Version 1

A




B

C





TCB Version 2

D




C

B



C

B



B

TCB Version 3

D



C

B