

System Microscope SMART Operation Instruction



To ensure the safety and obtain satisfactory performance, please study this operation instruction thoroughly before your operation.

CONTENTS

| Purpose | 1 |
|---------------------|---|
| 1. Parts Name | 2 |
| 2. Specifications | 3 |
| 3. Installation | 4 |
| 4. Operation | 5 |
| 5. Image Collection | 5 |
| 6. Maintenance | 6 |
| 7. Troubleshooting | 7 |
| 8. Outfits | 8 |


Our biological microscope

is designed for college teaching, clinical verify. The series microscope with original style, steady structure, convenient operation and clear image is suitable for observing various biological specimens, and mostly applied in college and hospital.



1. Pars Name

L



- Eyepiece
 Objective
- 3 Clamp
- -
- (4) Mechanical Stage
- (5) Condenser
- 6 Light Collector
- ⑦ Main Body

Fuse

- Seidentopf
- Binocular Head (Trinocular Head)
 Power Input
- **A** Diopter Adjustment Ring

9{

- **B** Nosepiece
- **C** Clamp Handle
- **D** Handle of Iris Aperture Diaphragm
- **E** Field Diaphragm Ring
- **F** Body Handle
- **G** Head Thrumb Screw
- **H** Mechanical Stage Moving Knob
- J Right Coarse & Fine Focusing Knobs
- \mathbf{K} Potentiometer
- L Power Switch
- M Condenser Focusing Knob

Tension Adjustment Ring

Left Coarse & Fine Focusing Knobs

N

N{

2. Specifications

2.1 Total magnifications

| Objective Total Magnifications Eyepiece | 4X | 10X | 20X (Optional) | 40X | 100X |
|---|-----|------|-------------------|------|-------|
| 10X | 40X | 100X | 200X | 400X | 1000X |
| 16X | 64X | 160X | 320X | 640X | 1600X |

2.2 Objectives (with eyepiece 10X)

| Infinity Plan Achromatic Objective | Numerical Aperture (N.A.) | Objective Field $(\varphi 20)$ | Resolving Power | Working Distance |
|---------------------------------------|------------------------------|--------------------------------|----------------------|---------------------|
| 4X | 0.10 | 5mm | 3.35µm | 12.1mm |
| 10X | 0.25 | 2mm | 1.34µm | 4.64mm |
| 20X (S) | 0.40 | 1mm | <mark>0.84</mark> μm | 2.41mm |
| 40X (S) | 0.66 | 0.5mm | <mark>0.51</mark> μm | 0.65mm |
| 100X (Oil) (S) | 1.25 | 0.2mm | <mark>0.27</mark> μm | 0.19mm |

The other specification

- 2.3.1 Mechanical tube length: 160mm
- 2.3.2 Conjugate distance: Infinity (Non- Infinity: 195mm)
- 2.3.3 Head: Seidentopf Binocular or Trinocualr, Inclined 30°, Rotable 360°,

Anti-fungal systems. Interpupillary Adjustable Distance Is 48-75mm,

Diopter adjustable range ± 5 .

- 2.3.4 Nosepiece: Quadplex nosepiece
- 2.3.5 Mechanical stage: Size 145mm×140mm X-Y travel 76mm×52mm

2.3.6 Focusing systems: Coaxial Coarse And Fine Focusing Knobs, Coarse stroke 26mm,

Fine division 2µm, Condenser up-down range 22mm

- 2.3.7 Condenser: Abbe condenser, N.A. 1.25, Adjustable aperture, Aperture center can be adjustable.
- 2.3.8 Illumination: Kohler Non-spherical System
- 2.3.9 Filter: Built in blue filer
- 2.3.10 Electric components: Input voltage AC100-240V, 50/60Hz

Output voltage DC3-12V/LED DC0.4-3.5V

12V/20W halogen lamp/3W LED

Rotation potentiometer with power switch

Fuse 5A ϕ 5×20/2A ϕ 5×20

3. Installation

Please clean the operation desk before installation. Put out the microscope of the carton and put it on the desk.

Make sure the supply voltage meets the instrument's requirement and the power switch is off.

Installation Instruction Fig.:

- 1. Turn the binocular (trinocular) head to working position;
- 2. Put out the dust cover of the eyepiece tube;
- 3. Insert into the eyepiece;
- 4. Install Abbe Condenser


3.1 Eyepiece Tube:

Loose the Head Thrumb Screw G, turn the tube to observing position, then tighten the Screw G.

3.2 Put out the eyepiece dust cover.


3.3 Eyepiece

Put out the eyepiece of the carton, and insert it into the tube. Please don't touch the lens of the eyepiece by hand.



installing ring

Condenser




3.4 Condenser


Put out the condenser of the carton, then turn Condenser Focusing Knob M to lower condenser installing ring. Loose the condenser screw, then install the condenser, and make the condenser graduation face to the front, Tighten the condenser screw, and higher the condenser installing ring to top.


Please don't touch the lens by hand.

3.5 Power Put in power, open Switch L, and turn Potentiometer J.



4. Operation





5.Image Collection

5.1 Installing

Connect the C-mount with CCD camera or connect camera with camera adaptor, then connect it with c-mount, finally put it into microscope.

5.2 Using

First get a clear image from eyepiece, then put out lever on the side of trinocular head, and collect image with camera. Clear image should be in screen. Adjust B14 fine focusing knobs to get it clear if image isn't clear.

6.Maintenance

6.1 Clean microscope

6.1.1 Don't touch the lens with hand, Dust on lens should be cleaned by soft brush or absorbent cotton or cleaned by absorbent cotton, lens paper with the mixture of alcohol and ether (proportion 1:4).

6.1.2 Alcohol and ether all are burnt early, please take them away from fire. Be careful for turn on and off power.

6.1.3 Don't clean painted metal and galvanizing metal with organic solvent such as alcohol, ether or the mixture of the both. Silicon cloth or soft cleaning preparation is suggested to clean it.

6.1.4 Plastic should be cleaned by soft cloth with clear water.

6.2 Environment of using and placing

6.2.1 Microscope should be used and placed in a cool, dry, non-dust, non-shake and non-corrosive gases environment.

6.2.2 Microscope should be used in environment of indoor temperature 0° -40° C and maximum relative humidity 85%.

6.2.3 Removing equipment is suggested to be installed when microscope used in heavy humidity area to avoid fungus and mist damage instrument.

6.2.4 Please pay attention to prevent microscope from violent shake and vibration in application and in carrying. Don't drag it on the surface of worktable to avoid damage to microscope and worktable.

6.3 Replacement of bulb

6.3.1 Turn off power, and pull out plug.

6.3.2 Wait the bulb become cool.

- ▲ Please be sure that the bulb is cool, then follow by the nest operations.

6.3.3 Lay aside the microscope reliably, unscrew the knurled thumb screw of the lamp housing cover on the underside of base.

6.3.4 Pull over the lamp housing cover.

6.3.5 Pull out the bulb should be replaced, hold a

new bulb with silk cloth to avoid fingerprint and dust

affect bulb brightness and service life, and insert fully the contact pins into the bulb socket. 6.3.6 Close the lamp housing cover, and screw the knurled thumb screw.

▲ After working for above 10 hours continuously, better cut off the microscope about 30 minutes.

▲ If the LED light source needs to be replaced, please contact the dealer or manufacturer in time.

6.4 Replacement of fuse

6.4.1 Cut off power of microscope, and pull out the plug.

6.4.2 Unscrew fuse cap in the back of base, take out old fuse.

6.4.3 Replace a new fuse, then screw the fuse cap.

7.Troubleshooting

In the period of using Smart series microscope, if there is any trouble occurs, please referring to the following sheet listed some common troubleshooting resolve them.

| Trouble | Causation | Remedy | |
|--|--|---|--|
| Switch on but bulb dark | Plug is unreliable | Plug in again | |
| | Bulb is broken | Change bulb | |
| | Fuse is broken | Change fuse | |
| Bulb is flickering or | Bulb is unstable | Insert it again | |
| brightness is unsteady | Bulb is broken | Replacing bulb | |
| Brightness of view field isn't enough or is Uneven | Bulb specification doesn't meet the requirement | Replacing bulb | |
| | Brightness isn't adjusted correctly | Adjust rotation potentiometer | |
| | Objective isn't in correct position | Make the objective in correct position | |
| | The size of iris aperture is too small | Adjust the size of iris aperture | |
| Brightness of view field isn't enough or is | Lens (objective,eyepiece, condenser, light collector) has dust | Clean it | |
| Uneven | Position of condenser is too low | Higher condenser | |
| Image isn't clear | Cover glass of specimen doesn't meet the requirement | Use required thickness cover glass (0.17mm) | |
| | Cover glass of specimen isn't in up direction | Place specimen correctly | |
| | Surface of objective lens isdirty (especially it is easy for the front lens of 40X objective to dip in immersion oil) | Clean it | |
| (contrast or definition isn't enough) | Immersion oil isn't used for 100X objective (oil) | Use immersion oil | |
| | Immersion oil doesn't meet the requirement | Use immersion oil supplied by us | |
| | There is bubble in immersion oil | Clear the bubble way | |
| | Size of iris aperture isn't proper | Adjust the size of iris aperture | |
| | Position of condenser is too low | Readjust the position of condenser | |
| One side of image is dark or image is moving as focusing | Objective isn't in correct position | Make the objective in correct position | |
| | Specimen isn't placed correctly | Place specimen levelly on stage and clip it with clamp | |
| Objective touches specimen as changing | Cover glass of specimen isn't in up direction | Place specimen correctly | |
| low times objective to high times objective | Cover glass doesn't meet the requirement | Use required thickness cover glass (0.17mm) | |
| Image observed by two eyes aren't in superposition entirely. | Interpupilary distance isn't adjusted correctly | Adjust interpupilary distance according to two eyes | |
| It is easy for eyes to be tired during observing | Diopter isn't adjusted correctly | Readjust diopter | |