

Label Template

Documents NoRelationTD.OD.ET.0106.0

Release date 06.04.2020

Revision No

Revision Date


1		2	3		4
Sümer		Ürün Adı /Model	MD	CE 2195	
6		7		8	
		SN	хххххх	\sim	ххххх
9	10	11	12	13	14
		木	IP20	\wedge	Giriş Gücü: AC 100-240V 50/60 Hz Max 2.2A
15	16		-	17	-
TD.OD.ET.01 Rev. No:00 Rev. Tarihi://	Ĵ		Merkez Adres: G.M. Kızılay/Ankara Üretim Adresi: Başk Malıköy Sincan/Anka Telefon: 0312 384 6 Faks: 0312 394 6195	ara 173 / 0312 503 0821	esi, Başkent Bulvarı No:81

Symbols and Explanations				
1	Company Logo	10	See User Manual	
2	Product Name/Model	11	Applied Divisions (Type B)	
3	Medical Device Mark	12	IP Statement	
4	CE mark	13	Follow the Warnings Given in the Instruction.	
6	Barcode number	14	Supply Voltage/Power	
7	Serial number	15	Label Information	
8	Production date	16	Keep Away From Contact With Water	
9	Protective Grounding	17	Manufacturer Information	



Notification Label Template

Documents No	Release date	Revision No	Revision Date	
TD.OD.ET.02	22.02.2021	00		



Symbol Meaning		explanation		
1	Oxygen Flow Direction	Indicates the flow direction of oxygen in the system.		
2	Compressed Air Flow Direction	It indicates the flow direction of the compressed air in the system.		
3	Combustible Substance- Oxidizing Gas	Keep equipment in a well-ventilated area and keep fumes away from flammable materials.		
4	Electric Shock Risk - Voltage	Disconnect the system from power supply and power before maintenance or technical service.		
5	Rollover Risk	Beware of the risk of tipping. Do not stand around parts that could tip over.		
6	Pressure Output	Depressurize the equipment before maintenance or technical service.		
7	Do Not Breathe Gases!	The equipment should be placed in a well-ventilated area. Inhalation of gases should be avoided.		
8	Attention!	Care must be taken while performing the procedure.		
9	Hot Surface	Do not touch the hot surface until it has cooled.		